## **Preface**

Thank you for choosing GTAKE **GK820 Series High Performance AC Motor Drives**. This user manual presents a detailed description of GK820 series with respect to product features, structural characteristics, functions, installation, parameter setting, troubleshooting, commissioning and daily maintenance, etc. Be sure to carefully read through the safety precautions before use, and use this product on the premise that personnel and equipment safety is ensured.

#### **IMPORTANT NOTES**

- Please assure the intactness of product enclosure and all safety covers before installation.
   Operation must conform to the requirements of this manual and local industrial safety regulations and/or electrical codes.
- Contents of this manual may be subject to appropriate modification as a result of product upgrade, specification change and update of the manual.
- In the event of damage or loss of user manual, users may ask local distributors, offices or our Technical Service Department for a new one.
- If any item as stated in this manual is not clear, please contact our Technical Service Department.
- If any anomaly occurs after power up or during the operation, it is essential to stop the machine and identify the fault or seek technical services as soon as possible.
- Telephone number of our Technical Service Department: (+86) 0755-86392601.

## **Table of Contents**

Preface		1 -
Chapter 1	1 Safety Precautions	1 -
1.1	Safety Considerations	1 -
1.2	Other Considerations	5 -
Chapter 2	2 Product Information	7 -
2.1	Model Explanation	7 -
2.2	Nameplate Information	7 -
2.3	Information of Product Model	8 -
2.4	Technical Features of GK820	10 -
2.5	Parts Drawing	13 -
2.6	Appearance, Mounting Dimensions and Weight	15 -
2.7	External Dimensions of Control Panel	20 -
2.8	External Dimensions of Control Panel Bracket	20 -
Chapter 3	3 Installation and Wiring	21 -
3.1	Installation Environment	21 -
3.2	Minimum Mounting Clearances	21 -
3.3	Remove & Mount Control Panel and Cover	23 -
3.4	Configuration of Peripheral Devices	28 -
3.5	Terminal Configuration	34 -
3.6	Main Circuit Terminals and Wiring	31 -
3.7	Control Terminal Wiring	36 -

	3.8	Conf	rol Terminal Specification	-
	3.9	Cont	rol Terminal Usage 44	-
	3.10	Instr	uction of Signal Switches 53	-
	3.11	EMI	Solutions 54	-
Ch	apter 4	Oper	ation and Run Instructions 57	-
	4.1	Ope	ration of Control Panel 57	-
	4.2	First	-time Power up 73	-
Ch	apter 5	List c	of Parameters - 75	-
Ch	apter 6	Spec	ification of Parameters 129	-
	Group A	Sys	stem Parameters and Parameter Management 129	-
	Grou	p A0	System Parameters 129	-
	Grou	p A1	User-defined Display Parameters 133	-
	Group b	Ru	n Parameter Setting 135	-
	Grou	p b0	Frequency Reference 135	-
	Grou	p b1	Start/Stop Control 148	-
	Grou	p b2	Accel/Decel Parameters 154	-
	Group C	: Inp	out & Output Terminals 161	-
	Grou	p C0	Digital Input 161	-
	Grou	p C1	Digital Output 178	-
	Grou	p C2	Analog and Pulse Input 185	-
	Grou	р СЗ	Analog and Pulse Output 190	-
	Grou	p C4	Automatic Correction of Analog Input 195	-
	Group d	Moto	or and Control Parameters 196	-
	Grou	p d0	Parameters of Motor 1 196	-
	Grou	p d1	V/f Control Parameters of Motor 1202	_

Group d2	Vector Control Parameters of Motor 1	208 -					
Group d3	Parameters of Motor 2	215 -					
Group d4	V/f Control Parameters of Motor 2	217 -					
Group d5	Vector Control Parameters of Motor 2	218 -					
Group d6	Encoder Parameters	219 -					
Group E En	hanced Function and Protection Parameters	223 -					
Group E0	Enhanced Function	223 -					
Group E1	Protection Parameters	227 -					
Group F Ap	plication	231 -					
Group F0	Process PID	231 -					
Group F1	Multi-step Frequency	237 -					
Group F2	Simple PLC	240 -					
Group F3	Wobble Frequency and Fixed Length Count	249 -					
Group F4	Position Control	254 -					
Group H Com	munication Parameters	258 -					
Group H0	MODBUS Communication Parameters	258 -					
Group H1	Profibus-DP communication parameters	260 -					
Group L Keys	and Display of Control panel	260 -					
Group L0	Keys of Control panel	260 -					
Group L1	Control Panel Display Setting	261 -					
Group U Mon	itoring	264 -					
Group U0	Status Monitoring	264 -					
Group U1	History Fault	268 -					
Chapter 7 Troub	Chapter 7 Troubleshooting 270 -						
7.1 Faul	t Causes and Troubleshooting	- 270 -					

Chapt	ter 8 Maintenance	279 -
8.1	Routine Inspection	279 -
8.2	Regular Maintenance	280 -
8.3	Replacement of Vulnerable Parts	281 -
8.4	Storage	282 -
Apper	ndix Communication Protocol	284 -
1.	Networking Mode	284 -
2.	Interface Mode	284 -
3.	Communication Mode	284 -
4.	Protocol Format	285 -
5.	Protocol Function	287 -
6.	Operation Instructions	300 -
7.	LRC/CRC Generation	304 -

## **Chapter 1 Safety Precautions**

#### **Safety Precautions**

Safety signs in this manual:

**WARNING**: indicates the situation in which the failure to follow operating requirements may result in fire or serious personal injury or even death.

ATTENTION: indicates the situation in which the failure to follow operating requirements may cause moderate or slight injury and damage to equipment.

Users are requested to read this chapter carefully when installing, commissioning and repairing this product and perform the operation according to safety precautions as set forth in this chapter without violation. GTAKE bears no responsibility for any injury and loss as a result of any violation operation.

#### 1.1 Safety Considerations

#### 1.1.1 Prior to Installation

## /\wARNING

- Do not touch control terminals, circuit boards and any other electronic parts and components with bare hands.
- Do not use the drive whose component(s) is/are missing or damaged. Failure to comply
  may result in more faults and/or personal injury even death.

## **ATTENTION**

- Check if the product information indicated on the nameplate is consistent with the order requirements. If not, do not install it.
- Do not install the drive in the event that the packing list does not match with real
  equipment.

#### 1.1.2 Installation

## /k WARNING

 Only qualified personnel familiar with adjustable frequency AC drives and associated machinery should plan or implement the installation. Failure to comply may result in equipment damage and/or personnel injury even death.

- This equipment must be mounted on metal or other flame retardant objects. Failure to comply
  may result in fire.
- This equipment must be mounted in an area which is away from combustibles and heat sources. Failure to comply may result in fire.
- This equipment must in no case be mounted in the environment exposed to explosive gases.
   Failure to comply may result in explosion.
- Never adjust mounting bolts of this equipment, especially the ones with red markers. Failure to comply may result in equipment damage.

- Handle the equipment gently and take hold of its sole plate so as to avoid foot injury or equipment damage.
- Mount the equipment where its weight can be withstood. Failure to comply may result in equipment damage and/or personnel injury if falling happens.
- Make sure the installation environment conforms to the requirements as stated in Section 2.4. If not, de-rating is necessary. Failure to comply may result in equipment damage.
- Prevent drilling residues, wire ends and screws from falling into the equipment during installation. Failure to comply may result in faults or equipment damage.
- When mounted in a cabinet, this equipment should be provided with appropriate heat dissipation. Failure to comply may result in faults or equipment damage.

#### 1.1.3 Wiring

# MARNING

- Only qualified personnel familiar with adjustable frequency AC drives and associated machinery should plan or implement the wiring. Failure to comply may result in personnel injury and/or equipment damage.
- Wiring must strictly conform to this manual. Failure to comply may result in personnel injury and/or equipment damage.
- Make sure the input power supply has been completely disconnected before wiring.
   Failure to comply may result in personnel injury and/or equipment damage.
- All wiring operations must comply with EMC and safety regulations and/or electrical codes, and the conductor diameter should conform to recommendations of this manual.
   Failure to comply may result in personnel injury and/or equipment damage.
- Since overall leakage current of this equipment may be bigger than 3.5mA, for safety's sake, this equipment and its associated motor must be well grounded so as to avoid risk of electric shock.
- Be sure to implement wiring in strict accordance with the marks on this equipment's

- terminals. Never connect three-phase power supply to output terminals U/T1, V/T2 and W/T3. Failure to comply may result in equipment damage.
- Install braking resistors at terminals ⊕(⊕1/⊕2) and B2 (BR) only. Failure to comply
  may result in equipment damage.
- Wiring screws and bolts for main circuit terminals must be screwed tightly. Failure to comply may result in equipment damage.
- AC 220V signal is prohibited from connecting to other terminals than control terminals RA, RB, RC and TA, TB, TC. Failure to comply may result in equipment damage.

- Since all adjustable frequency AC drives from GTAKE have been subjected to hi-pot test before delivery, users are prohibited from implementing such a test on this equipment.
   Failure to comply may result in equipment damage.
- Signal wires should to the best of the possibility be away from main power lines. If this
  cannot be ensured, vertical cross-arrangement shall be implemented, otherwise
  interference noise to control signal may occur.
- If motor cables are longer than 100m, it is recommended output AC reactor be used.
   Failure to comply may result in faults.
- The coder must be provided with shielded cables whose shielded layer must be well grounded.

#### 1.1.4 Run

## /\sqrt{WARNING

- Drives which have been stored for more than 2 years should be used with voltage regulator to gradually boost the voltage when applying power to the drives. Failure to comply may result in equipment damage.
- Be sure to implement the wiring as per Section 3.4 before applying power to the drive.
   Failure to comply may result in equipment damage and/or electric shock hazard.
- Be sure to confirm the completion and correctness of the drive wiring and close the cover before applying power to the drive. Do not open the cover after applying power. Failure to comply may result in electric shock hazard.
- After applying the power, never touch the drive and peripheral circuits no matter what state the drive is under, otherwise there will be electric shock hazard.
- Prior to the running of the drive, check there is no person in surrounding area who can reach the motor so as to prevent personal injury.
- During the running of the drive, foreign bodies should be prevented dropping into the equipment. Failure to comply may result in faults and/or equipment damage.
- · Only qualified technicians familiar with adjustable frequency AC drives are allowed to

- perform signal test during operation. Failure to comply may result in equipment damage and/or personal injury.
- Never change the drive parameters at will. Failure to comply may result in equipment damage.

- Make sure the number of phases of power supply and rated voltage are consistent with product nameplate. If not, contact the seller or GTAKE.
- Check there are no short circuits in peripheral circuits connected with the drive, and make sure the connection is tight. Failure to comply may result in equipment damage.
- Make sure the motor and associated machinery are within allowable range of service prior to operation. Failure to comply may result in equipment damage.
- Never touch fans, heat sink and braking resistor with bare hands. Failure to comply may result in equipment damage and/or personal injury.
- It is not allowed to start & stop the driver frequently via direct switching power on or off.
   Failure to comply may result in equipment damage.
- Make sure the drive is in a non-output status before switch-on/switch-off of the drive output and/or contactor. Failure to comply may result in equipment damage.

#### 1.1.5 Maintenance

## **∕** WARNING

- Only qualified technicians are allowed to implement the maintenance, and troubleshooting.
- Never implement the maintenance, and troubleshooting before power supply has been turned off and discharged completely. Failure to comply may result in equipment damage and/or personal injury.
- To avoid an electric shock hazard, wait at least 10 minutes after the power has been turned off and make sure the residual voltage of the bus capacitors has discharged to 0V before performing any work on the drive.
- After the replacement of the drive, be sure to perform the same procedures in strict accordance with above-noted rules.

- Do not touch the electric components with bare hands during maintenance, and troubleshooting. Failure to do this may result in component damage due to ESD.
- All pluggable components can be inserted or pulled out only when power has been turned off.

#### 1.2 Other Considerations

#### 1.2.1 Input Power Supply

This series of drives are not applicable to applications out the range of operating voltage as set forth in this manual. If necessary, please use booster to rise or drop the voltage to regulated voltage range.

This series of drives support common DC bus input. Users are suggested to consult GTAKE technical personnel before use.

#### 1.2.2 Surge Protection

This series of drives are furnished with surge suppressor that has certain resistance to lightning induction. However, users in areas with frequent occurrence of lightning need to mount an external surge suppressor in front of the drive power input side.

#### 1.2.3 Operation of Contactor

As to the configuration of peripheral devices recommended by this manual, it is necessary to mount a contactor between the power supply and this drive input side. Such a contactor should not be used as a control device for start and stop of the drive, as frequent charging & discharging shall reduce the service life of internal electrolytic capacitors.

When it is necessary to mount a contactor between the drive output and the motor, it should be ensured the drive is in a non-output status before switch-on/switch-off of such a contactor. Failure to comply may result in drive damage.

### 1.2.4 Output Filter

Since the drive output is PWM high frequency chopping voltage, mounting filter devices such as an output filter and an output AC reactor between the motor and the drive shall effectively reduce output noise, avoiding interference to other surrounding equipments.

If the length of cable between the drive and the motor exceeds 100m, an output AC reactor is

recommended to use with the purpose of preventing drive fault as a result of overcurrent caused by excessive distributed capacitance. An output filter is optional depending on field requirements.

Be sure not to mount phase-shifting capacitor or surge absorber at output side of the drive since this may result in drive damage as a result of over-temperature.

#### 1.2.5 Insulation of the Motor

In view of the fact that the drive output is PWM high frequency chopping voltage accompanied by higher harmonics, the noise, temperature rise and vibration of the motor is higher compared with sinusoidal voltage. Particularly this debases motor insulation. Therefore, the motor should be subjected to insulation inspection before initial use or reuse after being stored for a long period of time. The motor in regular service should also be subjected to regular insulation inspection so as to avoid the drive damage as a result of motor insulation damage. A 500V voltage mode mega-ohmmeter is recommended to use for the measurement of the motor insulation, during which, it is essential to disconnect the motor from the drive. Normally, the insulation resistance of the motor should be bigger than  $5M\Omega$ .


#### 1.2.6 Derating

Due to the thin air in high-altitude areas, the radiating performance of the drive with forced air cooling may degrade while the electrolyte of electrolytic capacitors is more volatile, which can result in reduction in product life. Drive should be derated when used in an area at the altitude above 1000 meters. It is recommended to derate 1% for every 100m when the altitude is above 1000 meters.

## **Chapter 2 Product Information**

### 2.1 Model Explanation

Model shown on product nameplate indicates the series name, applicable type of power supply, power class and the version of software and hardware, etc. via the combination of numbers, symbols and letters.



#### 2.2 Nameplate Information



Fig. 2-2 Nameplate information

## 2.3 Information of Product Model

Table 2-1 Product model and technical data

■ GK820-4T□□□(B), three-phase 400V level

Model	Power Rating (kW)	Rated Output Current (A)	Rated Input current (A)	Applicable motor (kW)	Brake chopper	DC reactor
GK820-4T1.5B	1.5	3.8	5.0	1.5		
GK820-4T1.3B	2.2	5.5	6.0	2.2		
GK820-4T3.7B	3.7	9.0	10.5	3.7		
GK820-4T5.5B	5.5	13	14.6	5.5		
	7.5	_		7.5	Inbuilt	,
GK820-4T7.5B	-	17	20.5			/
GK820-4T11B	11	24	29	11		
GK820-4T15B	15	30	35	15		
GK820-4T18.5B	18.5	39	44	18.5		
GK820-4T22B	22	45	50	22		
GK820-4T30(B/D/H)*	30	60	65	30		Inbuilt
GK820-4T37(B/D/H)*	37	75	80	37	Inbuilt	optional
GK820-4T45(B)**	45	91	83	45	optional	Inbuilt
GK820-4T55(B)**	55	112	102	55	οριιστίαι	IIIDulit
GK820-4T75(B)****	75	150	157	75		/
GK820-4T90	90	176	160***	90		
GK820-4T110	110	210	192***	110		
GK820-4T132	132	253	232***	132		
GK820-4T160	160	310	285***	160		
GK820-4T185	185	350	326***	185		
GK820-4T200	200	380	354***	200		
GK820-4T220	220	430	403***	220		Externally
GK820-4T250	250	470	441***	250	Externally	mounted
GK820-4T280	280	520	489***	280	mounted	
GK820-4T315	315	590	571***	315		
GK820-4T355	355	650	624***	355		
GK820-4T400	400	725	699***	400		
GK820-4T450	450	820	790***	450		
GK820-4T500	500	860	835***	500		
GK820-4T560	560	950	920***	560		Inbuilt
GK820-4T630	630	1100	1050***	630		Hibuit

- \* means brake chopper and DC reactor are optionally inbuilt. Take 30kW for example: the model without brake chopper and DC reactor is GK820-4T30B, the model with DC reactor is GK820-4T30B, the model with DC reactor is GK820-4T30D, and the model with brake chopper and DC reactor is GK820-4T30H. Braking resistor needs to be mounted externally with reference to 3.4.3.
- \*\* means DC reactor is inbuilt, and brake chopper is optionally inbuilt. Take 45kW for example: the model with DC reactor is GK820-4T45, and the model with DC reactor and brake chopper is GK820-4T45(B). Braking resistor needs to be mounted externally with reference to 3.4.3
- \*\*\* means the rated input current configured a DC reactor. The drive GK820-4T90 GK820-4T500 is provided with an external-mounted DC reactor in shipment as default. Be sure to connect the DC reactor. Failure to comply may result in drive abnormal run. GK820-4T560 and GK820-4T630 are cabinet type, whose DC reactor and output AC reactor are inbuilt as default
- \*\*\*\* means for 75kW AC drive, model number is GK820-4T75 without inbuilt brake chopper, and model number is GK820-4T75B with inbuilt brake chopper

## 2.4 Technical Features of GK820


**Table 2-2 Technical features of GK820** 

	14210 2 2 100	illical leatures of GRozu
	Rated input voltage	200V level: single/three phase 200V~240V 400V level: three phase 380V~440V
	Frequency	50Hz/60Hz, tolerance ±5%
Power input		Continuous voltage fluctuation ±10%, short fluctuation -15%~+10%, i.e. 200V: 170V~264V; 400V: 323V~484V;
	Voltage range	1.e. 200V. 170V~204V, 400V. 323V~404V,
		Voltage out-of-balance rate <3%, distortion rate as per the requirements of IEC61800-2
	Rated input current	See Section 2.3
	Applicable motor (kW)	See Section 2.3
	Rated current (A)	See Section 2.3
Power output	Output voltage (V)	3-phase: 0~ rated input voltage, error < ±3%
	Output frequency (Hz)	0.00~ 600.00Hz; unit: 0.01Hz
	Overload capacity	150% - 1min; 180% - 10s; 200% - 0.5s
	V/f patterns	V/f control Sensor-less vector control 1 Sensor-less vector control 2 Closed-loop vector control (including position control)
	Range of speed regulation	1:100 (V/f control, sensor-less vector control 1) 1:200 (sensor-less vector control 2) 1:1000 (closed-loop vector control)
Control	Speed accuracy	±0.5% (V/f control) ±0.2% (sensor-less vector control 1 & 2) ±0.02% (closed-loop vector control)
characteristics	Speed fluctuation	±0.3% (sensor-less vector control 1 & 2) ±0.1% (closed-loop vector control)
	Torque response	< 10ms (sensor-less vector control 1 & 2) < 5ms (closed-loop vector control)
	Torque control	±7.5% (sensor-less vector control 2)
	accuracy	±5% (closed-loop vector control)
	Starting torque	0.5Hz:180% (V/f control, sensor-less vector control 1) 0.25Hz: 180% (sensor-less vector control 2) 0Hz: 200% (closed-loop vector control)

	Positioning accuracy	±1 line pulse
	Start frequency	0.00~ 600.00Hz
	Accel/ Decel time	0.00~60000s
	Switching frequency	0.7kHz~16kHz
	Frequency setting	Digital setting + control panel ^/v Digital setting + terminal UP/DOWN Communication Analog setting (AI1/AI2/AI3) Terminal pulse setting
	Motor start-up methods	Started from start frequency DC brake then started Flying start
	Motor stop methods	Ramp to stop Coast to stop Ramp to stop + DC brake
Basic functions	Dynamic braking capacity	Brake choppers for GK820-4T75 and below are inbuilt or can be inbuilt. See table 2-1 Brake chopper working voltage: 200V class: 325~375V; 400V class: 650V~750V Service time: 0.0~100.0s
	DC brake capacity	DC brake start frequency: 0.00~600.00Hz DC brake current: 0.0~200.0% DC brake time: 0.00~30.00s
	Input terminals	7 digital inputs, one of which can be used for high- speed pulse input. Compatible with active open collectors NPN, PNP and dry contact input. 3 analog inputs, one of which supports voltage input only, and the other two are voltage/current programmable.
	Output terminals	One high-speed pulse output terminal, 0~50kHz square signal; can output set frequency, output frequency and so forth One digital output terminal Two relay output terminals Two analog output terminals, voltage/current programmable; can output set frequency, output frequency and so forth
Encoder	Compatible with 5V/12	
signal terminal	·	nt types of encoder signal input, such as open collector,

	push-pull and differentia	al, etc.				
Featured functions	push-pull and differential, etc.  Parameter copy, parameter backup, common DC bus, free switchover between two motors' parameters, flexible parameter displayed & hidden, various master & auxiliary frequency reference and switchover, reliable speed search started, a variety of Accel/Decel curves programmable, automatic correction of analog, mechanical brake control, 16-step speed control programmable (2-step support flexible frequency reference), wobble frequency control, fixed length control, count function, three faults recorded, over excitation brake, over voltage stall protection programmable, under voltage stall protection programmable, restart upon power loss, skip frequency, frequency binding, four kinds of Accel/Decel time, motor thermal protection, flexible fan control, process PID control, simple PLC, multifunctional key programmable, droop control, asynchronous and synchronous motor tune, field-weakening control, high-precision torque control, V/f separated control, torque control at sensor-less vector control, torque control at closed-loop vector control, two encoder signal inputs (support incremental, UVW hybrid and resolver, etc.), flexible deceleration ratio control, pulse train position					
Protection functions	Refer to Chapter 7 - Troubleshooting					
	Place of operation	Indoors, no direct sunlight, free from dust, corrosive gases, flammable gases, oil mist, water vapor, water drop and salt, etc.				
	Altitude	0~2000m. De-rate 1% for every 100m when the altitude is above 1000 meters				
Environment	Ambient temperature	-10 °C ~40 °C . The rated output current should be derated 1% for every 1 °C when the ambient temperature is 40 °C ~50 °C				
	Relative humidity	5%~95%, no condensation				
	Vibration	Less than 5.9m/s2 (0.6g)				
	Storage temperature	-40°C~+70°C				
	Efficiency at rated Amps	7.5kW and below: ≥93% 11~ 45kW: ≥ 95% 55kW and above: ≥98%				
Others	Installation	560kW and 630kW are cabinet type, the others are wall-mounted				
	IP grade	IP20				
	Cooling method	nod Forced air cooling				


### 2.5 Parts Drawing



Middle casing
Middle casing


a) GK820-4T22B and below

b) GK820-4T30(B/D/H) GK820-4T37(B/D/H)




c) GK820-4T45(B)~ GK820-4T55(B)

### d) GK820-4T75(B)




e) GK820-4T90~ GK820-4T500




#### f) GK820-4T560 and GK820-4T630


Fig. 2-3 Parts drawing


## 2.6 Appearance, Mounting Dimensions and Weight







a) GK820-4T22B and below







## b) $GK820-4T30(B/D/H) \sim GK820-4T37(B/D/H)$







## c) $GK820-4T45(B) \sim GK820-4T55(B)$









e) GK820-4T90 ~ GK820-4T160



## f) GK820-4T185 ~ GK820-4T500





g) GK820-4T560 ~ GK820-4T630

Fig. 2-4 External dimensions

Table 2-3 Appearance, mounting dimensions and weight

	External and installation dimensions (mm)						Weight	
Model	W	(kg)	D	W1	H1	H2	Mounting hole dia.	(kg)
GK820-4T1.5B								
GK820-4T2.2B				80	233	220		
GK820-4T3.7B	120	245	169				5.5	2.9
GK820-4T5.5B								
GK820-4T7.5B								
GK820-4T11B	145	280	179	105	268	255	5.5	3.9
GK820-4T15B								
GK820-4T18.5B	190	365	187	120	353	335	6	6.2
GK820-4T22B								
GK820-4T30(B)				230		/	6.8	12
GK820-4T37(B)	250	400	235		380			
GK820-4T30D(H)			235	230	380	/	6.8	16.4
GK820-4T37D(H)	250	400						
GK820-4T45(B)	300	300 545		245	523	510	10	3
GK820-4T55(B)				243	323	310		S
GK820-4T75(B)	385	670	261	260	640	600	12	37
GK820-4T90	395	785	291	260	750	705	12	50
GK820-4T110	393	703	291	200	730	703	12	50
GK820-4T132	440	900	356	300	865	820	14	66
GK820-4T160	110					020		
GK820-4T185							14	
GK820-4T200	500	990	90 368	360	950	900		88
GK820-4T220								
GK820-4T250 GK820-4T280	650	1040	406	400	1000	950	14	123
GK820-4T315								
GK820-4T355	•							
GK820-4T400	815	1300	428	600	1252	1200	14	165
GK820-4T450			720		1202		'-	
GK820-4T500	1							
GK820-4T560	1100	2000	550	/	/	/	/	515
GK820-4T630	1100	2000	330	,	,	,	,	313

#### 2.7 External Dimensions of Control Panel

Control panel model of GK820 series high performance AC motor drive is KBU-BX1 whose appearance and external dimensions are shown in Fig. 2-5.





Fig. 2-5 External dimensions of KBU-BX1

#### 2.8 External Dimensions of Control Panel Bracket

A bracket should be provided to support the panel and a hole in the cabinet needs to be opened when the control panel KBU-BX1 needs to be remotely used. Bracket model is KBU-DZ1 whose external dimensions are shown in Fig. 2-6 a). Fig. 2-6 b) shows applicable hole dimensions in the cabinet.



a) External dimensions of KBU-DZ1

b) Hole dimensions in the cabinet

Fig. 2-6 External dimensions of KBU-DZ1 and cabinet hole dimensions


## **Chapter 3 Installation and Wiring**

#### 3.1 Installation Environment

- 1) Ambient temperature is in the range of -10  $^{\circ}$ C to 40  $^{\circ}$ C.
- Drive should be installed on surface of flame retardant object, with adequate surrounding space for heat dissipation.
- 3) Installation should be performed where vibration is less than 5.9m/s<sup>2</sup> (0.6g).
- 4) Protect from moisture and direct sunlight.
- 5) Protect the cooling fan by avoiding oil, dust and metal particles.
- 6) Do not expose to an atmosphere with flammable gases, corrosive gases, explosive gases or other harmful gases.
- 7) Prevent drilling residues, wire ends and screws falling into drive.
- 8) Ventilation part of the drive should be installed outside from harsh environment (e.g. textile facilities with fiber particles and chemical facilities filled with corrosive gases).

### 3.2 Minimum Mounting Clearances

To ensure favorable heat dissipation, mount the drive upright on a flat, vertical and level surface as per Fig. 3.1. For installation inside cabinet, the product shall be mounted side by side to the greatest extent while adequate surrounding space shall be preserved for favorable heat dissipation.






Fig. 3-1 Minimum mounting clearances of GK820-4T22B and below

Remove dust covers when mounting a drive GK820-4T22B or below. If several drives are mounted in one cabinet, parallel side-by-side mounting is recommended.




Fig. 3-2 Minimum mounting clearances of GK820-4T30(B/D/H)~ GK820-4T37(B/D/H)




Fig. 3-3 Minimum mounting clearances of GK820-4T45(B) and above

When mounting a drive GK820-4T30(B/D/H) or above, the minimum mounting clearances as set forth in Table 3-1 should be assured. In case several drives are mounted in one cabinet, parallel side-by-side mounting is recommended.

Table 3-1 Requirement of minimum mounting clearances

Drive model	Mounting clearances (mm)			
Drive model	А	В		
GK820-4T30(B/D/H) ~ GK820-4T37(B/D/H)	≥50	≥200		
GK820-4T45(B) ~ GK820-4T500G	≥50	≥300		

#### 3.3 Remove & Mount Control Panel and Cover

#### 3.3.1 Remove and Mount Control Panel

- Remove control panel
  - Press the buckle of control panel as indicated by number "1" in Fig. 3-4, then pull the panel out to release as indicated by "2".
- Mount control panel
  - Slightly slant the panel in the direction as indicated by number "1" in Fig. 3-5 and align it to clamping port at lower part of panel bracket, then press it in as indicated by "2". When a "click" sound heard, it indicates clamping has been properly made.





Fig. 3-4 Remove the control panel

Fig. 3-5 Mount the control panel

#### 3.3.2 Open & Mount the Covers of GK820-4T22B and below


#### Remove the control panel

Use the remove method as stated in Section 3.3.1.

#### Open the cover

**Method 1:** loosen the captive cover screws as shown in Fig. 3-6 a) (provided only for 15/18.5/22kW model), hold the left and front sides of middle housing with left hand, put the right thumb into the buckle and press tightly on cover with the other four fingers, pull the lower part of the cover out to release, as indicated by number "2".

**Method 2:** loosen the captive cover screws, as indicated by number "1" in Fig. 3-6 b) (provided only for 15/18.5/22kW model), use a sizeable slotted screwdriver to push the buckle slightly at the lower part of the cover to make buckle naturally off the groove, as indicated by "2", pull the cover out to release, as indicated by number "3".



a) Method 1



b) Method 2

Fig. 3-6 Open the cover

#### Mount the cover

On the completion of wiring, insert the buckle at higher part of the cover into the grooves at middle housing as indicated by number "1" in Fig. 3-7, then push in the lower part of the cover as indicated by "2". When a "click" sound heard, it indicates clamping has been properly made. Tighten the screws (provided only for 15/18.5/22kW model) in buckle grooves as finish.



Fig. 3-7 Mount the cover

#### Mount the control panel

Use the mounting method as stated in Section 3.3.1.

#### ATTENTION:

Be sure to remove the control panel before opening the cover and mount the cover before mounting the control panel.

## 3.3.3 Open & Mount the Covers of GK820-4T30(B/D/H)~ GK820-4T37(B/D/H)

#### Remove the control panel

Use the remove method as stated in Section 3.3.1.

#### Open cover

Use a sizeable slotted screwdriver to push the buckle(on both sides) slightly at the lower part of the cover to make buckle naturally off the groove, as indicated by "2" in Fig. 3-8, pull the cover out to release, as indicated by number "3"..



Fig. 3-8 Open cover

#### Mount cover

On the completion of wiring, insert the buckle at higher part of the cover into the grooves at middle housing as indicated by number "1" in Fig. 3-9, then push in the lower part of the cover as indicated by "2". When a "click" sound heard, it indicates clamping has been properly made, as cover mounting finish.



Fig. 3-9 Mount cover

#### Mount the control panel

Use the mounting method as stated in Section 3.3.1.

#### ATTENTION:

Be sure to remove the control panel before opening the cover and mount the cover before mounting the control panel.

### 3.3.4 Open & Mount the Covers of GK820-4T45(B) and above

#### Remove the control panel


Use the remove method as stated in Section 3.3.1.

#### Open the lower cover

Loosen the two captive cover screws at lower part of the lower cover by using cross screwdriver, as indicated by number "1" as shown in Fig. 3-10 (left), then pull the cover out and up as indicated by number "2".

#### Open the upper cover

Loosen the two captive cover screws at lower part of the lower cover by using cross screwdriver, as indicated by number "3" and "4" as shown in Fig. 3-10 (right), then pull the cover out and up as indicated by number "5".






Fig. 3-10 Open the lower and upper cover

#### Mount the upper cover

Insert the upper part of the cover into mounting groove as shown in Fig. 3-11 (left), close the upper cover, use cross screwdriver to tighten the four captive screws, as indicated by number "1" and "2".

#### Mount the lower cover

Insert the lower cover into upper cover in the direction as indicated by number 3 in Fig. 3-11 (right), close the lower cover and tighten the two captive screws, as indicated by number "4".




Fig. 3-11 Mount the upper and lower covers

#### Mount the control panel

Use the mounting method as stated in Section 3.3.1.

### **ATTENTION:**

Be sure to remove the control panel before opening the cover and mount the cover before mounting the control panel.

## 3.4 Configuration of Peripheral Devices

## 3.4.1 Standard Configuration of Peripheral Devices




Fig. 3-12 Standard configuration of peripheral devices

## 3.4.2 Instructions of Peripheral Devices

Table 3-2 Instructions of peripheral devices

Device	Instructions
Power supply	Input three-phase AC power supply should be in the range as specified in this manual
Circuit breaker	Purpose: disconnect power supply and protect the equipment in case of abnormal overcurrent occurs  Type selection: breaking current of circuit breaker is defined to be 1.5~2 times the rated current of the drive  Breaking time characteristic of circuit breaker should be selected based on overload protection time characteristic of the drive
RCD	Purpose: since the drive outputs PWM HF chopping voltage, HF leakage current is inevitable Type selection: type B dedicated RCD is recommended
Contactor	For safety's sake, do not frequently close and break the contactor since this may bring about equipment faults  Do not control the start & stop of the drive directly through switch on and off the contactor since this will result in a reduction on the product life
Input AC reactor or DC choke	Improve power factor Reduce the impact of imbalanced three-phase input AC power supply on the system Suppress higher harmonics and reduce the conducted and radiated interference to peripheral devices Restrict the impact of impulse current on rectifier bridges
Input filter	Reduce conducted interference from power supply to the drive, improve the immunity of the drive from noise Reduce conducted and radiated interference of the drive to peripheral devices
Brake chopper and braking resistor	Purpose: consume motor feedback energy to attain quick brake Type selection: Contact GTAKE technical personnel for type selection of brake chopper. Refer to type selection of braking resistor in Table 3-3 Selection of Peripheral Devices.
Output filter	Reduce conducted and radiated interference of the drive to peripheral devices
Output AC reactor	Avoid the motor insulation damage result from harmonic voltage Reduce frequent protection from the drive caused by leakage current In case the cable connecting drive and motor is over 100 meters, output AC reactor recommended
Motor	Should match the drive

### 3.4.3 Selection of Peripheral Devices

Table 3-3 Selection of peripheral devices

	Circuit breaker (A)	Contactor (A)	Braking resistor/Brake chopper *	
Drive model			Power (W)	Resistance (Ω)
GK820-4T1.5B	10	9	300	≥100
GK820-4T2.2B	10	9	400	≥100
GK820-4T3.7B	16	12	500	≥75
GK820-4T5.5B	20	18	550	≥50
GK820-4T7.5B	32	25	550	≥50
GK820-4T11B	40	32	800	≥25
GK820-4T15B	50	40	1100	≥23
GK820-4T18.5B	63	50	1300	≥16
GK820-4T22B	63	50	1500	≥16
GK820-4T30(B/D/H)	100	65	2500	≥15
GK820-4T37(B/D/H)	100	80	2800	≥15
GK820-4T45(B)	125	95	3000	≥10
GK820-4T55(B)	160	150	3600	≥10
GK820-4T75(B)	225	185	5000	≥5
GK820-4T90	250	225	Select based on brake chopper	
GK820-4T110	315	265		
GK820-4T132	350	330		
GK820-4T160	400	330		
GK820-4T185	500	400		
GK820-4T200	500	400		
GK820-4T220	630	500		
GK820-4T250	630	500		
GK820-4T280	800	630		
GK820-4T315	800	630		
GK820-4T355	1000	800		
GK820-4T400	1250	800		
GK820-4T450	1250	1000		
GK820-4T500	1600	1000		
GK820-4T560	1600	1250		
GK820-4T630	2000	1600		

<sup>\*</sup> When brake chopper is built in, the power and resistance value of brake resistor should meet the requirement as stated in the table. When brake chopper is mounted externally, the power and resistance value of brake resistor should be in accordance with brake chopper. The resistance value of the braking resistor in the table is the recommended minimum value (braking frequency 5%) when using the occasional braking load. The user can choose different resistance value and power according to the actual working conditions of the braking resistor. On the premise of fulfilling brake requirement, brake resistance value should be bigger than the minimum value as

stated in the table. Failure to comply may result in damage to the drive. Brake resistors are not built in and need to be procured additionally.


The long-term exposure of the braking resistor may cause conductive dust to accumulate, resulting in a short circuit of the resistor to ground. It is necessary to add a dust cover or place the resistor in the resistor box according to the actual situation.


## 3.4.4 External DC reactor installation and selection

## 3.4.4.1 Extermal DC reactor installation

GK820 series frequency inverter 90kW to 500kW is configured with external DC reactor as default, and will be shipped to customer with separate wooden case together with the frequency inverter. User must connect the DC reactor between 1 and  $\bigoplus$ ternima $\bigoplus$  and there is no polarity between the connection of reactor terminal and frequency inverter terminal. 560kW and 630kW are cabinet type, and are configured with internal DC reactor as default.

## 3.4.4.2 External DC reactor appearance and dimension








Fig. 3-13 external DC reactor appearance and dimension

Table 3-4 External DC reactor dimension

	Mounting dimension (mm)			Deseter						
Applicable model	А	В	С	D	Е	F	G	Mount hole	Copper bar hole	Reactor model
GK820-4T90	160	190	123	161	255	222	193	10X15	Ø12	MA4T903GL1
GK820-4T110	100	190	123	101	255	222	193	10715	Ø12	or BC-C00051D
GK820-4T132	100	100	400	101	٥٢٢	222	400	40745	Ø40	MA4T134GL1
GK820-4T160	160	190	123	161	255	222	193	10X15	Ø12	or BC-C00052D
GK820-4T185										MA4T184GL1
GK820-4T200	191	215	117	143	280	260	215	13X18	Ø14	or
GK820-4T220										BC-C00401A
GK820-4T250	190	230	93	128	325	300	200	13X18	Ø15	MA4T254GL1
GK820-4T280	190	230	93	120	323	300	200	13/10	Ø13	or BC-C00074D
GK820-4T315										
GK820-4T355										MA4T314GL1
GK820-4T400	224	250	132	165	335	312	235	12X20	Ø14	or
GK820-4T450										BC-C00127D
GK820-4T500										

## 3.5 Terminal Configuration




Fig. 3-14 Terminal configuration

## 3.6 Main Circuit Terminals and Wiring

# / WARNING


- Only qualified personnel familiar with AC motor drives are allowed to implement wiring.
   Failure to comply may result in equipment damage and/or personnel injury even death.
- Wiring should be in strict accordance with this manual, otherwise hazard of electric shock or equipment damage exists.
- Make sure input power supply has been completely disconnected before wiring operation. Failure to comply will result in personnel injury even death.
- All wiring operations and lines should comply with EMC and national and local industrial safety regulations and/or electrical codes. The conductor diameter should be in accordance with recommendations of this manual. Otherwise, hazard of equipment damage, fire, and/or personnel injury exists.
- Since leakage current of the drive may exceed 3.5mA, for safety's sake, the drive and the motor must be grounded so as to avoid hazard of electric shock.
- Be sure to perform wiring in strict accordance with the drive terminal marks. Never connect three-phase power supply to output terminals U/T1, V/T2 and W/T3. Failure to comply will result in equipment damage.
- Only mount braking resistors at terminals ⊕ (⊕ 1/⊕ 2) and B2 (BR) when needed.
   Failure to comply will result in equipment damage.
- Wiring screws and bolts for main circuit terminals must be screwed tightly. Failure to comply may result in faults and/or equipment damage.

# $\Lambda$

## **ATTENTION**

- Signal wires should be away from main power lines to the best of possibility. In the event
  that this cannot be ensured, vertical cross arrangement should be adopted, reducing
  EMI interference to the signal wires as much as possible.
- In case the motor cable exceeds 100m, an appropriate output reactor should be mounted.

## 3.6.1 Main Circuit Terminals of GK820-4T1.5B~GK820-4T22B



Terminal marks	Designation and function of terminals		
R/L1, S/L2, T/L3	Three-phase AC input terminals		
⊕2/B1, B2	Braking resistor connection terminals when brake unit is inbuilt*		
⊕1 , <sup>©</sup>	DC power supply input terminals**		
U/T1, V/T2, W/T3	Three-phase AC output terminals		
<b>(</b>	Ground terminal PE		

<sup>\*</sup> For GK820-4T11B, terminal 2/B1 is deleted, brake resistor connection terminals are and B2, for other model brake resistor connection, please refer to above table

# 3.6.2 Main Circuit Terminals of GK820-4T30(B/D/H)~ GK820-4T37(B/D/H)




Terminal marks	Designation and function of terminals		
R/L1, S/L2, T/L3	Three-phase AC input terminals		
BR, ⊕	Braking resistor connection terminals when brake unit is inbuilt*		
⊕, ⊖	DC power supply input terminals		
U/T1, V/T2, W/T3	Three-phase AC output terminals		
4	Ground terminal PE		

<sup>\*\*</sup> For GK820-4T5.5B and GK820-4T7.5B, DC power supply input terminals are ⊕ 2/B1 and ⊖, for other model DC input connection, please refer to above table. For 1.5kW-3.7kW and 15kW, ⊕ 1, ⊕ 2/B1 has been shorted with copper bar; for 18.5kW and 22kW, ⊕ 1 and ⊕ 2/B1 has been shorted internally.

\* For 30kW $\sim$ 37kW drives without "B" or "H" in the model number, there is no built-in brake unit as factory default,

brake resistor connected between BR and  $\oplus$  terminals is invalid.


# 3.6.3 Main Circuit Terminals of GK820-4T45(B)~GK820-4T55(B)



Terminal marks	Designation and function of terminals		
R/L1, S/L2, T/L3	Three-phase AC input terminals		
⊕ ,BR	Braking resistor connection terminals when brake unit is inbuilt*		
⊕, ⊖	DC power supply input terminals		
U/T1, V/T2, W/T3	Three-phase AC output terminals		
<b>(</b>	Ground terminal PE		

<sup>\*</sup> For 45kW∼55kW drives without "H" in the model number, there is no built-in brake unit as factory default, brake resistor connected between BR and ⊕ terminals is invalid.


# 3.6.4 Main Circuit Terminals of GK820-4T75(B)



Terminal marks	Designation and function of terminals
R/L1、S/L2、T/L3	Three-phase AC input terminals
⊕1,⊕2/B1 DC reactor connection terminals. Connected with a jumper	
0 1 1 0 2/2 1	factory default *
⊕2/B1、B2	Braking resistor connection terminals when brake unit is inbuilt*
⊕2/B1、⊖	DC input terminals of external- mounted brake unit
⊕1、⊖	DC power supply input terminals
U/T1、V/T2、W/T3	Three-phase AC output terminals
<b>(</b>	Ground terminal PE

\* For 75kW drives without "B" in the model number, there is no built-in brake unit as factory default, brake resistor connected between B1 and B2 terminals is invalid.

## 3.6.5 Main Circuit Terminals of GK820-4T90 ~ GK820-4T500



Terminal marks	Designation and function of terminal
R/L1、S/L2、T/L3	Three-phase AC input terminals
⊕1, ⊕2	DC reactor connection terminals *
⊕2, ⊙	DC input terminals of external- mounted brake unit
⊕1, ⊙	DC power supply input terminals
U/T1, V/T2, W/T3	Three-phase AC output terminals
	Ground terminal PE

<sup>\*</sup> GK820-4T90~GK820-4T500 have external-mounted DC reactor in shipment as default. Be sure to connect the DC reactor between terminals ⊕1 and ⊕2, or there will be no display when applying power on the drives.

## 3.6.6 Main Circuit Terminals of GK820-4T560 ~ GK820-4T630

Terminals are copper bar for GK820-4T560 ~ GK820-4T630 as following:















Terminal marks	Designation and function of terminals	
R/L1, S/L2, T/L3	Three-phase AC input terminals	
U/T1, V/T2, W/T3	Three-phase AC output terminals	
<b>(</b>	Ground terminal PE	

# 3.6.7 Terminal Screw and Wiring Requirement

Table 3-5 Terminal screw and wiring requirement

Power terminal				Ground terminal			
Drive model	Cable (mm2)	Screw	Torque (kgf.cm)	Cable (mm2)	Screw	Torque (kgf.cm)	
GK820-4T1.5B	2.5	M4	14±0.5	2.5	M4	14±0.5	
GK820-4T2.2B	2.5	M4	14±0.5	2.5	M4	14±0.5	
GK820-4T3.7B	2.5	M4	14±0.5	2.5	M4	14±0.5	
GK820-4T5.5B	2.5	M4	14±0.5	2.5	M4	14±0.5	
GK820-4T7.5B	4	M4	14±0.5	4	M4	14±0.5	
GK820-4T11B	4	M4	14±0.5	4	M4	14±0.5	
GK820-4T15B	6	M5	28±0.5	6	M4	14±0.5	
GK820-4T18.5B	10	M5	28±0.5	10	M4	14±0.5	
GK820-4T22B	10	M5	28±0.5	10	M4	14±0.5	
GK820-4T30(B/D/H)	16	M6	48±0.5	16	M6	48±0.5	
GK820-4T37(B/D/H)	25	M6	48±0.5	16	M6	48±0.5	
GK820-4T45(B)	35	M8	120±0.5	16	M8	120±0.5	
GK820-4T55(B)	50	M8	120±0.5	25	M8	120±0.5	
GK820-4T75(B)	70	M10	250±0.5	35	M8	120±0.5	
GK820-4T90	95	M12	440±0.5	50	M12	440±0.5	
GK820-4T110	120	M12	440±0.5	70	M12	440±0.5	
GK820-4T132	120	M12	440±0.5	70	M12	440±0.5	
GK820-4T160	150	M12	440±0.5	95	M12	440±0.5	
GK820-4T185	185	M12	440±0.5	95	M12	440±0.5	
GK820-4T200	185	M12	440±0.5	95	M12	440±0.5	
GK820-4T220	240	M12	440±0.5	120	M12	440±0.5	
GK820-4T250	120×2	M16	690±0.5	120	M16	690±0.5	
GK820-4T280	120×2	M16	690±0.5	120	M16	690±0.5	
GK820-4T315	150×2	M16	690±0.5	150	M16	690±0.5	
GK820-4T355	185×2	M16	690±0.5	95×2	M16	690±0.5	
GK820-4T400	240×2	M16	690±0.5	120×2	M16	690±0.5	
GK820-4T450	240×2	M16	690±0.5	120×2	M16	690±0.5	
GK820-4T500	240×2	M16	690±0.5	120×2	M16	690±0.5	
GK820-4T560	300×2	M16	690±0.5	150×2	M16	690±0.5	
GK820-4T630	300×2	M16	690±0.5	150×2	M16	690±0.5	

#### 3.7 **Control Terminal Wiring**



# **WARNING**

- Only qualified personnel familiar with AC motor drives are allowed to implement wiring. Failure to comply may result in equipment damage and/or personnel injury even death.
- Wiring should be in strict accordance with this manual, otherwise hazard of electric shock or equipment damage exists.
- Make sure input power supply has been completely disconnected before wiring operation. Failure to comply will result in personnel injury even death.
- All wiring operations and lines should comply with EMC and national and local industrial safety regulations and/or electrical codes. The conductor diameter should be in accordance with recommendations of this manual. Otherwise, hazard of equipment damage, fire, and/or personnel injury exists.
- Screws or bolts for terminal wiring must be screwed tightly.
- AC 220V signal is prohibited from connecting to other terminals than control terminals RA, RB, RC and TA, TB, TC.



# 1 ATTENTION

- Signal wires should to the best of possibility be away from main power lines. If this cannot be ensured, vertical cross arrangement should be adopted, reducing EMI interference to the signal wires as much as possible.
- Coder must be provided with shielded cables whose shielded layer must be properly arounded.

## 3.7.1 Control Board Diagram




Fig. 3-15 Control board diagram

## 3.7.2 Wiring Diagram




Fig. 3-16 Wiring diagram

# 3.8 Control Terminal Specification

**Table 3-6 Control terminal specification** 

Category	Terminal	Terminal designation	Specification			
		Analog input	10.3V ±3%			
	voltage		Maximum output current 25mA The resistance of external potentiometer should be larger than $400\Omega$			
	GND	Analog ground	Isolated from COM interiorly			
	Al1	Analog input 1	0~20mA: input impedance - 500Ω, maximum input current - 25mA 0~10V: input impedance - 22kΩ, maximum input voltage - 12.5V Switch S2 on control board for jumping between 0~20mA and 0~10V, factory default: 0~10V			
Analog input			0~20mA: input impedance: 500Ω, maximum			
	410	Analog input 2	input current: 25mA  0~10V: input impedance: 22kΩ, maximum input voltage: 12.5V			
	Al2		Switch S3 on control board for jumping between 0~20mA and 0~10V, factory default: 0~10V			
			Jumper switch S4 can realize analog input of direct detection of motor temperature			
			-10V~10V: input impedance: 25kΩ			
	Al3 Analog input 3		Maximum range of input voltage: - 12.5V~+12.5V			
			0~20mA: impedance: 200Ω~500Ω			
			0~10V: impedance ≥ 10k			
	AO1 Analog output 1	Switch S5 on control board for jumping between 0~20mA and 0~10V, factory default: 0~10V				
Analog output			0~20mA: impedance: 200Ω~500Ω			
Juipui			0~10V: impedance: ≥10kΩ			
	AO2 Analog output 2		Switch S6 on control board for jumping between 0~20mA and 0~10V, factory default: 0~10V			
	GND	Analog ground	Isolated from COM interiorly			

Category	Terminal	Terminal	Specification			
		designation				
	24)/	0.01	24V±10%, Isolated from GND interiorly			
	+24V	+24V	Maximum load: 200mA			
	PLC	Digital input Common terminal	Used for switching between high and lo levels, short-circuited with +24V when deliver i.e. low value of digital input valid			
District		torriiriai	External power input			
Digital input	COM	+24V ground	Isolated from GND interiorly			
		Digital input	Input: 24VDC, 5mA			
	X1~X6	Terminals 1~6	Range of frequency: 0~200Hz			
			Range of voltage: 10V~30V			
		Digital	Digital input: same as X1~X6			
	X7/DI	input/pulse input	Pulse input: 0.1Hz~50kHz; range of voltage: 10-30V			
	Y1	Open collector	Range of voltage: 0~24V			
Digital	11	output	Range of current: 0~50mA			
output Y2/DO	Open collector output /	Open collector output: same as Y1				
	Pulse o		Pulse output: 0~50kHz;			
<b>D</b>			RA-RB: NC			
Relay 1 output	RA/RB/RC	Relay output	RA-RC: NO			
σαιραι			Contact capacity: 250VAC/3A, 30VDC/3A			
			TA-TB: NC			
Relay 2 output	TA/TB/TC	Relay output	TA-TC: NO			
σαιραι			Contact capacity: 250VAC/3A, 30VDC/3A			
	VCC	Encoder power supply	Select power supply 5V/12V for encoder by S7			
Encoder	СОМ	Encoder power ground	Isolated from GND interiorly			
signal input	A+	Phase input A+	Select differential/OC input mode by S7. In OC mode, this terminal is not connected			
	A-	Phase input A-	Select differential/OC input mode by S7. In OC mode, this terminal is directly connected to phase A signal of the encoder			
	B+ Phase input B+		Select differential/OC input mode by S7. In OC mode, this terminal is not connected			

Category	Terminal	Terminal	Specification
		designation	
Encoder signal input	B-	Phase input B-	Select differential/OC input mode by S7 In OC mode, this terminal is directly connected to phase B signal of the encoder
	485+	Differential signal 485+	Rate: 4800/9600/19200/38400/57600/115200bps
Terminal 485	485-	Differential signal 485-	Maximum distance: 500m (use standard network cable)
Interface	GND	485 Communication shielded ground	Isolated from COM interiorly
Control panel 485 interface	CN4	Control panel 485 interface	Use standard network cable Maximum cable distance: 15m

When 485 communication interface is used, GND terminal must be reliably connected to 485 communication power supply ground of host computer. Failure to comply may result in damage of system 485 communication circuit.

# 3.9 Control Terminal Usage

## 3.9.1 Lay-out of Control Terminals




Fig. 3-17 Lay-out of control terminals

## 3.9.2 Control Terminal Screw and Wiring Requirement

Table 3-7 Terminal screw and wiring specification

Cable type	Cable requirement (mm²)	Screw	Torque (kgf.cm)
Shielded cable	1.0	М3	5±0.5

# 3.9.3 Instructions of Analog Input/Output Terminals

Being particularly vulnerable to noise, analog input & output signals cables should be as short as possible, shielded, and their shielded layers should be properly grounded, close to the side of drive. The cables should not exceed 20m.

Control cables shall be kept no less than 20cm away from main circuit and strong current lines (e.g. power lines, motor lines, relay lines and contactor lines) and should not be arranged in parallel with strong current lines. In case it is inevitable to intersect strong current line, vertical wiring is recommended so as to avoid drive faults as the result of noise.

Where analog input & output signals are severely interfered, the side of analog signal source should be provided with filter capacitor or ferrite core.

## 3.9.4 Instructions of Digital Input/Output Terminals

Digital input & output signals cables should be as short as possible, shielded, and their shielded layers should be properly grounded close to the side of drive. The cables should not exceed 20m. When active drive is selected, take necessary filtering measures against power crosstalk, for which dry contact control is recommended.

Control cables shall be kept no less than 20cm away from main circuit and strong current lines (e.g. power lines, motor lines, relay lines and contactor lines) and should not be arranged in parallel with strong current lines. In case it is inevitable to intersect strong current line, vertical wiring is recommended to avoid drive faults as a result of noise. Operating instructions for switching value input terminal

## Instructions of digital input terminal

#### Dry contact




Fig. 3-18 Internal power supply dry contact




Fig. 3-19 External power supply dry contact

When external power supply is used, the jumper between +24V and PLC must be removed. Otherwise, it may result in equipment damage.

The voltage range of external power supply should be DC20~30V. Otherwise, normal operation could not be assured and/or result in equipment damage.

# Open collector NPN connection




Fig. 3-20 External power supply open collector NPN connection




Fig. 3-21 External power supply open collector NPN connection

When external power supply is utilized, the jumper between +24V and PLC must be removed. The voltage range of external power supply should be DC20~30V, otherwise normal operation could not be assured and/or hazard of equipment damage exists.

## Open collector PNP connection




Fig. 3-22 Internal power supply open collector PNP connection

When PNP connection is adopted, it is necessary to remove the jumper between +24V and PLC, and connect the jumper to PLC and COM.




Fig. 3-23 External power supply open collector PNP connection


## **ATTENTION:**

When external power supply is used, the jumper between +24V and PLC must be removed. The voltage range of external power supply should be DC20~30V. Otherwise, normal operation could not be assured and/or hazard of equipment damage exists.

## Instructions of digital output terminal

a) Internal power supply


#### ♦ Instructions of Y1 and Y2/DO output terminals



b) External power supply

Fig. 3-24 Wiring when Y1 and Y2/DO output with pull-up resistors

When set to be pulse output, Y2/DO terminal shall output 0~50kHz pulse signal.



a) Internal power supply

b) External power supply

Fig. 3-25 Wiring diagram when Y1 and Y2/DO drive relay

# **ATTENTION:**

When relay coil voltage is lower than 24V, a resistor as voltage divider should be mounted between relay and output terminal, based on coil impedance.

## Wiring instruction of relay output terminal

Control boards of GK820 series drives are provided with two programmable relay dry contact outputs. One relay contacts are RA/RB/RC, whose RA and RB are normally closed while RA and RC are normally open. See parameter C1-02 for details. The other's contacts are TA/TB/TC, whose TA and TB are normally closed while TA and TC are normally open. See parameter C1-03 for details.

# ATTENTION:

In case inductive load (e.g. electromagnetic relay or contactor) is to be driven, a surge voltage absorbing circuit such as RC absorbing circuit (note that its leakage current shall be less than holding current of controlled contactor or relay), piezo-resistor or fly-wheel diode etc. shall be mounted (be sure to pay close attention to polarity in case of DC electromagnetic circuit). Absorbing devices should be mounted close to the ends of relay or contactor.

#### 3.9.5 Instructions of Encoder Terminal

GK820 series drives without the optional boards also support the following three types of encoders.

# Type of open collector output

Select the first position of toggle switch from the left according to the power supply of selected encoder. Slide up for 12V power supply, and slide down for 5V power supply. The #2 and #3 positions from the left are for selection of signal type. Slide up for open collector output, as shown in Fig. 3-25.




Fig. 3-26 S7 operation when using encoder of open collector output type

Fig. 3-26 shows the wiring of encoder of open collector output type. Positive pole of encoder power supply is connected to VCC, negative pole to COM. Phase A signal is connected to drive A-, while phase B signal to drive B-. Drive terminals A+ and B+ are internally pulled up to VCC, not connected externally.




Fig. 3-27 Wiring of encoder of open collector output type

## ◆ Type of push-pull output

Select the first position of toggle switch from the left according to the power supply of selected encoder. Slide up for 12V power supply, and slide down for 5V power supply. The #2 and #3 positions from the left are for selection of signal type. Slide up for push-pull output, as shown in Fig. 3-27.



Fig. 3-28 S7 operation when using encoder of push-pull output type

Fig. 3-28 shows the wiring of encoder of push-pull output type. Positive pole of encoder power supply is connected to VCC, negative pole to COM. Phase A signal is connected to drive A-, while phase B signal to drive B-. Drive terminals A+ and B+ are internally pulled up to VCC, not connected externally.




Fig. 3-29 Wiring of encoder of push-pull output type

## Differential output type

Select the first position of toggle switch from the left according to the power supply of selected encoder. Slide up for 12V power supply, and slide down for 5V power supply. The #2 and #3 positions from the left are for selection of signal type. Slide up for differential output, as shown in Fig. 3-29.



Fig. 3-30 S7 operation when using encoder of differential output type

Fig. 3-30 shows wiring of encoder of differential output type. Positive pole of encoder power supply is connected to VCC, negative pole to COM. Encoder A+, A-, B+ and B- are connected to drive A+, A-, B+ and B- respectively.




Fig. 3-31 Wiring of encoder of differential output type

#### 3.9.6 Instructions of RS485 Communication Terminals

It is recommended to apply chain connection as Fig. 3-31 ("one-to-many" star connection cannot be applied) between RS485 communication nodes of the drive and host computer etc. Try to lay 485 communication cables away from power cables and machine cabinets.

There should be at least three cables as RS485 communication bus: two paired cables which can effectively resist outside noise interference is used to connect 485 signal terminal; the third cable (also called equipotential cable) is used to connect power supply reference of communication circuit of each 485 node, thus to prevent communication circuit of each node from being damaged due to big difference of reference potential. To ensure communication bus away from noise current loop, equipotential cable cannot be connected to ground or machine cabinet.

For normal industrial application, generally paired shielded cables are selected as 485 communication bus; the shielded layer can work as equipotential cable, and shall be kept as intact as possible during cable layout. Multi-cored paired cables (e.g. Ethernet cable) can also be selected to connect each 485 node; select one pair of paired cables to connect 485 signal terminals, and wrest other cables together as equipotential connection. For handmade paired cables, the conducting section area of wire shall be  $\geq 0.2$ mm², twisted space shall be  $\leq 15$ mm, conducting section area of equipotential wire shall be  $\geq 1$ mm², and be closely laid to paired cable.




Fig. 3-32 Wiring diagram of RS485 communication terminal

There may be no lead-out terminals of communication power supply reference for some 485 nodes, then try to find reference ground of 485 communication circuit on board related to the node, lead out wire for equipotential connection (simply connecting them to ground or other irrelevant terminals is not allowed). If reference ground of 485 communication circuit cannot be found, then hang equipotential wire of the node in air, meanwhile connect ground of the 485 node and ground of neighbor 485 node with other grounding wire.

Connect a terminal resistor on end node of 485 communication bus according to requirement. On one aspect, if high-frequency characteristic impedance determined by paired cable structure is close to the terminal resistor value, communication signal quality will be promoted by connecting a terminal resistor; on another aspect, communication loop load will be increased, and voltage amplitude of signal will be decreased if a terminal resistor is connected.

## 3.10 Instruction of Signal Switches




Fig. 3-33 Jumper diagram of signal switch

Designation	Function	Default setting
S1	Selection of 485 termination resistor; ON :100Ω termination resistor provided; OFF: no termination resistor	OFF
S2	Type selection of Al1 analog signal: I: current input (0~20mA); V: voltage input (0~10V)	V: 0~10V
S3	Type selection of Al2 analog signal: I: current output (0~20mA); V: voltage output (0~10V)	V: 0~10V
S4	Input mode selection of Al2:  NOR: normal analog signal input, determined by S3;  TMP: motor thermal detector input, S3 must be selected as  "V"	NOR: normal mode
S5	Type selection of AO1 analog signal: I: current output (0~20mA); V: voltage output (0~10V)	V: 0~10V
S6	Type selection of AO2 analog signal: I: current output (0~20mA); V: voltage output (0~10V)	V: 0~10V

When Al2 is selected as motor thermal detector input mode (S4 is selected as TMP), which supports PTC130, PTC150 and KTY84, etc. types of thermal detector, S3 should be selected as "V". Refer to d0-23, d0-25 and d0-26 (or d3-23, d3-25 and d3-26) for corresponding parameters setting. Please seek for service about how to calculate the value of d0-26 or d3-26 before using this function.

## 3.11 EMI Solutions

Due to its working principle, the drive will inevitably produce certain noise that may influence and disturb other equipment. Moreover, since the internal weak electric signal of drive is also susceptible to the interference of drive itself and other equipment, EMI problems shall be inevitable. In order to reduce or avoid the interference of drive to external environment and protect drive against interference from external environment, this section makes a brief description of noise abatement, ground handling, leakage current suppression and the application of power line filters.

#### 3.11.1 Noise Abatement

- When peripheral equipment and drive share the power supply of one system, noise from
  drive may be transmitted to other equipment in this system via power lines and result in
  misoperation and/or faults. In such a case, the following measures could be taken:
  - 1) Mount input noise filter at input terminal of the drive;
  - Mount power supply filter at power input terminal of affected equipment;
  - Use isolation transformer to isolate the noise transmission path between other equipment and the drive.
- As the wiring of peripheral equipment and drive constitutes a circuit, the unavoidable earthing leakage current of inverter will cause equipment misoperation and/or faults.
   Disconnect the grounding connection of equipment may avoid this misoperation and/or faults.
- Sensitive equipment and signal lines shall be mounted as far away from drive as possible.
- Signal lines should be provided with shielded layer and reliably grounded. Alternatively, signal cable could be put into metallic conduits between which the distance shall be no less than 20cm, and shall be kept as far away from drive and its peripheral devices and cables as possible. Never make signal lines in parallel with power lines or bundle them.
- Signal lines must orthogonally cross power lines if this cross inevitable. Motor cables shall
  be placed in thick protective screen like more than 2mm-thick pipelines or buried cement
  groove, also, power lines can be put into metallic conduit and grounded well with shielded
  cables.
- Use 4-core motor cables of which one is grounded at close side of the drive and the other side is connected to motor enclosure. Input and output terminals of drive are respectively equipped with radio noise filter and linear noise filter. For example, ferrite common mode choke can restrain radiation noise of power lines.

## 3.11.2 Grounding

Recommended ground electrode is shown in the figure below:




Fig. 3-34 Grounding

- Use to the fullest extent the maximum standard size of grounding cables to reduce the impedance of grounding system.
- Grounding wires should be as short as possible. Grounding point shall be as close to the
  drive as possible.
- One wire of 4-core motor cables shall be grounded at the drive side and connected to grounding terminal of motor at the other side. Better effect will be achieved if motor and drive are provided with dedicated ground electrodes.
- When grounding terminals of various parts of system are linked together, leakage current

turns into a noise source that may influence other equipment in the system, thus, grounding terminals of the drive and other vulnerable equipment should be separated. Grounding cable shall be kept away from inlet & output of noise-sensitive equipment.

## 3.11.3 Leakage Current Suppression

- Leakage current passes through the line-to-line and ground distributed capacitors at input & output sides of drive, and its size is associated with the capacitance of distributed capacitor and the switching frequency. Leakage current is classified into ground leakage current and line-to-line leakage current.
- Ground leakage current not only circulates inside drive system, but may also influence other equipment via ground loop. Such a leakage current may result in malfunction of RCD and other equipment. The higher the switching frequency of drive is, the bigger the ground leakage current would be. The longer the motor cables and the bigger the parasitic capacitance are, the bigger the ground leakage current would be. Therefore, the most immediate and effective method for suppression of ground leakage current is to reduce switching frequency and minimize the length of motor cables.
- The higher harmonics of line-to-line leakage current that passes through between cables at output side of drive will Accel the aging of cables and may bring about malfunction of other equipment. The higher the switching frequency of drive is, the bigger the line-to-line leakage current would be. The longer the motor cables and the bigger the parasitic capacitance are, the bigger the line-to-line leakage current would be. Therefore, the most immediate and effective method for suppression of ground leakage current is to reduce switching frequency and minimize the length of motor cable. Line-to-line leakage current can also be effectively suppressed by mounting additional output reactors.

# 3.11.4 Use of Power Supply Filter

Since AC drives may generate strong interference and are also sensitive to outside interference, power supply filters are recommended. Pay close attention to the following instructions during the use:

- Enclosure of the filter needs to be reliably grounded;
- Input lines of the filter shall be kept as far away from output lines as possible so as to avoid mutual coupling;
- Filter shall be as close to the drive side as possible;
- Filter and drive must be connected to the same common ground.

# **Chapter 4 Operation and Run Instructions**

# 4.1 Operation of Control Panel

As a human-machine interface, control panel is the main part for the drive to receive command and display parameters.



Fig. 4-1 Control Panel

# 4.1.1 Key Functions on Control Panel

On control panel there are 8 keys whose functions are as shown in Table 4-1.

Symbol Key name Meaning

Symbol	Key name	Meaning				
ENT	Enter key	Parameter edition enter     Confirmation of parameter settings     Confirmation of MF key function				
ESC	Escape key	Return function     Invalid parameter edit value				
_	Increase key	Increase of selected bit of function code     Increase of selected bit of parameter     Increase of set frequency				
	Decrease key	Decrease of selected bit of function code     Decrease of selected bit of parameter value     Decrease of set frequency				
<b>&gt;&gt;</b>	Shift key	Selection of parameter bit     Selection of parameter bit     Selection of stop/run status display parameter value     Fault status switches to parameter display status				
RUN	Run key	Run				

Symbol	Key name	Meaning
RESET	Stop/reset key	1) Stop 2) Fault reset
MF	Multi-function key	See Table 4-2 " MF key function definition"

# Table 4-2 MF key function definition

L0-00 set value	Function of MF key	Meaning			
0	Disabled	MF key disabled			
1	Forward JOG	Forward JOG function			
2	Reverse JOG	Reverse JOG function			
3	Forward/Reverse switch	Run direction forward and reverse switching			
4	Emergency STOP 1	Press to STOP, with ramp-down time b2-09			
5	Emergency STOP 2	Coast to stop, the drive cuts off output			
6	Run command setting mode switch	Control panel control -> Terminal control -> Communication control -> Control panel control, press to confirm within 5 seconds			

## 4.1.2 Control Panel Indicators

Control panel is furnished with 7 indicators whose descriptions are as below

**Table 4-3 Description of indicators** 

Indicator	Designation	Meaning				
Hz	Frequency indicator	ON: currently displayed parameter value is running frequency or the current parameter unit is frequency Flash: currently displayed parameter value is set frequency				
А	Current indicator	ON: currently displayed parameter value is current				
V	Voltage indicator	ON: currently displayed parameter value is voltage				
Hz+A	Running speed indicator	ON: currently displayed parameter value is running speed Flash: currently displayed parameter value is setting speed				
A+V	Percentage indicator	ON: currently displayed parameter value is a percentage value				
All OFF	No unit	No unit				
MON	Run command setting mode indicator	ON: Control panel OFF: Terminal Flash: Communication				
RUN	Run status indicator	ON: Run OFF: Stop Flash: Stopping				
FWD	Forward indicator	ON: If the drive in stop status, forward command enabled. If the drive in run status, the drive is running forward Flash: Forward is being transferred to reverse				
REV	Reverse indicator	ON: If the drive in stop status, reverse command enabled. If the drive in run status, the drive is running reversely. Flash: Reverse is being transferred to forward				

## 4.1.3 Control Panel Display Status

Control panel indicates eight types of status, STOP parameters display, RUN parameters display, Fault display, parameter number edition, parameter setting, Password authentication, Direct frequency modification and Prompt message. The operation relating to these statuses and the switching among these statuses is described as follows.

## 4.1.3.1 Display of STOP Parameters

The drive normally gets into STOP parameters display once run has been stopped. By default, set frequency is displayed in such a status, and other parameters can be displayed through setting of L1-02 parameters and the key. For example, when users need to check set frequency as well as the values of bus voltage and Al1 value in stop status, make L1-02=0013 (refer to setting method of parameters) and press the key to display the value of bus voltage and then press again to display the value of Al1.



Fig. 4-2 Stop parameter display status (Displaying setting frequency – 50.00Hz)

Run status would be enabled immediately upon the receipt of run command in stop status. Press to get into parameter edit status (get into password authentication status if parameter under password protection). Directly get into frequency modification status when receive UP/DOWN command from terminal, or and pressing on Control panel. Switch to fault display status once a fault occurs or an alarm is given.

# 4.1.3.2 Run Parameters Display Status

In case there is no fault, the drive will get into run parameters display status upon receipt of run command. Default display is run frequency, and other parameters can be displayed through setting of L1-00 and L1-01 and press to shift. For example, in run status, when users need to check bus voltage, motor speed, and input terminals status, please set L1-00= 0084 and L1-01= 0004, and press to shift to the display of bus voltage, then press again to display motor speed, and then press to display input terminals state value.



Fig. 4-3 Run parameter display status (Displaying run frequency – 50.00Hz)

Stop status will be enabled immediately upon receipt of stop command in such a status. Press to get into parameter edit status (get into password authentication status if parameter under password protection). Directly get into frequency modification status when receiving UP/DOWN command from terminal, or pressing or Switch to fault alarm display status once a fault occurs or an alarm is given.

# 4.1.3.3 Fault Alarm Display Status

In case a fault occurs or an alarm is given, the drive will get into fault or alarm display status.



Fig. 4-4 Fault or alarm display status (CCL: Contactor act fault)

In such a status, the drive gets into stop status upon receipt of pressing ent, and would get into parameter edit status when receiving pressing command again (if parameter is under password protection, the drive would get into password authentication status). Directly get into frequency modification status when receiving UP/DOWN command from terminal, or pressing or

## 4.1.3.4 Parameter Edit Status

Enter parameter edit status immediately upon pressing in STOP status, run parameters display status, and direct frequency modification status. This status could also be entered upon receipt of consecutive twice pressing in fault display status. The drive shall quit current status and be previous status upon receipt of pressing status.



Fig. 4-5 Parameter edit status

# 4.1.3.5 Parameter Value Setting Status

Enter parameter value setting status upon receipt of pressing when in parameter value edit status. When pressing or command is received in such a state, escape parameter edit status.



Fig. 4-6 Parameter setting status (b0-02 is set to 49.83Hz)

## 4.1.3.6 Password Authentication Status

On condition that parameters are under password protection, users would have to go through password authentication when they want to modify function code parameter value. Only A0-00 is visible in such a state.

Under password protection, the password authentication status will be first entered upon the receipt of pressing in STOP parameter display status, run parameter display status, or direct frequency modification status (refer to the setting method of parameters). It will enter parameter edit status upon the completion of password authentication.

## 4.1.3.7 Direct Frequency Modification Status

In the status of STOP, fault or run, the drive will enter frequency modification status when terminal UP/DOWN is enabled, or pressing or ...



Fig. 4-7 Direct frequency modification status

# 4.1.3.8 Prompt Message Status

Prompt message status shall be displayed at the completion of some certain operations. For instance, the "bASIC" prompt message would be displayed upon the completion of parameter initialization.



Fig. 4-8 Prompt message status

Prompt message characters and their meanings are shown as specified in Table 4-4.

**Table 4-4 Prompt characters** 

Prompt	Meaning	Prompt	Meaning
symbol		symbol	
bASIC	When A0-01 is set to 0	Cpyb1	Backup parameter value
dISP1	When A0-01 is set to 1	LoAd	Parameter upload to control panel
USEr	When A0-01 is set to 2	dnLd1	Parameter download from control panel (motor parameter excluded)
ndFLt	When A0-01 is set to 3	dnLd2	Parameter download from control panel (motor parameter included)
LoC-1	Control panel locked 1 (full locked)	P-Set	Password has been set
LoC-2	Control panel locked 2 (all locked except RUN, STOP/RESET)	P-CLr	Password cleared
LoC-3	Control panel locked 3 (all locked except STOP/RESET)	TUNE	Motor tune in process

LoC-4	Control panel locked 4 (all locked except shift )	LoU	Drive undervoltage		
PrtCt	Control panel protection	CLr-F	Clear fault record		
UnLoC	Control panel lock cleared	dEFt1	Restore to factory default parameters (motor parameter excluded)		
rECy1	Read the backup parameter value to parameter	dEFt2	Restore to factory default parameters (motor parameter included)		

Table 4-5 shows meanings of the characters displayed on control panel.

**Table 4-5 Meanings of displayed characters** 

Displayed	Character	Displayed	Character	Displayed	Character	Displayed	Character
character	Meaning	character	Meaning	character	Meaning	character	Meaning
	0	E.	А		ı		Т
	1		b		J		t
	2		С		L		U
	3		С		N		V
-	4	•	d		n		у
	5		E		0		-
<b>=</b> .	6		F		Р	Πij	8.
	7		G		q		
<b>三</b> 。	8		Н		r		
	9		h		S		

## 4.1.4 Setting Method of Parameters

## 4.1.4.1 Parameter System

GK600 series drive parameter group: A0~A1, b0~b2, C0~C4, d0~d5, E0~E1, F0~F3, H0~H1, L0~L1, U0~U1. Each parameter group contains a number of parameters. Parameters are identified by the combination "parameter group character + parameter subgroup number + parameter number". For instance, "F3-07" indicates the seventh function code at subgroup 3, group F.

# 4.1.4.2 Parameter Display Structure

Parameters and the parameter values are subject to a two-tier structure. Parameters correspond to first-tier display, while parameter values correspond to second-tier display.

First-tier display shown in Fig. 4-9:



Fig. 4-9 First-tier display of parameter

Second-tier display shown in Fig. 4-10:



Fig. 4-10 Second-tier display of parameter ("3" is the value of b0-00)

# 4.1.4.3 Example of Setting of Parameter

Parameter values are divided into decimal (DEC) and hexadecimal (HEX) values. When a parameter value is expressed by a hexadecimal, all its bits are independent of each other during edition and the range of value would be (0~F). Parameter value is composed of the ones, tens, hundreds and thousands place. Shift Key is used to select the bit to be changed, while and are used to increase or decrease numerical value.

- Example of parameter password setting
  - ◆ Setting of password (A0-00 is set to 1006)
  - In non-parameter edit status, it displays current parameter A0-00 when pressing
  - 2) Press to display parameter value 0000 that belongs to A0-00;
  - 3) Press for six times to change the rightmost digit "0" to "6";
  - 4) Press to move the flashing digit to the leftmost bit;
  - 5) Press once to change "0" in leftmost bit to "1";
  - 6) Press to save the value of A0-00, then Control panel will switch to display the next parameter A0-01;
  - 7) Press to change A0-01 to A0-00;
  - 8) Repeat steps 2) till 6). A0-01 will be displayed after control panel displaying P-Set;
  - 9) There are three methods for users to bring the password setting above into effect:
    - ① Press ESC + ENT + simultaneously (PrtCt displayed), ② won't operate control panel within 5 minutes, ③ restart the drive.

# Flow chart of user password setting:




Fig. 4-11 Flow chart of user password setting

#### ATTENTION:

User's password is successfully set when step 8 finished, but will not take effect until the completion of step 9.

#### ◆ Password authentication

In non-parameter edit status, press to enter first-tier display A0-00, then press to enter second-tier display 0.0.0.0. Control panel will implement the display of other parameters only when correct password entered.

#### ◆ Clear password

Upon the successful password authentication, access password setting code A0-00. Password can be cleared by writing value 0000 into A0-00 for twice.

## Example of parameter setting

- ◆ Example 1: modify upper limit frequency from 600Hz to 50Hz (change b0-09 from 600.00 to 50.00)
  - 1) In non-parameter edit status, press to display current parameter A0-00;
  - 2) Press to move flashing digit to modification bit (A flashes);
  - 3) Press once to change "A" to "b";
  - 4) Press to move flashing to modification bit (0 in ones place flashing);
  - 5) Press nine times to change "0" to "9";
  - 6) Press to view the parameter value (600.00) of b0-09;
  - 7) Press to move flashing digit to modification digit (6 flashing);
  - 8) Press six times to change "6" to "0";
  - 9) Press once to move flashing digit rightwards by one bit;

- 10) Press for five times to change "0" to "5";
- 11) Press to save the value (50.00) of b0-09. Then the control panel will automatically switch to display the next function code (b0-10);
- 12) Press to exit parameter edit status.

#### Flow chart is shown below:




Fig. 4-12 Flow chart of upper limit frequency modification

## ◆ Example 2: user parameter initialization

- 1) In non-parameter edit status, press to display current parameter A0-00;
- 2) Press three times to change "0" in the rightmost bit of A0-00 to "3";
- 3) Press to display parameter value 0 of A0-03;
- 4) Press once to change "0" to "2" or "3" ("2" motor parameter excluded, "3" means motor parameter included);
- 5) Press to save the value of A0-03. Then control panel will automatically display parameter A0-00:
- 6) Press to escape parameter edit status.

#### Flow chart is shown below:




Fig. 4-13 Flow chart of user parameter initialization

## ◆ Example 3: setting method of hexadecimal parameter

Take L1-02 (LED STOP display parameter) for example, if LED control panel is required to display: setting frequency, bus voltage, Al1, running linear speed, and setting linear speed. Since all bits are independent of each other, the ones place, tens place, hundreds place and thousands place should be set separately. Determine the binary numbers of each bit and then convert the binary numbers into a hexadecimal number. See Table 4-6, the corresponding relation between binary numbers and a hexadecimal number.

Table 4-6 Corresponding relation between binary and hexadecimal

	Binary ı	numbers		Hexadecimal
BIT3	BIT2	BIT1	BIT0	(LED bit display value)
0	0	0	0	0
0	0	0	1	1
0	0	1	0	2
0	0	1	1	3
0	1	0	0	4
0	1	0	1	5
0	1	1	0	6
0	1	1	1	7
1	0	0	0	8
1	0	0	1	9
1	0	1	0	Α
1	0	1	1	В
1	1	0	0	С
1	1	0	1	D
1	1	1	0	E
1	1	1	1	F

#### Set the value in the ones place:

As shown in Fig. 4-14, "setting frequency" and "bus voltage" are respectively determined by BIT0 and BIT1 in ones place of L1-02. If BIT0=1, setting frequency will be displayed. The bits that correspond to the parameters which are not required to display shall be set to 0. Therefore, the value in ones place should be 0011, corresponding to 3 in a hexadecimal number. Set the ones place to 3.

#### Set the value in tens place:

As shown in Fig. 4-14, since it is required to display "Al1", the binary set value of tens place is 0001, corresponding to 1 in a hexadecimal number. Thus, bit of tens place shall be set to 1.

#### Set the value in hundreds place:

As shown in Fig. 4-14, the parameter required to display does not involve hundreds place, so the hundreds place shall be set to zero.

#### Set thousands place:

As shown in Fig. 4-14, since required to display "running linear speed" and "setting linear speed", the binary set value of thousand place shall be 0011 that corresponds to 3 in a hexadecimal number.

To sum up, L1-02 should be set to 3013.



Fig. 4-14 Setting of hexadecimal parameter L1-02

Under parameter setting status, the parameter value cannot be modified if the value has no flashing digit. Possible causes include:

- The parameter cannot be modified, such as actual detection parameters, running recording parameters, etc;
- 2) This parameter cannot be modified in run status but could be changed when motor stopped;
- 3) Parameter under protection. When parameter A0-02 is set to 1, parameters cannot be modified as the parameter protection against misoperation enabled. To edit parameter in such a circumstance, it is necessary to set A0-02 to 0 as first step.

#### 4.1.4.4 Lock/Unlock Control Panel

#### Lock control panel

All or some keys of CONTROL PANEL can be locked by any of the following three methods. See the definition of parameter L0-01 for further information.

Method 1: set the parameter value of L0-01 to non-zero, then press

Method 2: do not operate CONTROL PANEL within five minutes after L0-01 is set to non-zero.

Method 3: cut the power off and then applying power on after L0-01 parameter is set to non-zero.

Refer to flow chart 4-15 for locking CONTROL PANEL.

#### Unlock control panel

To unlock control panel, press FSC + FSC + Simultaneously. Unlocking won't

change the value of parameter L0-01. In other words, control panel will be locked again if the condition of locking control panel is fulfilled. To unlock control panel completely, L0-01 value must be modified to 0 after unlocking.

Refer to flow chart 4- 16 of unlocking control panel




Fig. 4-15 Flow chart of locking control panel



Fig. 4-16 Flow chart of unlocking control panel

# 4.2 First-time Power up

Perform wiring in strict accordance with technical requirements as set forth in Chapter 3 – Installation and Wiring.

# 4.2.1 Flow chart of first-time power up of asynchronous motor




Fig. 4-17 Flow chart of first-time power up for asynchronous motor

# 4.2.2 Flow chart of first-time power up of synchronous motor




Fig.4-18 Flow chart of first-time power up for synchronous motor

# **Chapter 5 List of Parameters**

GK820 parameter groups are listed below:

Category	Parameter Group	Reference Page
Group A: System Parameters	A0: System Parameters	P73; P126
and Parameter Management	A1: User-defined Display Parameters	P74; P130
Consum hu	b0: Frequency Reference	P76; P132
Group b:	b1: Start/Stop Control	P77; P145
Run Parameter Setting	b2: Accel/Decel Parameters	P79; P151
	C0: Digital Input	P81; P158
O C-	C1: Digital Output	P85; P175
Group C:	C2: Analog and Pulse Input	P87; P182
Input & Output Terminals	C3: Analog and Pulse Output	P89; P187
	C4: Automatic Correction of Analog Input	P90; P192
	d0: Parameters of Motor 1	P90; P193
	d1: V/f Control Parameters of Motor 1	P92; P199
0	d2: Vector Control Parameters of Motor 1	P93; P204
Group d:	d3: Parameters of Motor 2	P95; P211
Motor and Control Parameters	d4: V/f Control Parameters of Motor 2	P97; P213
	d5: Vector Control Parameters of Motor 2	P98; P214
	d6: Encoder Parameters	P100; P215
Group E: Enhanced Function	E0: Enhanced Function	P101; P219
and Protection Parameters	E1: Protection Parameters	P103; P223
	F0: Process PID	P105; P227
	F1: Multi-step Frequency	P107; P233
Group F:	F2: Simple PLC	P108; P236
Application Parameters	F3: Wobble Frequency and Fixed Length Count	P112; P245
	F4: Position Control	P113; P250
	H0: MODBUS Communication	P114; P254
Group H:	Parameters	
Communication Parameters	H1: Profibus-DP Communication	P115; P256
	Parameters	
Group L: Keys and Display of	L0: Keys of Control Panel	P117; P256
Control panel Parameters	L1: Control Panel Display Setting	P118; P257
Crave II. Manitarina	U0: Status Monitoring	P119; P260
Group U: Monitoring	U1: History fault	P123; P264

# ATTENTION:

Change attribute:

- "\triangle" means the value of this parameter can be modified in stop and run status of drive;
- "x" means the value of this parameter cannot be modified when drive is running;

Factory default: The value when restored to factory default. Neither measured parameter value nor recorded value will be restored.

Scope: the scope of setting and display of parameter values.

Param.	Designation	Scope	Factory Default	Attr	
	Group A: Syste	em Parameters and Parameter Managemer	nt		
	Group A0: System Parameters				
A0-00	Setting of User Password	0000~FFFF	0000	Δ	
A0-01	Parameter display	O: Display all parameters 1: Only display A0-00 and A0-01 2: Only display A0-00, A0-01 and user-defined parameters A1-00-A1-19 3: Only display A0-00, A0-01, and the parameters different with factory default	0	Δ	
A0-02	Parameter Protection	O: All parameter programmable     Only A0-00 and this parameter     programmable	0	×	
A0-03	Parameter Initialization	O: No operation 1: Clear fault record 2: Restore all parameters to factory default (excluding motor parameters) 3: Restore all parameters to factory default (including motor parameters) 4: Restore all parameters to backup parameters	0	×	
A0-04	Parameter Backup	0: No operation 1: Backup all parameters	0	×	
A0-05	Parameter copy	0: No operation 1: Upload parameter 2: Download parameter (excluding motor parameters) 3: Download parameter (including motor parameters)  motor parameters)	0	×	
A0-06	Reserved	Reserved	Reserved	×	

<sup>&</sup>quot;®" means this parameter is a measured value that cannot be modified;

Param.	Designation	Scope	Factory Default	Attr
A0-07	Power supply type of SMPS	Supplied by DC bus voltage of drive main circuit     Supplied independently	0	0
A0-08	Motor 1 / motor 2 selection	0: Motor 1 1: Motor 2	0	×
A0-09	Motor control technique	Ones place: motor 1 control technique 0: V/f control 1: Sensor-less vector control 1 2: Sensor-less vector control 2 3. Closed-loop vector control Tens place: motor 2 control technique 0: V/f control 1: Sensor-less vector control 1 2: Sensor-less vector control 2 3. Closed-loop vector control	00	×
	Group A1: User-defined Display Parameters			
A1-00	User-defined Display Parameter 1		A0-00	×
A1-01	User-defined Display Parameter 2		A0-00	×
A1-02	User-defined Display Parameter 3		A0-00	×
A1-03	User-defined Display Parameter 4		A0-00	×
A1-04	User-defined Display Parameter 5		A0-00	×
A1-05	User-defined Display Parameter 6	Setting range of thousands place: A, b, C, d, E, F, H, L, U	A0-00	×
A1-06	User-defined Display Parameter 7	Setting range of hundreds place: 0~9 Setting range of tens place: 0~9	A0-00	×
A1-07	User-defined Display Parameter 8	Setting range of ones place: 0~9	A0-00	×
A1-08	User-defined Display Parameter 9		A0-00	×
A1-09	User-defined Display Parameter 10	-	A0-00	×
A1-10	User-defined Display Parameter 11		A0-00	×
A1-11	User-defined Display Parameter 12		A0-00	×

Param.	Designation	Scope	Factory Default	Attr
A1-12	User-defined Display Parameter 13		A0-00	×
A1-13	User-defined Display Parameter 14		A0-00	×
A1-14	User-defined Display Parameter 15		A0-00	×
A1-15	User-defined Display Parameter 16		A0-00	×
A1-16	User-defined Display Parameter 17		A0-00	×
A1-17	User-defined Display Parameter 18		A0-00	×
A1-18	User-defined Display Parameter 19		A0-00	×
A1-19	User-defined Display Parameter 20		A0-00	×
A1-20	Parameter group display/hide setting 1	0000~FFFF	FFFF	×
A1-21	Parameter group display/hide setting 2	0000~FFFF	FFFF	×
A1-22	Fault masking	0~FF Ones: binary Bit3Bit2Bit1Bit0 Bit set 0:unmask; 1: mask Bit0: GdP fault Bit1: SP1 fault Bit2: SP2 fault Bit3: CPU fault Tens: binary Bit3Bit2Bit1Bit0 Bit set 0:unmask; 1: mask Bit0: AIP fault Bit1: OL3 fault Bit2: oCR fault Bit3: reserved Example: if faults of GdP, SP1, SP2, CPU need to be masked, then set ones as hexadecimal F (set binary Bit3Bit2Bit1Bit0 as 1). And it is similar meaning for tens.	08	Δ

Param.	Designation	Scope	Factory Default	Attr
	Gr	oup b: Run Parameter Setting		
	Gr	oup b0: Frequency Reference		
b0-00	FREQ reference mode	O: Master frequency reference 1: Master & auxiliary computation result 2: Switch between master and auxiliary frequency reference 3: Switch between master frequency reference, and master & auxiliary computation result 4: Switch between auxiliary frequency reference, and master & auxiliary computation result	0	×
b0-01	Master FREQ reference source	0: Digital setting (b0-02) + control panel ^/∨ adjustment 1: Digital setting (b0-02) + terminal UP/DOWN adjustment 2: Analog input Al1 3: Analog input Al2 4: Analog input Al3 5: X6/DI pulse input 6: Process PID output 7: PLC 8: Multi-step speed 9: Communication 10: The orthogonal pulse input A+/A-, B+/B- 11: Pulse input A+/A- + terminal direction input	0	×
b0-02	Digital setting of master FREQ reference	Lower limit frequency ~ Upper limit frequency	50.00Hz	Δ
b0-03	Auxiliary FREQ reference source	0: No command 1: Digital setting (b0-04) + Control panel ^/v adjustment 2: Digital setting (b0-04) + terminal UP/DOWN adjustment	0	×

Param.	Designation	Scope	Factory Default	Attr
b0-04	Digital setting of auxiliary FREQ reference	Lower limit frequency ~ upper limit frequency	0.00Hz	Δ
b0-05	Auxiliary FREQ range	Relative to maximum frequency     Relative to master frequency	0	×
b0-06	Auxiliary FREQ coeff	0.0%~100.0%	100.0%	×
b0-07	Computation of master and auxiliary FREQ reference	0: Master + auxiliary 1: Master - auxiliary 2: Max {master, auxiliary} 3: Min {master, auxiliary}	0	×
b0-08	Maximum frequency	Upper limit frequency ~600.00Hz	50.00Hz	×
b0-09	Upper limit frequency	Lower limit frequency ~ maximum frequency	50.00Hz	×
b0-10	Lower limit frequency	0.00Hz~upper limit frequency	0.00Hz	×
	Action when FREQ	0: Run at lower limit frequency		
b0-11	reference lower than lower limit FREQ	1: Run at 0 Hz 2: Stop	0	×
b0-12	Time-delay of stop when FREQ reference lower than lower limit frequency	0.0s ~ 6553.5s	0.0s	×
b0-13	Lower limit of skip FREQ band 1	0.00Hz~upper limit frequency	0.00Hz	×
b0-14	Upper limit of skip FREQ band 1	0.00Hz~upper limit frequency	0.00Hz	×
b0-15	Lower limit of skip FREQ band 2	0.00Hz~upper limit frequency	0.00Hz	×
b0-16	Upper limit of skip FREQ band 2	0.00Hz~upper limit frequency	0.00Hz	×
b0-17	Lower limit of skip FREQ band 3	0.00Hz~upper limit frequency	0.00Hz	×
b0-18	Upper limit of skip FREQ band 3	0.00Hz~upper limit frequency	0.00Hz	×
b0-19	Jog frequency	0.00Hz~upper limit frequency	5.00Hz	Δ
	(	Group b1: Start/Stop Control		
b1-00	Run command	Control panel control     Terminal control     Communication control	0	×

Param.	Designation	Scope	Factory Default	Attr
b1-01	Binding of run command and frequency reference	Ones place: frequency reference source bundled under control panel control:  0: No binding 1: Digital setting (b0-02) + control panel // adjustment 2: Digital setting (b0-02) + terminal UP/DOWN adjustment 3: Analog input Al1 4: Analog input Al2 5: Analog input Al3 6: X7/DI pulse input 7: Process PID output 8: Simple PLC 9: Multi-step frequency A: Communication input  Tens place: frequency reference source bundled under terminal control (same as ones place)  Hundreds place: frequency reference source bundled under communication control (same as ones place)	000	×
b1-02	Run direction	0: Forward 1: Reverse	0	Δ
b1-03	Reverse-proof action	0: Reverse enabled 1: Reverse disabled	0	×
b1-04	Dead time between forward and reverse	0.0s~3600.0s	0.0s	Δ
b1-05	Start Mode	0: From start frequency 1: DC injection braking start 2: Flying start 1 3: Flying start 2 4. Flying start 3 Note A: need flying start option board EPC-VD2 for flying start 2 Note B: Normally flying start 3 is used for SW search at best effect	0	×
b1-06	Start frequency	0.00Hz~upper limit frequency	0.00Hz	×
b1-07	Holding time of start frequency	0.0s~3600.0s	0.0s	Δ

Param.	Designation	Scope	Factory Default	Attr
b1-08	DC braking current at start	0.0%~200.0%	0.0%	Δ
b1-09	DC braking time at start	0.00s~30.00s	0.00s	Δ
b1-10	Flying Start 1 Current	0.0%~200.0%	100.0%	×
b1-11	Flying Start 1 Decel Time	0.1s~20.0s	2.0s	×
b1-12	Flying start adjustment coeff	0.0%~100.0%	1.0%	×
b1-13	Stop method	0: Ramp to stop 1: Coast to stop 2: Ramp to stop + DC brake	0	×
b1-14	Start frequency of DC injection braking stop	0.00Hz~upper limit frequency	0.00Hz	×
b1-15	Current of DC injection braking stop	0.0%~200.0%	0.0%	Δ
b1-16	Time of DC injection braking stop	0.00s~30.00s	0.00s	Δ
b1-17	Overexcitation brake	0: Disabled 1: Enabled	1	×
b1-18	Dynamic brake	0: Disabled 1: Enabled	0	×
b1-19	Dynamic brake threshold voltage	650V~750V	720V	×
b1-20	Auto restart when power up again after power loss	0: Disabled 1: Enabled	0	×
b1-21	Time delay of auto restart when power up again	0.0s~10.0s	0.0s	Δ
	Gro	up b2: Accel/Decel Parameters		
b2-00	Accel/Decel time resolution	0: 0.01s 1: 0.1s 2: 1s	1	×
b2-01	Accel time 1	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-02	Decel time 1	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-03	Accel time 2	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-04	Decel time 2	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-05	Accel time 3	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-06	Decel time 3	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-07	Accel time 4	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-08	Decel time 4	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-09	Decel time at emergency stop	0s~600.00s/6000.0s/60000s	6.0s	Δ

Param.	Designation	Scope	Factory Default	Attr
b2-10	Jog Accel time	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-11	Jog Decel time	0s~600.00s/6000.0s/60000s	6.0s	Δ
b2-12	Accel/Decele curve	0: Linear Accel/Decel 1: Broken-line Accel/Decel 2: S-curve Accel/Decel A 3: S-curve Accel/Decel B 4: S-curve Accel/Decel C	0	×
b2-13	Accel time switching FREQ of broken-line Accel/Decel	0.00Hz~upper limit FREQ	0.00Hz	Δ
b2-14	Decel time switching FREQ of broken-line Accel/Decel	0.00Hz~upper limit FREQ	0.00Hz	Δ
b2-15	Time of initial segment of Accel S-curve	0.00s~60.00s (S-curve A)	0.20s	Δ
b2-16	Time of last segment of Accel S-curve	0.00s~60.00s (S-curve A)	0.20s	Δ
b2-17	Time of initial segment of Decel S-curve	0.00s~60.00s (S-curve A)	0.20s	Δ
b2-18	Time of last segment of Decel S-curve	0.00s~60.00s (S-curve A)	0.20s	Δ
b2-19	Proportion of initial segment of Accel S-curve	0.0%~100.0% (S-curve B)	20.0%	Δ
b2-20	Proportion of last segment of Accel S-curve	0.0%~100.0% (S-curve B)	20.0%	Δ
b2-21	Proportion of initial segment of Decel S-curve	0.0%~100.0% (S-curve B)	20.0%	Δ
b2-22	Proportion of last segment of Decel S-curve	0.0%~100.0% (S-curve B)	20.0%	Δ

Param.	Designation	Scope	Factory Default	Attr
	Gro	oup C: Input & Output Terminals		
		Group C0: Digital Input		
C0-00	Enabled condition of run command terminals when power up	0: Trigger edge detected + ON detected 1: ON detected	0	×
C0-01	Function of terminal X1	0: No function	3	×
C0-02	Function of terminal X2	1: JOG forward	4	×
C0-03	Function of terminal X3	2: JOG reverse	1	×
C0-04	Function of terminal X4	3: Running forward (FWD)	23	×
C0-05	Function of terminal X5	4: Running reverse (REV)	11	×
C0-06	Function of terminal X6	5: Three-wire control 6: Running suspended	0	×
C0-07	Function of terminal X7/DI	7: External stop 8: Emergency stop	0	×
C0-08	Function of terminal AI1 (Digital enabled)	9: Stop command + DC brake 10: DC injection braking stop	0	×
C0-09	Function of terminal AI2 (Digital enabled)	11: Coast to stop 12: Terminal UP	0	×
C0-10	Function of terminal AI3	13: Terminal DOWN 14: UP/DOWN (including ^/v key) adjustment clear 15: Multi-step frequency terminal 1 16: Multi-step frequency terminal 2 17: Multi-step frequency terminal 3 18: Multi-step frequency terminal 4 19: Accel/Decel time determinant 1 20: Accel/Decel time determinant 2 21: Accel/Decel disabled(ramp stop not inclusive) 22: External fault input 23: Fault reset (RESET) 24: Pulse input (valid only for X7/DI) 25: Motor 1/2 switchover 26: Speed/Torque control switch 27: Run command switched to control panel control 28: Run command switched to terminal control 29: Run command switched to communication control 30: FREQ reference mode shift	0	×

Param.	Designation	Scope	Factory Default	Attr
		31: Master FREQ reference switched to		
		digital setting b0-02		
		32: Auxiliary FREQ reference switched		
		to digital setting b0-04		
		33: PID adjustment direction		
		34: PID paused		
		35: PID integration paused		
		36: PID parameter switch		
		37: Count input		
		38: Count clear		
		39: Length count		
		40: Length clear		
		41: Zero-speed clamping enabled		
		42: Reserved		
		43: Reserved		
		44: Reserved		
		45: Reserved		
		46: Reserved		
		47: Reserved		
		48: Reserved		
		49: Reserved		
		50: Reserved		
		51: Position reference pulse input		
		52: Position reference direction input		
		53: Clear positioning pulse		
		54: Forward position offset enabled		
		55: Reverse position offset enabled		
		56: Pulse correction input		
		57: Pulse correction direction		
		58~62: Reserved		
		63: Simple PLC paused		
		64: Simple PLC disabled		
		65: Simple PLC stop memory clear		
		66: Start wobble frequency		
		67: Clear wobble frequency status		
		68: Running prohibited		
		69: DC brake in run		
		70: Analog input curve switchover		
		71: Position control switched to		
		disabled		
		72: Pulse frequency direction reference		
		73: Analog signal gain switch		
		74~99: Reserved		1

Param.	Designation	Scope	Factory Default	Attr
C0-11	Filtering time of digital input terminal	0.000s~1.000s	0.010s	Δ
C0-12	Delay time of terminal X1	0.0s~3600.0s	0.0s	Δ
C0-13	Delay time of terminal X2	0.0s~3600.0s	0.0s	Δ
C0-14	Digital input terminal enabled status setting 1	Ones place: X1 0: Positive logic 1: Negative logic Tens place: X2 (same as ones place) Hundreds place: X3 (same as ones place) place) Thousands place: X4 (same as ones place)	0000	×
C0-15	Digital input terminal enabled status setting 2	Ones place: X5 0: Positive logic 1: Negative logic Tens place: X6 (valid as ordinary terminal, same as ones place) Hundreds place: X7 (as common terminal, same as ones place) Thousands place: reserved	0000	×
C0-16	Digital input terminal enabled status setting 3	Ones place: Al1 0: Positive logic 1: Negative logic Tens place: Al2 (same as ones place) Hundreds place: Al3 (same as ones place) place) Thousands place: reserved	0000	×
C0-17	Terminal UP/DOWN frequency adjustment control	Ones place: action when stop  0: Clear  1: Holding Tens place: action on power loss  0: Clear  1: Holding Hundreds place: integral function  0: No integral function  1: Integral function enabled Thousands place: run direction  0: Unable to change the direction  1: Enable to change the direction	0000	Δ
C0-18	Terminal UP/DOWN frequency change step size	0.00Hz/s~100.00Hz/s	0.03 Hz/s	Δ

Param.	Designation	Scope	Factory Default	Attr
CO-19	FWD/REV terminal control mode	0: Two-wire mode 1 1: Two-wire mode 2 2: Three-wire mode 1 3: Three-wire mode 2	0	×
1 (20-20	Option of virtual input terminal	000~77F 0: Actual terminal in effect 1: Virtual terminal in effect Ones place: BIT0~BIT3: X1~X4 Tens place: BIT4~BIT6: X5~X7, Hundreds place: BIT8~BIT10: AI1~AI3	000	×
C0-21	Enabled condition of run command terminal after fault reset	0: Trigger edge detected + ON detected 1: ON detected	0	Δ

Param.	Designation	Scope	Factory Default	Attr
		Group C1: Digital Output		
C1-00	Y1 output function	0: No output	0	Δ
C1-01	Y2/DO output function (when used as Y2)	Drive undervoltage     Drive run preparation completed	0	Δ
C1-02	Relay 1 output function	3: Drive is running	14	Δ
C1-03	Relay 2 output function	4: Drive in 0Hz running (no output at stop) 5: Drive in 0Hz running (output at stop) 6: Run direction 7: Frequency attained 8: Upper limit frequency attained 9: Lower limit frequency attained 10: Frequency higher than FDT 1 11: Frequency higher than FDT 2 12: Speed being restricted (torque control mode) 13: Torque being restricted (speed control mode) 14: Fault output 15: Alarm output 16: Drive (motor) overloaded alarm 17: Drive thermal alarm 18: Zero current detection 19: X1 20: X2 21: Motor 1/ 2 indication 22: Set count value attained 23: Designated count value attained 24: Length attained 25: Consecutive run time attained 26: Accumulative run time attained 27: Brake control 28: Positioning completed 29: Positioning approaching 30: PLC step completed 31: PLC cycle completed 32: Wobble frequency attains to upper or lower limit frequency 33: The upper/lower limit of set frequency obtained 34~99: Reserved 0.0s~3600.0s	0.0s	

Param.	Designation	Scope	Factory Default	Attr
C1-05	Y2 output delay time	0.0s~3600.0s	0.0s	Δ
C1-06	Relay 1 output delay time	0.0s~3600.0s	0.0s	Δ
C1-07	Relay 2 output delay time	0.0s~3600.0s	0.0s	Δ
C1-08	Enabled state of digital output	Ones place: Y1 0: Positive logic 1: Negative logic Tens place: Y2 (same as ones place) Hundreds place: Relay 1 output (same as ones place) Thousands place: Relay 2 output (same as ones place)	0000	×
C1-09		Ones place: FDT1 detective object 0: Set value of speed (frequency after Accel/Decel) 1: Detected speed value  Tens place: FDT2 detective object 0: Set value of speed (frequency after Accel/Decel) 1: Detected speed value	00	Δ
C1-10	FDT1 upper value	0.00Hz~maximum frequency	50.00Hz	Δ
C1-11	FDT1 lower value	0.00Hz~maximum frequency	49.00Hz	Δ
C1-12	FDT2 upper value	0.00Hz~maximum frequency	25.00Hz	Δ
C1-13	FDT2 lower value	0.00Hz~maximum frequency	24.00Hz	Δ
C1-14	Detection width of frequency attained	0.00Hz~maximum frequency	2.50Hz	Δ
C1-15	Zero current detection level	0.0%~50.0%	5.0%	Δ
C1-16	Zero current detection time	0.01s~50.00s	0.50s	Δ

Param.	Designation	Scope	Factory Default	Attr
	Gro	up C2: Analog and Pulse Input		
C2-00	Analog input curve	Ones place: Al1 input curve 0: Curve 1 (2 points) 1: Curve 2 (4 points) 2: Curve 3 (4 points) 3: Curve 2 and Curve 3 switchover Tens place: Al2 input curve (same as ones place) Hundreds place: Al3 input curve (same as ones place) Thousands place: reserved	0210	×
C2-01	·	Curve 1 minimum input ~ 110.0%	100.0%	Δ
C2-02	Corresponding set value of curve 1 maximum input	-100.0%~100.0%	100.0%	Δ
C2-03	Curve 1 minimum input	-110.0% ~ Curve 1 maximum input	0.0%	Δ
C2-04	Corresponding set value of curve 1 minimum input	-100.0%~100.0%	0.0%	Δ
C2-05	Curve 2 maximum input	Range: input of curve 2 inflection point A~110.0%	100.0%	Δ
C2-06	Corresponding set value of curve 2 maximum input	Range: -100.0%~100.0%	100.0%	Δ
C2-07	Input of curve 2 inflection point A	Input of curve 2 inflection point B ~ curve 2 maximum input	0.0%	Δ
C2-08	Set value corresponding to input of curve 2 inflection point A	Range: -100.0%~100.0%	0.0%	Δ
C2-09	Input of curve 2 inflection point B	Range: Curve 2 minimum input ~ Input of curve 2 inflection point A	0.0%	Δ
C2-10	Set value corresponding to input of curve 2 inflection point B	Range: -100.0%~100.0%	0.0%	Δ
C2-11	Curve 2 minimum input	Range: -110.0%~ input of curve 2 inflection point B	0.0%	Δ
C2-12	Set value corresponding to curve 2 minimum input	Range: -100.0%~100.0%	0.0%	Δ
C2-13	Curve 3 maximum input	Range: input of curve 3 inflection point A ~110.0%	100.0%	Δ
C2-14	Set value corresponding to curve 3 maximum input	Range: -100.0%~100.0%	100.0%	Δ
C2-15	Input of curve 3 inflection point A	Range: input of curve 3 inflection point B ~ curve 3 maximum input	0.0%	Δ

Param.	Designation	Scope	Factory Default	Attr
C2-16	Set value corresponding to input of curve 3 inflection point A	Range: -100.0%~100.0%	0.0%	Δ
C2-17	l '	Range: curve 3 minimum input~ input of curve 3 inflection point A	0.0%	Δ
C2-18	Set value corresponding to input of curve 3 inflection point B	Range: -100.0%~100.0%	0.0%	Δ
C2-19	Curve 3 minimum input	Range: -110.0%~ input of curve 3 inflection point B	0.0%	Δ
C2-20	Set value corresponding to curve 3 minimum input	Range: -100.0%~100.0%	0.0%	Δ
C2-21	AI1 terminal filtering time	0.000s~10.000s	0.100s	Δ
C2-22	AI2 terminal filtering time	0.000s~10.000s	0.100s	Δ
C2-23	AI3 terminal filtering time	0.000s~10.000s	0.100s	Δ
C2-24	DI maximum input	Range: C2-26~300.0kHz	50.0kHz	Δ
C2-25	Set value corresponding to DI maximum input	Range: -100.0%~100.0%	100.0%	Δ
C2-26	DI minimum input	Range: 0.0kHz~C2-24	0.0kHz	Δ
C2-27	Set value corresponding to DI minimum input	Range: -100.0%~100.0%	0.0%	Δ
C2-28	DI filtering time	0.000s~1.000s	0.001s	Δ
C2-29	Analog gain switchover value	0.0%~100.0%	100.0%	Δ

Param.	Designation	Scope	Factory Default	Attr
	Gro	up C3: Analog and Pulse Output		
C3-00	AO1 output function	0: No output	2	Δ
C3-01	AO2 output function	1: FREQ reference	1	Δ
C3-02	Y2/DO output function (when used as DO)	2: Output frequency 3: Output current 4: Output torque 5: Output voltage 6: Output power 7: Bus voltage 8: Torque command 9: Torque current 10: Magnetic flux current 11: Al1 12: Al2 13: Al3 14: Reserved 15: DI 16: Communication input percentage 17: Output frequency before compensation 18: Output current (relative to motor rated current) 19: Output torque (direction hinted) 20: Set torque (direction hinted) 21~99: Reserved	0	Δ
C3-03	AO1 offset	-100.0%~100.0%	0.0%	×
C3-04	AO1 gain	-2.000~2.000	1.000	×
C3-05	AO1 filtering time	0.0s~10.0s	0.0s	Δ
C3-06	AO2 offset	-100.0%~100.0%	0.0%	×
C3-07	AO2 gain	-2.000~2.000	1.000	×
C3-08	AO2 filtering time	0.0s~10.0s	0.0s	Δ
C3-09	DO maximum output pulse frequency	0.1kHz~50.0kHz	50.0kHz	Δ
C3-10	DO output center point	0: No center point 1: Center point is (C3-09)/2, and the corresponding parameter value is positive when frequency is higher than center point 2: Center point is (C3-09)/2, and the corresponding parameter value is positive when frequency is lower than center point	0	×

Param.	Designation	Scope	Factory Default	Attr
C3-11	DO output filtering time	0.00s~10.00s	0.00s	Δ
	Group C4:	Automatic Correction of Analog Input		
		0: No correction		
04.00	A 1 1 - 1 - 1 1	1: Correct AI1		
C4-00	Analog corrected channel	2: Correct Al2	0	×
		3: Correct Al3		
C4-01	Sampling value of AI1 calibration point 1	0.00V~10.00V	1.00V	0
C4-02	Input value of AI1 calibration point 1	0.00V~10.00V	1.00V	×
C4-03	Sampling value of AI1 calibration point 2	0.00V~10.00V	9.00V	0
C4-04	Input value of AI1 calibration point 2	0.00V~10.00V	9.00V	×
C4-05	Sampling value of AI2 calibration point 1	0.00V~10.00V	1.00V	0
C4-06	Input value of AI2 calibration point 1	0.00V~10.00V	1.00V	×
C4-07	Sampling value of Al2 calibration point 2	0.00V~10.00V	9.00V	0
C4-08	Input value of AI2 calibration point 2	0.00V~10.00V	9.00V	×
C4-09	Sampling value of Al3 calibration point 1	-10.00V~10.00V	1.00V	0
C4-10	Input value of Al3 calibration point 1	-10.00V~10.00V	1.00V	×
C4-11	Sampling value of Al3 calibration point 2	-10.00V~10.00V	9.00V	0
C4-12	Input value of AI3 calibration point 2	-10.00V~10.00V	9.00V	×
	Group	d Motor and Control Parameters		
	Gro	oup d0: Parameters of Motor 1		
d0-00	Type of motor 1	0: Ordinary motor 1: Variable frequency motor 2: Synchronous motor	1	×
d0-01	Power rating of motor 1	0.4kW~6553.5kW	Model dependent	×
d0-02	Rated voltage of motor 1	0V~480V (for drives 400V level)	380V	×

Param.	Designation	Scope	Factory Default	Attr
d0-03	Rated current of motor 1	0.0A~6553.5A	Model dependent	×
d0-04	Rated frequency of motor 1	0.00Hz~maximum frequency	50.00Hz	×
d0-05	Pole number of motor 1	1~80	4	×
d0-06	Rated speed of motor 1	0r/min~65535r/min	Model dependent	×
d0-07	Stator resistance R1 of async motor 1	0.001Ω~65.535Ω	Model dependent	×
d0-08	Leakage inductance L1 of async motor 1	0.1mH~6553.5mH	Model dependent	×
d0-09	Rotor resistance R2 of async motor 1	0.001Ω~65.535Ω	Model dependent	×
d0-10	Mutual inductance L2 of async motor 1	0.1mH~6553.5mH	Model dependent	×
d0-11	No-load current of async motor 1	0.0A~6553.5A	Model dependent	×
d0-12	Flux weakening coeff 1 of async motor 1	0.0000~1.0000	Model dependent	×
d0-13	Flux weakening coeff 2 of async motor 1	0.0000~1.0000	Model dependent	×
d0-14	Flux weakening coeff 3 of async motor 1	0.0000~1.0000	Model dependent	×
d0-15	Stator resistance of synch motor 1	0.001Ω~65.535Ω	Model dependent	×
d0-16	Direct-axis inductance of synch motor 1	0.1mH~6553.5mH	Model dependent	×
d0-17	Quadrature axis inductance of synch motor 1	0.1mH~6553.5mH	Model dependent	×
d0-18	Counter-EMF constant of synch motor 1	0~1000	Model dependent	×
d0-19	Autotune current of synch motor 1	0.0%~100.0%	30.0%	×

Param.	Designation	Scope	Factory Default	Attr
d0-20	Initial angle of synch motor 1	0.0°~360.0°	0.0°	×
d0-21	Z-pulse initial angle of synch motor 1	0000~FFFF	0000	×
d0-22	Autotune of motor 1	O: No autotune 1: Static autotune of async motor 2: Rotary autotune of async motor 3: Static autotune of synch motor 4: Rotary autotune of synch motor	0	×
d0-23	Overload protection mode of motor 1	0: No protection 1: Judged by motor current 2: Judged by temperature transducer	1	×
d0-24	Overload protection detection time of motor 1	0.1min~15.0min	5.0min	×
d0-25	Temperature transducer signal input of motor 1	0: Al1 1: Al2 2: Al3	1	×
d0-26	Thermal protection threshold of motor 1 temperature transducer	0.00V~10.00V	10.00V	×
d0-27	SW rotary speed track Kp	0.00~655.35	0.00	×
d0-28	SW rotary speed track Ki	0.00~655.35	2.00	×
	Group d	1: V/f Control Parameters of Motor 1		
d1-00	V/f curve setting	0: Linear V/f 1: Multi-step V/f (d1-01~d1-08) 2: 1.2nd power 3: 1.4th power 4: 1.6th power 5: 1.8th power 6: 2.0nd power	0	×
d1-01	V/f frequency value f3	0.00Hz~rated frequency of motor	50.00Hz	×
d1-02	V/f voltage value V3	0.0%~100.0%	100.0%	×
d1-03	V/f frequency value f2	d1-05~d1-01	0.00Hz	×
d1-04	V/f voltage value V2	0.0%~100.0%	0.0%	×
d1-05	V/f frequency value f1	d1-07~d1-03	0.00Hz	×
d1-06	V/f voltage value V1	0.0%~100.0%	0.0%	×
d1-07	V/f frequency value f0	0.00Hz~d1-05	0.00Hz	×
d1-08	V/f voltage value V0	0.0%~100.0%	0.0%	×
d1-09	Torque boost	0.0%~30.0%	0.0%	Δ

Param.	Designation	Scope	Factory Default	Attr
d1-10	Slip compensation gain	0.0%~400.0%	100.0%	Δ
d1-11	Droop control	0.00Hz~10.00Hz	0.00Hz	Δ
d1-12	Current limitation mode	0: Disabled 1: Set by d1-13 2: Set by Al1 3: Set by Al2 4: Set by Al3 5: Set by X7/DI	1	×
d1-13	Digital setting of current limit value	20.0%~200.0%	160.0%	×
d1-14	Current limit coeff on flux weakening	0.001~1.000	0.500	Δ
d1-15	Energy saving percentage	0.0%~40.0%	0.0%	Δ
d1-16	V/f oscillation suppression gain 1	0~3000	66	Δ
d1-17	V/f oscillation suppression gain 2	0~3000	0	Δ
	Group d2:	Vector Control Parameters of Motor 1		
d2-00	Speed/torque control	0: speed control 1: torque control	0	×
d2-01	ASR high-speed proportional gain Kp1	0.0~20.0	2.0	Δ
d2-02	ASR high-speed integration time Ti1	0.000s~8.000s	0.200s	Δ
d2-03	ASR low-speed proportional gain Kp2	0.0~20.0	2.0	Δ
d2-04	ASR low-speed integration time Ti2	0.000s~8.000s	0.200	Δ
d2-05	ASR switching frequency	0.00Hz~d2-06	5.00Hz	Δ
d2-06	ASR switching frequency 2	d2-05~upper limit frequency	10.00Hz	Δ
d2-07	ASR input filtering time	0.0ms~500.0ms	0.3ms	Δ
d2-08	ASR output filtering time	0.0ms~500.0ms	0.3ms	Δ
d2-09	D-axis ACR proportion coefficient Kp	0.000~8.000	1.000	Δ
d2-10	D-axis ACR integration coefficient Ki	0.000~8.000	1.000	Δ

Param.	Designation	Scope	Factory Default	Attr
d2-11	Pre-excitation time	0.000s~5.000s	0.200s	Δ
d2-12	Driven torque restriction source	0: d2-14 digital setting 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	×
d2-13	Braking torque restriction source	0: d2-15 digital setting 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	×
d2-14	Digital setting of driven torque limit value	0.0%~200.0%	180.0%	Δ
d2-15	Digital setting of braking torque limit value	0.0%~200.0%	180.0%	Δ
d2-16	Torque limit coefficient in flux weakening	0.0%~100.0%	50.0%	Δ
d2-17	Driven slip compensation gain	10.0%~300.0%	100.0%	Δ
d2-18	Brake slip compensation gain	10.0%~300.0%	100.0%	Δ
d2-19	Torque reference source	0: Set by d2-20 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	х
d2-20	Digital setting of torque	-200.0%~200.0%	0.0%	Δ
d2-21	Forward speed limitation source under torque control	0: Set by d2-23 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	Х
d2-22	Reverse speed limitation source under torque control	0: Set by d2-24 1: Al1 2: Al2	0	

Param.	Designation	Scope	Factory Default	Attr
		3: Al3 4: X7/DI pulse input 5: Communication		
d2-23	Forward speed limited value under torque control	0.00Hz ~maximum frequency	50.00Hz	×
d2-24	Reverse speed limited value under torque control	0.00Hz ~maximum frequency	50.00Hz	×
d2-25	Set torque accel/decel time	0.00s~120.00s	0.10s	Δ
d2-26	Low-frequency torque switching frequency 1	0.0%~d2-06	0.00Hz	Δ
d2-27	Low-frequency torque switching frequency 2	d2-05~upper limit frequency	10.00Hz	Δ
d2-28	Low-frequency torque	0.0%~200.0%	120.0%	Δ
d2-29	Q-axis ACR proportion coefficient Kp	0.000~8.000	1.000	Δ
d2-30	Q-axis ACR integration coefficient Ki	0.000~8.000	1.000	Δ
	Gro	oup d3: Parameters of Motor 2		
d3-00	Type of motor 2	O: Ordinary asynchronous motor     Variable frequency asynchronous motor     Synchronous motor	0	×
d3-01	Power rating of motor 2	0.4kW~6553.5kW	Model dependent	×
d3-02	Rated voltage of motor 2	0V~480V (for drives 400V level)	380V	×
d3-03	Rated current of motor 2	0.0A~6553.5A	Model dependent	×
d3-04	Rated frequency of motor 2	0.00Hz~maximum frequency	50.00Hz	×
d3-05	Pole number of motor 2	1~80	4	×
d3-06	Rated speed of motor 2	0r/min~65535r/min	Model dependent	×
d3-07	Stator resistance R1 of async motor 2	0.001Ω~65.535Ω	Model dependent	×

Param.	Designation	Scope	Factory Default	Attr
d3-08	Leakage inductance L1 of async motor 2	0.1mH~6553.5mH	Model dependent	×
d3-09	Rotor resistance R2 of async motor 2	0.001Ω~65.535Ω	Model dependent	×
d3-10	Mutual inductance L2 of asynchronous motor 2	0.1mH~6553.5mH	Model dependent	×
d3-11	No-load current of async motor 2	0.0A~6553.5A	Model dependent	×
d3-12	Flux weakening coeff 1 of async motor 2	0.0000~1.0000	Model dependent	×
d3-13	Flux weakening coeff 2 of async motor 2	0.0000~1.0000	Model dependent	×
d3-14	Flux weakening coeff 3 of async motor 2	0.0000~1.0000	Model dependent	×
d3-15	Stator resistance of synch motor 2	0.001Ω~65.535Ω	Model dependent	×
d3-16	Direct-axis inductance of synch motor 2	0.1mH~6553.5mH	Model dependent	×
d3-17	Quadrature axis inductance of synch motor 2	0.1mH~6553.5mH	Model dependent	×
d3-18	Counter-EMF constant of synch motor 2	0~1000	Model dependent	×
d3-19	Autotune current of synch motor 2	0.0%~100.0%	30.0%	×
d3-20	Initial angle of synch motor 2	0°~360.0°	0.0°	×
d3-21	Z-pulse initial angle of synch motor 2	0~FFFF	0	×
d3-22	Autotune of motor 2	0: No autotune 1: Static autotune of async motor 2: Rotary autotune of async motor 3: Static autotune of synch motor 4: Rotary autotune of synch motor	0	×

Param.	Designation	Scope	Factory Default	Attr
d3-23	Overload protection mode of motor 2	0: No protection 1: Judged by motor current 2: Judged by temperature transducer	1	×
d3-24	Overload protection detection time of motor 2	0.1min~15.0min	5.0min	×
d3-25	Temperature transducer signal input of motor 2	0: Al1 1: Al2 2: Al3	1	×
d3-26	Thermal protection threshold of motor 2 temperature transducer	0.00V~10.00V	10.00V	×
	Group d	4: V/f Control Parameters of Motor 2		
d4-00	V/f curve setting	0: Linear V/f 1: Multi-step V/f (d1-01~d1-08) 2: 1.2 <sup>nd</sup> power 3: 1.4 <sup>th</sup> power 4: 1.6 <sup>th</sup> power 5: 1.8 <sup>th</sup> power 6: 2.0 <sup>nd</sup> power	0	×
d4-01	V/f frequency value f3	0.00Hz~rated frequency of motor	50.00Hz	×
d4-02	V/f voltage value V3	0.0%~100.0%	100.0%	×
d4-03	V/f frequency value f2	d4-05~d4-01	0.00Hz	×
d4-04	V/f voltage value V2	0.0%~100.0%	0.0%	×
d4-05	V/f frequency value f1	d4-07~d4-03	0.00Hz	×
d4-06	V/f voltage value V1	0.0%~100.0%	0.0%	×
d4-07	V/f frequency value f0	0.00Hz~d4-05	0.00Hz	×
d4-08	V/f voltage value V0	0.0%~100.0%	0.0%	×
d4-09	Torque boost	0.0%~30.0%	0.0%	Δ
d4-10	Slip compensation gain	0.0%~300.0%	100.0%	Δ
d4-11	Droop control	0.00Hz~10.00Hz	0.00Hz	Δ
d4-12	Current limitation mode	0: Disabled 1: Set by d4-13 2: Set by Al1 3: Set by Al2 4: Set by Al3 5: Set by X7/DI	1	×
d4-13	Digital setting of current limit value	20.0%~200.0%	160.0%	×

Param.	Designation	Scope	Factory Default	Attr
d4-14	Current limit coeff on flux weakening	0.001~1.000	0.500	Δ
d4-15	Energy saving percentage	0%~40.0%	0.0%	Δ
d4-16	V/f oscillation suppression gain 1	0~3000	16	Δ
d4-17	V/f oscillation suppression gain 2	0~3000	20	Δ
	Group d5:	Vector Control Parameters of Motor 2		
d5-00	Speed/torque control	0: speed control 1: torque control	0	×
d5-01	ASR high-speed proportional gain Kp1	0.0~20.0	2.0	Δ
d5-02	ASR high-speed integration time Ti1	0.000s~8.000s	0.200	Δ
d5-03	ASR low-speed proportional gain Kp2	0.0~20.0	2.0	Δ
d5-04	ASR low-speed integration time Ti2	0.000s~8.000s	0.200	Δ
d5-05	ASR switching frequency	0.00Hz~d5-06	5.00Hz	Δ
d5-06	ASR switching frequency 2	d5-05~upper limit frequency	10.00Hz	Δ
d5-07	ASR input filtering time	0.0ms~500.0ms	0.3ms	Δ
d5-08	ASR output filtering time	0.0ms~500.0ms	0.3ms	Δ
d5-09	ACR proportion coeff Kp	0.000~4.000	1.000	Δ
d5-10	ACR integration coeff Ki	0.000~4.000	1.000	Δ
d5-11	Pre-excitation time	0.000s~5.000s	0.200s	Δ
d5-12	Driven torque restriction source	0: d5-14 digital setting 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	×
d5-13	Braking torque restriction source	0: d5-15 digital setting 1: AI1 2: AI2 3: AI3	0	×

Param.	Designation	Scope	Factory Default	Attr
		4: X7/DI pulse input 5: Communication		
d5-14	Digital setting of driven torque limit value	0.0%~200.0%	180.0%	Δ
d5-15	Digital setting of braking torque limit value	0.0%~200.0%	180.0%	Δ
d5-16	Torque limit coefficient in flux weakening	0.0%~100.0%	50.0%	Δ
d5-17	Driven slip compensation gain	10.0%~300.0%	100.0%	Δ
d5-18	Brake slip compensation gain	10.0%~300.0%	100.0%	Δ
d5-19	Torque reference source	0: Set by d5-20 1: Al1 2: Al2 3: Al3 4: X7/Dl pulse input 5: Communication	0	×
d5-20	Digital setting of torque	-200.0%~200.0%	0.0%	Δ
d5-21	Forward speed limitation source under torque control	0: Set by d5-23 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	×
d5-22	Reverse speed limitation source under torque control	0: Set by d5-24 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Communication	0	×
d5-23	Forward speed limited value under torque control	0.00Hz ~maximum frequency	50.00Hz	×
d5-24	Reverse speed limited value under torque control	0.00Hz ~maximum frequency	50.00Hz	×
d5-25	Set torque accel/decel	0.00s~120.00s	0.10s	Δ

Param.	Designation	Scope	Factory Default	Attr
	time			
d5-26	Static friction torque compensation	0.0%~100.0%	0.0%	Δ
d5-27	Sliding friction torque compensation	0.0%~100.0%	0.0%	Δ
d5-28	Rotary inertia compensation coeff	0.000~1.000	0.000	Δ
	Gı	roup d6: Encoder Parameters		
d6-00	Speed feedback encoder options	Ones place: motor 1 speed feedback encoder option 0: encoder 1 (local) 1: encoder 2 (expanded) Tens place: motor 2 speed feedback encoder option 0: encoder 1 (local) 1: encoder 2 (expanded)	00	×
d6-01	Resolution of encoder 1	1~10000	1024	Δ
d6-02	Direction of encoder 1	0: Forward 1: Reverse	0	×
d6-03	Numerator of the ratio of motor speed to encoder 1 speed	1~65535	1000	×
d6-04	Denominator of the ratio of motor speed to encoder 1 speed	1~65535	1000	×
d6-05	Encoder 1 disconnection detected time	0.0s~8.0s	3.0s	Δ
d6-06	Type of encoder 2	0: ABZ encoder 1: UVW encoder 2: Resolver 3: SINCOS encoder (Select 2 for PG4 and 1 for PG6)	0	×
d6-07	Resolution of encoder 2	1~10000	1024	Δ
d6-08	Direction of encoder 2	Ones place: AB direction 0: Forward 1: Reverse	00	×

Param.	Designation	Scope	Factory Default	Attr
		Tens place: UVW direction 0: Forward 1: Reverse		
d6-09	Numerator of the ratio of motor speed to encoder 2 speed	1~65535	1000	×
d6-10	Denominator of the ratio of motor speed to encoder 2 speed	1~65535	1000	×
d6-11	Encoder 2 disconnection detected time	0.0s~8.0s	3.0s	Δ
d6-12	Over-speed (OS) and excessive speed deviation (DEV) action	Ones place: action in over-speed (OS) 0: Coast to stop, with fault reported 1: Run continued Tens place: action in excessive speed deviation (DEV) 0: Coast to stop, with fault reported 1: Run continued	11	×
d6-13	Detected value of over- speed (OS)	0.0%~120.0%	120.0%	×
d6-14	Detected time of over- speed (OS)	0.00s~20.00s	0.50s	×
d6-15	Detected value of excessive speed deviation (DEV)	0.0%~50.0%	10.0%	×
d6-16	Detected time of excessive speed deviation (DEV)	0.00s~20.00s	1.00s	×
	Group E: Enha	nced Function and Protection Paramete	rs	
	G	Group E0: Enhanced function		
E0-00	Switching FREQ	≤15kW:  0.7kHz~16.0kHz, factory default:  8.0kHz  18.5kW~45kW:  0.7kHz~10.0kHz, factory default:  4.0 kHz  55kW~75kW:  0.7kHz~8.0kHz, factory default:  3.0 kHz	Model dependent	Δ

Param.	Designation	Scope	Factory Default	Attr
		≥90kW: 0.7kHz~3.0kHz, factory default: 2.0 kHz		
E0-01	PVVM optimization	Ones place: switching FREQ adjusted with temperature  0: Self-adaption  1: No adjustment Tens place: PWM modulation mode  0: Five-segment and seven-segment automatic switchover  1: Five-segment mode  2: Seven-segment mode  Hundreds place: over-modulation adjustment  0: Disabled  1: Enabled Thousands place: PWM switching frequency relation with output frequency  0: Self-adaption  1: No adaption	0100	×
E0-02	Action when run time attained	Ones place: action when consecutive run time attained: 0: Run continued 1: Stop and fault reported Tens place: action when accumulative run time attained: 0: Run continued 1: Stop and fault reported Hundreds place: unit of run time 0: Second 1: Hour	000	×
E0-03	Consecutive run time setting	0.0s(h)~6000.0s(h)	0.0s(h)	×
E0-04	Accumulative run time setting	0.0s(h)~6000.0s(h)	0.0s(h)	×
E0-05	Mechanical brake control	0: Disabled 1: Enabled	0	×
E0-06	Mechanical brake open frequency	0.00Hz~10.00Hz	2.50Hz	×

Param.	Designation	Scope	Factory Default	Attr
E0-07	Mechanical brake open current	0.0%~200.0%	120.0%	×
E0-08	Accel delay time after brake open	0.0s~10.0s	1.0s	×
E0-09	Mechanical brake frequency	0.00Hz~10.00Hz	2.00Hz	×
E0-10	Mechanical brake close waiting time	0.0s~10.0s	0.0s	×
E0-11	Mechanical brake close holding time	0.0s~10.0s	1.0s	×
	Gro	oup E1: Protection Parameters		
		O: Prohibited		
E1-00	Overvoltage stall	1: Allowed	1	×
		2: Only valid for decel		
E1-01	Overvoltage stall protection voltage	120%~150%	130%	×
E1-02	Undervoltage stall	0: Disabled 1: Enabled	0	×
E1-03	Overload alarm	Ones place: detection option:  0: Always detect  1: Detect at constant speed only  Tens place: compared with  0: Motor rated current  1: Drive rated current  Hundreds place: drive action  0: Alarm but run continued  1: Alarm and coast to stop	000	×
E1-04	Overload alarm threshold		180.0%	Δ
E1-05	Overload alarm detecting time	0.1s~60.0s	5.0s	Δ
E1-06	Protection action 1	Ones place:encoder disconnected(CLL) 0: Alarm and coast to stop 1: Alarm but run continued Tens place: PIM temperature measurement circuit fault (oH3) 0: Alarm and coast to stop 1: Alarm but run continued Hundreds place: abnormal EEPROM (Epr) 0: Alarm and coast to stop	0000	×

Param.	Designation	Scope	Factory Default	Attr
		1: Alarm but run continued Thousands place: abnormal terminal communication (TrC) 0: Alarm and coast to stop 1: Alarm but run continued Ones place: abnormal power supply at		
E1-07	Protection action 2	run (SUE)  0: Alarm and coast to stop  1: Alarm but run continued  Tens place: current detection circuit failed (CtC)  0: Alarm and coast to stop  1: Alarm but run continued  Hundreds place: abnormal contactor (CCL):  0: Alarm and coast to stop  1: Alarm but run continued  Hundreds place: abnormal contactor (CCL):  0: Alarm and coast to stop  1: Alarm but run continued  Thousands place: input power supply fault / output phase loss (ISF, oPL):  0: Protection for neither input supply fault nor output phase loss  1: No protection for input supply fault, protection enabled for output phase loss  2: Protection enabled for input supply fault, no protection for output phase loss  3: Protection enabled for both input supply fault and output phase loss	3001	×
E1-08	Fault memory after power loss	Not memorized after power loss     Memorized after power loss	0	×
E1-09	Fault auto-reset times	0~20	0	×
E1-10	Auto-reset interval	2.0s~20.0s	2.0s	×
E1-11	Relay action on drive fault	Ones place: when undervoltage fault occurs  0: No action 1: Action enabled Tens place: when fault locked 0: No action 1: Action enabled Hundreds place: auto-reset interval 0: No action	010	×

Param.	Designation	Scope	Factory Default	Attr
		1: Action enabled		
E1-12	Cooling fan control	0: Auto run 1: Always run after power up	0	Δ
E1-13	Drive overheat alarm threshold	0.0°C~100.0°C	80.0℃	Δ
	Gro	oup F Application Parameters		
		Group F0: Process PID		
		0: F0-01 digital setting		
		1: Al1		
		2: AI2	_	
F0-00	PID reference	3: AI3	0	×
		4: X7/DI pulse input		
		5: Communication		
F0-01	PID digital setting	0.0%~100.0%	50.0%	Δ
	3 3	0: Al1		
	PID feedback	1: AI2		
		2: AI3		
		3: Al1+Al2		
F0-02		4: Al1-Al2	0	×
		5: Max {AI1, AI2}	· ·	~
		6: Min {Al1, Al2}		
		7: X7/DI pulse input		
		8: Communication		
		Ones place: output frequency		
		0: Must be the same direction as the		
		set run direction		
		1: Opposite direction allowed		
F0-03	PID adjustment	Tens place: integration selection	10	×
	,	0: Integral continued when FREQ		
		attains upper/lower limit		
		1: Integral stopped when FREQ attains		
		upper/lower limit		
F0.04	PID positive and negative	0: Positive adjustment	0	
F0-04	adjustment	1: Negative adjustment	0	×
F0-05	Filtering time of PID reference	0.00s~60.00s	0.00s	Δ
F0-06	Filtering time of PID feedback	0.00s~60.00s	0.00s	Δ
F0-07	Filtering time of PID output	0.00s~60.00s	0.00s	Δ
F0-08	Proportional gain Kp1	0.0~200.0	50.0	Δ

Param.	Designation	Scope	Factory Default	Attr
F0-09	Integration time Ti1	0.000s~50.000s	0.500s	Δ
F0-10	Derivative time Td1	0.000s~50.000s	0.000s	Δ
F0-11	Proportional gain Kp2	0.0~200.0	50.0	Δ
F0-12	Integration time Ti2	0.000s~50.000s	0.500s	Δ
F0-13	Derivative time Td2	0.000s~50.000s	0.000s	Δ
F0-14	PID parameter switch	O: No switch, determined by parameters Kp1, Ti1 and Td1 1: Auto-switched on the basis of input offset 2: Switched by terminal	0	×
F0-15	Input offset under PID auto switch	0.0%~100.0%	20.0%	Δ
F0-16	Sampling period T	0.001s~50.000s	0.002s	Δ
F0-17	PID offset limit	0.0%~100.0%	0.0%	Δ
F0-18	PID derivative limit	0.0%~100.0%	0.5%	Δ
F0-19	PID initial value	0.0%~100.0%	0.0%	×
F0-20	PID initial value holding time	0.0s~3600.0s	0.0s	Δ
F0-21	PID feedback loss detection value	0.0%~100.0%	0.0%	Δ
F0-22	PID feedback loss detection time	0.0s~30.0s	1.0s	Δ
F0-23	Cutoff FREQ when opposite to rotary set direction	0.00Hz∼maximum FREQ	50.00Hz	Δ
F0-24	PID computation option	0: No computation in stop status 1: Computation continued in stop status	0	Δ

Param.	Designation	Scope	Factory Default	Attr
	Gı	oup F1: Multi-step Frequency		
F1-00	FREQ set source of multi-step 0	0: Digital setting F1-02 1: Digital setting b0-02 + control panel ^/   v adjustment 2: Digital setting b0-02 + terminal   UP/DOWN adjustment 3: Al1 4: Al2 5: Al3 6: X7/DI pulse input 7: Process PID output 8: Communication	0	×
F1-01	FREQ set source of multi-step 1	0: Digital setting F1-03 1: Digital setting b0-04 + control panel ^/	0	×
F1-02	Multi-step FREQ 0	-100.0%~100.0% Note: percentage against upper limit FREQ b0-09. Meaning of F1-03~F1-17 is the same with F1-02	0.0%	Δ
F1-03	Multi-step FREQ 1	-100.0%~100.0%	0.0%	Δ
F1-04	Multi-step FREQ 2	-100.0%~100.0%	0.0%	Δ
F1-05	Multi-step FREQ 3	-100.0%~100.0%	0.0%	Δ
F1-06	Multi-step FREQ 4	-100.0%~100.0%	0.0%	Δ
F1-07	Multi-step FREQ 5	-100.0%~100.0%	0.0%	Δ
F1-08	Multi-step FREQ 6	-100.0%~100.0%	0.0%	Δ
F1-09	Multi-step FREQ 7	-100.0%~100.0%	0.0%	Δ
F1-10	Multi-step FREQ 8	-100.0%~100.0%	0.0%	Δ
F1-11	Multi-step FREQ 9	-100.0%~100.0%	0.0%	Δ
F1-12	Multi-step FREQ 10	-100.0%~100.0%	0.0%	Δ
F1-13	Multi-step FREQ 11	-100.0%~100.0%	0.0%	Δ
F1-14	Multi-step FREQ 12	-100.0%~100.0%	0.0%	Δ
F1-15	Multi-step FREQ 13	-100.0%~100.0%	0.0%	Δ

Param.	Designation	Scope	Factory Default	Attr
F1-16	Multi-step FREQ 14	-100.0%~100.0%	0.0%	Δ
F1-17	Multi-step FREQ 15	-100.0%~100.0%	0.0%	Δ
		Group F2: Simple PLC		
F2-00	Simple PLC run mode	Ones place: PLC run mode 0: Stop after a single cycle 1: Continue to run with the last FREQ after a single cycle 2: Cycle repeated Tens place: power loss memory 0: No memory on power loss 1: Memorized on power loss Hundreds place: start mode 0: Run from the first step "multi-step frequency 0" 1: Continue to run from the step of stop (or fault) 2: Continue to run from the step and FREQ at which the running stopped (or fault occurred) Thousands place: unit of simple PLC run time 0: Second (s) 1: Minute (min)	0000	×
F2-01	Setting of multi-step 0	Ones place: FREQ reference 0: Multi-step FREQ 0 (F1-02) 1: Al1 2: Al2 3: Al3 4: X7/DI pulse input 5: Process PID output 6: Multi-step FREQ 7: Communication Tens place: run direction 0: Forward 1: Reverse 2: Determined by run command Hundreds place: Accel/Decel time 0: Accel/Decel time 1 1: Accel/Decel time 2 2: Accel/Decel time 3 3: Accel/Decel time 4	000	×
F2-02	Run time of step 0	0.0s(min)~6000.0s(min)	0.0s	Δ

F2-03	Setting of step 1	Ones place: FREQ reference 0: Multi-step FREQ 1 (F1-03) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-04	Run time of step 1	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-05	Setting of step 2	Ones place: FREQ reference 0: Multi-step FREQ 2 (F1-04) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-06	Run time of step 2	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-07	Setting of step 3	Ones place: FREQ reference 0: Multi-step FREQ 3 (F1-05) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-08	Run time of step 3	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-09	Setting of step 4	Ones place: FREQ reference 0: Multi-step FREQ 4 (F1-06) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-10	Run time of step 4	0.0s(min)~6000.0s(min)	0.0s	Δ
	Setting of step 5	Ones place: FREQ reference 0: Multi-step FREQ 5 (F1-07) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-12	Run time of step 5	0.0s(min)~6000.0s(min)	0.0s	Δ
	Setting of step 6	Ones place: FREQ reference 0: Multi-step FREQ 6 (F1-08) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-14	Run time of step 6	0.0s(min)~6000.0s(min)	0.0s	Δ

	T			
F2-15	Setting of step 7	Ones place: FREQ reference 0: Multi-step FREQ 7 (F1-09) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-16	Run time of step 7	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-17	Setting of step 8	Ones place: FREQ reference 0: Multi-step FREQ 8 (F1-10) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-18	Run time of step 8	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-19	Setting of step 9	Ones place: FREQ reference 0: Multi-step FREQ 9 (F1-11) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: ACC/DEC time option (same as F2-01)	000	×
F2-20	Run time of step 9	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-21	Setting of step 10	Ones place: FREQ reference 0: multi-step FREQ 10 (F1-12) 1~7: same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-22	Run time of step 10	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-23	Setting of step 11	Ones place: FREQ reference 0: Multi-step FREQ 11 (F1-13) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-24	Run time of step 11	0.0s(min)~6000.0s(min)	0.0s	Δ

F2-25	Setting of step 12	Ones place: FREQ reference 0: Multi-step FREQ 12 (F1-14) 1~7: Same as F2-01 Tens place: run direction (same as F2-01)	000	×
		Hundreds place: Accel/Decel time option (same as F2-01)		
F2-26	Run time of step 12	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-27	Setting of step 13	Ones place: FREQ reference 0: Multi-step FREQ 13 (F1-15) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-28	Run time of step 13	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-29	Setting of step 14	Ones place: FREQ reference 0: Multi-step FREQ 14 (F1-16) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-30	Run time of step 14	0.0s(min)~6000.0s(min)	0.0s	Δ
F2-31	Setting of step 15	Ones place: FREQ reference 0: Multi-step FREQ 15 (F1-17) 1~7: Same as F2-01 Tens place: run direction (same as F2-01) Hundreds place: Accel/Decel time option (same as F2-01)	000	×
F2-32	Run time of step 15	0.0s(min)~6000.0s(min)	0.0s	Δ

Param.	Designation	Scope	Factory Default	Attr
	Group F3: Wo	obble Frequency and Fixed Length Coun	t	
F3-00	Wobble FREQ function setting	Wobble FREQ function disabled     Wobble FREQ function enabled	0	×
F3-01	Wobble FREQ run setting	Ones place: started method 0: Automatically 1: Started by terminal Tens place: amplitude control 0: Relative to center FREQ 1: Relative to maximum FREQ Hundreds place: wobble FREQ memorized when stop 0: Memory enabled 1: Memory disabled Thousands place: wobble FREQ memorized on power loss 0: Memory enabled 1: Memory disabled	0000	×
F3-02	Pre-wobble FREQ	0.00Hz~600.00Hz	0.00Hz	Δ
F3-03	Pre-wobble FREQ holding time	0.0s~3600.0s	0.0s	Δ
F3-04	Wobble FREQ amplitude	0.0%~50.0%	0.0%	Δ
F3-05	Hop FREQ	0.0%~50.0% (relative to F3-04)	0.0%	Δ
F3-06	Cycle of wobble FREQ	0.0s~999.9s	0.0s	Δ
F3-07	Triangular wave ramp-up time	0.0%~100.0% (of wobble FREQ cycle)	0.0%	Δ
F3-08	Length unit	0: m 1: 10m	0	Δ
F3-09	Length setting	0~65535	1000	Δ
F3-10	Pulse number per meter	0.1~6553.5	100.0	Δ
F3-11	Action when the length attained	0: Not stop 1: Stop	0	Δ
F3-12	Set count value	1~65535	1000	Δ
F3-13	Designated count value	1~65535	1000	Δ

Param.	Designation	Scope	Factory Default	Attr
	G	roup F4: Position Control		
F4-00	Position control mode	O: Non-position control 1: Zero-speed clamping (FREQ attained valid) 2: Zero-speed clamping (terminal enabled) 5: Pulse train position control	0	×
F4-01	Positioning complete width	0~3000	10	×
F4-02	Positioning complete time	0.000s~40.000s	0.200s	×
F4-03	Position loop gain	0.000~40.000	1.000	Δ
F4-04	Zero-speed clamping start FREQ	0.00Hz~upper limit FREQ	1.00Hz	×
F4-33	Position reference mode	<ul> <li>0: X7/DI pulse input + terminal direction input</li> <li>1: Encoder 1 reference, phase A/B pulse. Phase A that is 90°ahead of phase B corresponds to forward</li> <li>2: Encoder 1 reference, phase A/B pulse. Phase B that is 90°ahead of phase A corresponds to forward</li> <li>3: Encoder 1 reference, phase A is pulse, phase B is direction (low level forward, high level reverse)</li> <li>4: Encoder 1 reference, phase A is pulse, phase B is direction (high level forward, low level reverse)</li> <li>5: Encoder 2 reference, phase A/B pulse, phase A that is 90°ahead of phase B corresponds to forward</li> <li>6: Encoder 2 reference, phase A/B pulse, phase B that is 90°ahead of phase A corresponds to forward</li> <li>7: Encoder 2 reference, phase A is pulse, phase B is direction (low level forward, high level reverse)</li> <li>8: Encoder 2 reference, phase A is pulse, phase B is direction (high level forward, low level reverse)</li> </ul>	0	×
F4-34	Numerator of electronic gear ratio	1~30000	1000	Δ

Param.	Designation	Scope	Factory Default	Attr
F4-35	Denominator of electronic gear ratio	1~30000	1000	Δ
F4-36	Feed-forward gain	0.000~7.000	1.000	Δ
F4-37	Feed-forward filtering time	0.000s~7.000s	0.001s	Δ
F4-38	Position offset change rate	0~9999	800	×
F4-39	Electronic gear change rate	0~9999	1000	Δ
F4-40	Output amplitude limit of position-loop	0.0%~100.0%	10.0%	×
F4-41	Position control optimization	Ones place: Pulse error counter reset option 0: Reset when stop 1: Kept when stop Tens place: Reserved Hundreds place: Reserved Thousands place: Reserved	0000	×
	P Grou	up H Communication Parameters		
	Group H0:	MODBUS Communication Parameters		
H0-00	SCI port selection	0: Local 485 port 1: Optional 232 port	0	×
H0-01	SCI port communication configuration	Ones place: baud rate 0: 4800bps 1: 9600bps 2: 19200bps 3: 38400bps 4: 57600bps 5: 115200bps Tens place: data format 0: 1-8-2-N format, RTU 1: 1-8-1-E format, RTU 2: 1-8-1-O Format, RTU 3: 1-7-2-N format, ASCII 4: 1-7-1-E format, ASCII 4: 1-7-1-O format, ASCII Hundreds place: connection type 0: Direct cable connection (232/485) 1: MODEM (232) Thousands place: communication data handling at power loss	0001	×

Param.	Designation	Scope	Factory Default	Attr
		Not saved at power loss     Saved at power loss		
H0-02	Local address of SCI port communication	0~247, 0 is broadcast address	1	×
H0-03	Time out detection of SCI port communication	0.0s~1000.0s	0.0s	×
H0-04	Time delay of SCI port communication	0ms~1000ms	0ms	×
H0-05	Master/Slave option	0: PC controls this drive 1: As master 2: As slave	0	×
H0-06	Parameter store address when this drive working as master	0: b0-02 1: F0-01	0	×
H0-07	Proportional factor of received FREQ	0.0~1000.0	100.0	Δ
	Group H1: P	rofibus-DP Communication Parameters		
H1-00	Local address	1~126; 127 is broadcast address	4	Δ
H1-01	PPO type	0: Profibus disabled 1: PPO1 2: PPO2 3: PPO3 4: PPO4 5: PPO5	0	Δ
H1-02	PZD2_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-03	PZD3_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-04	PZD4_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-05	PZD5_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-06	PZD6_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-07	PZD7_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ

Param.	Designation	Scope	Factory Default	Attr
H1-08	PZD8_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-09	PZD9_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-10	PZD10_OUT (master → slave)	0: none 0x6200~0x6214	0	Δ
H1-11	PZD2_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-12	PZD3_IN (slave → master)	0: none A0-00~U2-xx; 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-13	PZD4_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-14	PZD5_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-15	PZD6_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-16	PZD7_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-17	PZD8_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-18	PZD9_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-19	PZD10_IN (slave → master)	0: none A0-00~U2-xx 0x6200~0x6214; 0x6300~0x6323	0	Δ
H1-20	Operation at bus fault	0: No action 1: Stop	0	Δ

Param.	Designation	Scope	Factory Default	Attr
	Group L	Keys and Display of Control panel		
	Gı	oup L0: Keys of Control panel		
		0: No function		
		1: Forward jog		
		2: Reverse jog		
L0-00	MF key setting	3: Forward/reverse switchover	0	Δ
LU-00	wir key setting	4: Emergency stop 1 (set Decel time by	U	
		b2-09)		
		5: Emergency stop 2 (coast to stop)		
		6: Run command sources shifted		
		0: Not locked		
		1: All locked		
L0-01	Keys locked option	2: Keys locked except RUN,	0	Δ
L0-01	rteys locked option	STOP/RESET		
		3: Keys locked except STOP/RESET		
		4: Keys locked except >>		
		0: STOP key active only at control		
L0-02	Function of STOP key	panel control	0	Δ
L0 02		1: STOP key deactivated under any run		
		command source		
		Ones place: option on stop		
		0: Clear at stop		
		1: Holding at stop		
		Tens place: option on power loss		
		0: Clear at power loss		
L0-03	FREQ adjustment	1: Holding at power loss	0100	Δ
20 00	through keys ^/v	Hundreds place: integrating option	0100	
		0: Integrating disabled		
		1: Integrating enabled		
		Thousands place: run direction		
		0: Direction changing prohibited		
		1: Direction changing permitted		
	Step size of FREQ			
L0-04	adjustment through keys	0.00Hz/s~10.00Hz/s	0.03 Hz/s	Δ
	^/∨			

Param.	Designation	Scope	Factory Default	Attr
	Group	L1: Control Panel Display Setting		
L1-00	Display parameter setting 1 on run status	Binary system setting:  0: No Display  1: Display  Ones place: BIT0: Run FREQ (Hz) BIT1: FREQ reference (Hz) BIT2: Bus voltage (V) BIT3: Output current (A) Tens place: BIT0: Output torque (%) BIT1: Output power (kW) BIT2: Output voltage (V) BIT3: Motor speed (r/min) Hundreds place: BIT0: Al1 (V) BIT1: Al2 (V) BIT3: Output sync FREQ (Hz) Thousands place: BIT0: DI BIT1: External count value BIT2: Reserved BIT3: Reserved Note: when this parameter is set to 0000, run FREQ (Hz) would be displayed as default	080F	Δ
L1-01	Display parameter setting 2 on run status	Binary system setting:  0: No Display  1: Display  Ones place: BIT0: Run linear speed (m/s) BIT1: Set linear speed (m/s) BIT2: Input terminal status BIT3: Output terminal status Tens place: BIT0: PID reference (%) BIT1: PID feedback (%) BIT2: Set length (m) BIT3: Actual length (m) Hundreds place: BIT0: Torque reference (%)	0000	Δ

Param.	Designation	Scope	Factory Default	Attr
L1-02	Display parameter setting on stop status	BIT1: Reserved BIT2: Reserved BIT3: Reserved Thousands place: reserved Binary system setting: 0: No Display 1: Display Ones place: BIT0: FREQ reference (Hz) BIT1: Bus voltage (V) BIT2: Input terminal status BIT3: Output terminal status Tens place: BIT0: Al1 (V) BIT1: Al2 (V) BIT2: Al3 BIT3: Reserved Hundreds place: BIT0: PID reference (%) BIT1: PID feedback (%) BIT2: Set length (m) BIT3: Actual length (m) Thousands place: BIT0: Run linear speed (m/s) BIT1: Set linear speed (m/s) BIT2: External count value BIT3: DI Note: when this function code is set to	Default 0003	Δ
L1-03	Linear speed coeff	displayed as default (Hz) 0.1%~999.9%	100.0%	Δ
	'	Group U Monitoring		
	(	Group U0: Status Monitoring		
U0-00	Run frequency	0.00Hz~600.00Hz	0.00Hz	0
U0-01	Set frequency	0.00Hz~600.00Hz	0.00Hz	0
U0-02	Bus voltage	0V~65535V	0V	0
U0-03	Output voltage	0V~65535V	0V	0
U0-04	Output current	0.0A~6553.5A	0.0A	0
U0-05	Output torque	-300.0%~300.0%	0.0%	0
U0-06	Output power	0.0%~300.0%	0.0%	0

Param.	Designation	Scope	Factory Default	Attr
U0-07	Master FREQ reference	0: Digital setting + adjustment through  ^/v on control panel 1: Digital setting + terminal UP/DOWN  adjustment 2: Analog input Al1 3: Analog input Al2 4: Analog input Al3 5: X7/DI pulse input 6: Process PID output 7: PLC 8: Multi-step FREQ 9: Communication 10: Orthogonal pulse input A+/A-,  B+/B- 11: Pulse input A+/A- + terminal  direction input	0	0
U0-08	source	0: No set 1: Digital setting + adjustment through  ^/∨ on control panel 2: Digital setting + terminal UP/DOWN adjustment 3: Analog input Al1 4: Analog input Al2 5: Analog input Al3 6: X7/DI pulse input 7: Process PID output 8: PLC 9: Multi-step FREQ 10: Communication	0	0
U0-09	Master FREQ reference	0.00Hz~600.00Hz	0.00Hz	0
U0-10	Auxiliary FREQ reference	0.00Hz~600.00Hz	0.00Hz	0
U0-11	Drive status	Ones place: run status 0: Accelerating 1: Decelerating 2: Constant speed running Tens place: drive status 0: Stop 1: Running 2: Autotune Hundreds place: 0: Speed control 1: Torque control	000	0

Param.	Designation	Scope	Factory Default	Attr
		2: Position control		
U0-12	AI1 input voltage	0.00V~10.00V	0.00V	0
U0-13	AI2 input voltage	0.00V~10.00V	0.00V	0
U0-14	AI3 input voltage	-10.00V~10.00V	0.00V	0
U0-15	AO1 output	0.0%~100.0%	0.0%	0
U0-16	AO2 output	0.0%~100.0%	0.0%	0
U0-17	X7/DI HF pulse FREQ	0.0kHz~100.0kHz	0.0kHz	0
U0-18	Digital input terminal status	00~7F	00	0
U0-19	Digital output terminal status	0~7	0	0
U0-20	PID set	0.0%~100.0%	0.0%	0
U0-21	PID feedback	0.0%~100.0%	0.0%	0
U0-22	PID input offset	-100.0%~100.0%	0.0%	0
U0-23	PLC step	0~15	0	0
U0-26	Encoder feedback pulse FREQ	-300.00kHz~300.00kHz	0.00kHz	0
U0-27	Position reference pulse FREQ	-300.00kHz~300.00kHz	0.00kHz	0
U0-28	Encoder 2 (optional) resolution	0~65535	0	0
U0-29	Torque reference value	0.0%~300.0%	0.0%	0
U0-30	Cumulative power-up time	0h~65535h	0h	0
U0-31	Cumulative run time	0h~65535h	0h	0
U0-32	Heat sink temperature 1	-40.0°C~100.0°C	0.0℃	0
U0-33	Heat sink temperature 2	-40.0°C~100.0°C	0.0℃	0
U0-34	FAL fault source	0: No fault 1: IGBT overcurrent 2: Reserved 3: Output grounding fault 4: Output overcurrent 5: DC bus overvoltage 6: Other sources	0	0
U0-35	Terminal count value	0~65535	0	0
U0-36	Run command log at LoU	0~1	0	0
U0-37	Fault code log at LoU	0~100	0	0
U0-38	Main circulation execution time	0.0~6553.5	0.0	0

Param.	Designation	Scope	Factory Default	Attr
U0-39	CtC fault source	O: No fault 1: U-phase current detection circuit fault 2: V-phase current detection circuit fault 3: W-phase current detection circuit fault	0	•
U0-40	Higher-bit numbers of actual length	0~65	0	0
U0-41	Lower-bit numbers of actual length	0~65535	0	0
U0-42	Higher-bit numbers of control panel ^/v stored value	-1~1	0	0
U0-43	Lower-bit numbers of control panel ^/v stored value	0.00~655.35 Hz	0.00Hz	0
U0-44	Higher-bit numbers of terminal UP/DOWN stored value	-1~1	0	0
U0-45	Lower-bit numbers of terminal UP/DOWN stored value	0.00~655.35 Hz	0.00Hz	0
U0-46	Position control pulse error	-9999~+9999	0	0
U0-52	Center FREQ of wobble FREQ	0Hz~600.00Hz	0.00 Hz	0
U0-53	Sync motor rotor angle	0~65535	0	0
U0-54	Encoder feedback FREQ	0.00Hz~600.00Hz	0.00 Hz	0
U0-55	Position reference feed- forward FREQ	0.00Hz~600.00Hz	0.00 Hz	0
U0-56	Sin gain	0~65535	0	0
U0-57	Sin offset	0~65535	0	0
U0-58	Cos gain	0~65535	0	0
U0-59	Cos offset	0~65535	0	0
U0-60	Rotator angle	0~65535	0	0

Group U1: History Fault  0: No fault 1: Accel overcurrent (oC1) 2: Constant-speed overcurrent (oC2) 3: Decel overcurrent (oC3) 4: Accel overvoltage (ov1) 5: Constant-speed overvoltage (ov2) 6: Decel overvoltage (ov3) 7: Module protection (FAL) 8: Autotune failed (tUN) 9: Drive overloaded (oL1) 10: Motor overloaded (oL2) 11: Current detection circuit failed (CtC) 12: Output ground short-circuit protection (GdP) 13: Input power supply fault (ISF) 14: Output phase loss (oPL) 15: Inverter module overloaded (oL3) 16: Module overheated (OH1) 17: Motor overheated (PTC) (OH2)	Param.	Designation	Scope	Factory Default	Attr
1: Accel overcurrent (oC1) 2: Constant-speed overcurrent (oC2) 3: Decel overcurrent (oC3) 4: Accel overvoltage (ov1) 5: Constant-speed overvoltage (ov2) 6: Decel overvoltage (ov3) 7: Module protection (FAL) 8: Autotune failed (tUN) 9: Drive overloaded (oL1) 10: Motor overloaded (oL2) 11: Current detection circuit failed (CtC) 12: Output ground short-circuit protection (GdP) 13: Input power supply fault (ISF) 14: Output phase loss (oPL) 15: Inverter module overloaded (oL3) 16: Module overheated (OH1) 17: Motor overheated (PTC) (OH2)			Group U1: History Fault		
18: PIM temperature measurement circuit fault (oH3) 19: Encoder disconnection (CLL) 20: Option board 1 connection abnormal (EC1) 21: Option board 2 connection abnormal (EC2) 22: Control board flat cable connection abnormal (dCL) 23: Function conflict between analog terminals (Ter) 24: External equipment malfunction (Per) 25: Reserved 26: Continuous run time attained (to2) 27: Accumulative run time attained (to3) 28: Abnormal power supply at run (SUE) 29: EEPROM read/write fault (Epr) 30: Abnormal contactor (CCL)	U1-00	History fault 1 (latest)	0: No fault 1: Accel overcurrent (oC1) 2: Constant-speed overcurrent (oC2) 3: Decel overcurrent (oC3) 4: Accel overvoltage (ov1) 5: Constant-speed overvoltage (ov2) 6: Decel overvoltage (ov3) 7: Module protection (FAL) 8: Autotune failed (tUN) 9: Drive overloaded (oL1) 10: Motor overloaded (oL2) 11: Current detection circuit failed (CtC) 12: Output ground short-circuit protection (GdP) 13: Input power supply fault (ISF) 14: Output phase loss (oPL) 15: Inverter module overloaded (oL3) 16: Module overheated (PTC) (oH2) 18: PIM temperature measurement circuit fault (oH3) 19: Encoder disconnection (CLL) 20: Option board 1 connection abnormal (EC1) 21: Option board 2 connection abnormal (EC2) 22: Control board flat cable connection abnormal (dCL) 23: Function conflict between analog terminals (Ter) 24: External equipment malfunction (Per) 25: Reserved 26: Continuous run time attained (to2) 27: Accumulative run time attained (to3) 28: Abnormal power supply at run (SUE) 29: EEPROM read/write fault (Epr)	0	

Param.	Designation	Scope	Factory Default	Attr
		32: Control panel communication abnormal (PdC) 33: Parameter copy fault (Cpy) 34: Reserved 35: Software version compatibility fault (SFt) 36: CPU interference as a fault (CPU) 37: Overcurrent benchmark error (oCr) 38: 5V power supply out-of-limit (SP1) 39: 10V power supply out-of-limit (SP2) 40: Al input out-of-limit (AIP) 41: Undervoltage protection (LoU) 42: Over-speed fault (oSP) 43: Excessive speed deviation (SPL) 44: Reserved 45: PID feedback loss (Plo) 46: Profibus commu. Abnormal (PFS)		
U1-01	Run FREQ at fault 1	0.00Hz~600.00Hz	0.00Hz	0
U1-02	Output current at fault 1	0.0A~6553.5A	0.0A	0
U1-03	Bus voltage at fault 1	0V~1000V	0V	0
U1-04	Temperature 1 of heat sink at fault 1	-40.0°C~100.0°C	0.0°C	0
U1-05	Temperature 2 of heat sink at fault 1	-40.0℃~100.0℃	0.0℃	0
U1-06	Input terminal status at fault 1	0000~FFFF	0000	0
U1-07	Output terminal status at fault 1	0000~FFFF	0000	0
U1-08	Cumulative run time at fault 1	0h~65535h	0h	0
U1-09	Code of fault 2	Same as U1-00	0	0
U1-10	Run FREQ at fault 2	0.00Hz~600.00Hz	0.00Hz	0
U1-11	Output current at fault 2	0.0A~6553.5A	0.0A	0
U1-12	Bus voltage w at fault 2	0V~1000V	0V	0
U1-13	Temperature 1 of heat sink at fault 2	-40.0°C~100.0°C	0.0℃	0
U1-14	Temperature 2 of heat sink at fault 2	-40.0°C~100.0°C	0.0℃	0
U1-15	Input terminal status at fault 2	0000~FFFF	0000	0

Param.	Designation	Scope	Factory Default	Attr
U1-16	Output terminal status at fault 2	0000~FFFF	0000	0
U1-17	Cumulative run time at fault 2	0h~65535h	0h	0
U1-18	Code of fault 3	Same as U1-00	0	0
U1-19	Run FREQ at fault 3	0.00Hz~600.00Hz	0.00Hz	0
U1-20	Output current at fault 3	0.0A~6553.5A	0.0A	0
U1-21	Bus voltage w at fault 3	0V~1000V	0V	0
U1-22	Temperature 1 of heat sink at fault 3	-40.0°C~100.0°C	0.0℃	0
U1-23	Temperature 2 of heat sink at fault 3	-40.0°C~100.0°C	0.0℃	0
U1-24	Input terminal status at fault 3	0000~FFFF	0000	0
U1-25	Output terminal status at fault 3	0000~FFFF	0000	0
U1-26	Cumulative run time at fault 3	0h~65535h	0h	0

# **Chapter 6 Specification of Parameters**

## **Group A** System Parameters and Parameter Management

## Group A0 System Parameters

A0-00	Setting of user password	Range: 0000~FFFF	Factory default:
	9	3	0000

## Setting of password:

A non-zero four-digital number could be set as a user password by entering this password into A0-00 and pressing ENT key to confirm once, then reenter and reconfirm it once again within 10 seconds. Once this password has been successfully set, the word "P-Set" would be displayed. The password setting will take effect as long as there is no operation on control panel within 5 minutes, or cutting the power off and power up again .

### Change password:

Access A0-00 after entering the original four-digit password (at this point, A0-00 displays 0000) and set the new password following the above-noted procedure.

### Password clearance:

Access A0-00 after entering the original four-digit password (at this point, A0-00 displays 0000), enter 0000 twice and press ENT key to make confirmation. In this way, password is successfully cleared and the word "P-CLr" is displayed.

A0-01	Parameter display	Range: 0~3	Factory default: 0	
-------	-------------------	------------	-----------------------	--

This parameter sets the display/hide of parameters.

- 0: Display all parameters (A1-20~A1-21 parameter display/hide is valid)
- 1: Only display parameters A0-00 and A0-01
- 2: Only display A0-00, A0-01 and user-defined A1-00~A1-19
- 3: Only display A0-00, A0-01, and the parameters different with factory default

A0-02	Parameter protection	Danger 0: 1	Factory default:
AU-02	Parameter protection	Range: 0~1	0

- 0: All parameter programming allowed
- 1: Only A0-00 and this parameter programming allowed

When this parameter is set to 1, all parameters other than A0-00 and A0-02 are not allowed to modify. Set A0-02 to 0 before the modification of other parameters.

A0-03	Parameter initialization	Range: 0~4	Factory default: 0
-------	--------------------------	------------	-----------------------

- 0: No operation
- 1: Clear fault record

When this parameter is set to 1, all fault record of Group U1 will be cleared.

- 2: Restore all parameters to factory default (excluding motor parameters)
- 3: Restore all parameters to factory default (including motor parameters)
- 4: Restore all parameters to backup parameters

A0-04	Parameter backup	Range: 0~1	Factory default: 0
-------	------------------	------------	-----------------------

- 0: No operation
- 1: Backup all parameters

A0-05	Parameter copy	Range: 0~3	Factory default:
7.0 00	r drameter copy	runge. e e	0

- 0: No operation
- 1: Upload all parameters other than Group U to control panel
- 2: Download all parameters of control panel other than d0-01~d0-18 and d3-01~d3-18 to drive
- 3: Download all parameters of control panel to drive

A0-07	Power supply type of SMPS	Range: 0~1	Factory default: 0
-------	---------------------------	------------	-----------------------

0: Supplied by DC bus voltage of drive main circuit

The switching power supply inside the drive is supplied by DC bus voltage.

1: Supplied independently

The switching power supply inside the drive is not supplied by DC bus voltage, while it is supplied by independent rectifier circuit or battery, and in such circumstance, option board EPC-VD2 is required for detecting the DC bus voltage of main circuit. This setting is usually for occasions that the work of drive control circuit cannot be stopped at power loss.

A0-08	Motor 1 / motor 2	Range: 0~1	Factory default:
AU-00	selection	Kange. 0~1	0

### 0. Motor 1

Select the current loaded motor as motor 1. Set the parameters of motor 1 in parameter groups d0~d2.

1: Motor 2

Select the current loaded motor as motor 2. Set the parameters of motor 2 in parameter groups d3~d5. The current loaded motor can also be selected through digital input terminal "motor 1/2 switchover" as shown in Table 6-1:

Table 6-1

A0-08	Motor 1/2 switchover terminal	Motor selection
0	OFF	Motor 1
0	ON	Motor 2
1	OFF	Motor 2
1	ON	Motor 1

A0-09	Motor control technique	Range: 00~33	Factory default: 00
-------	-------------------------	--------------	---------------------

## Ones place: motor 1 control technique

### 0: V/f control

Constant Volt/Hertz ratio control: Applicable to such cases in which the performance requirement to the drive is not rigorous, or using one drive to drive several motors, or it is difficult to identify motor parameters correctly, etc. When motor 1 under V/f control is selected, need to set related parameters group d1 well.

### 1: Sensor-less vector control 1

This helps achieve high-performance control without encoder and provides strong adaptability of load. Under this selection, please correctly set motor parameters of Group d0 and vector control parameters of Group d2. Sensor-less vector control 1 is robust vector control. If motor rotary tune is not able to be performed or permitted, sensor-less vector control 1 performance would be relatively ideal than sensor-less vector control 2.

### 2: Sensor-less vector control 2

This helps achieve high-performance control without encoder. This control technique is superior to sensor-less vector control 1. Under this selection, please correctly set motor parameters of Group d0 and vector control parameters of Group d2. Sensor-less vector control 2 is precise vector control and it requires motor rotary tune.

### 3: Closed-loop vector control

Closed-loop vector control and realize high-precise speed control, torque control, torque constraint, and simple servo drive functions, etc. When this control pattern is selected, please install PG (optical-electricity encoder or rotating transformer). Also PG parameters should be set well, in d6 group. In order to get an ideal performance, group d0 and d2 also need to set well.

## ◆ Tens place: motor 2 control technique

#### 0: V/f control

Constant Volt/Hertz ratio control: Applicable to such cases in which the performance requirement to the drive is not rigorous, or using one drive to drive several motors, or it is difficult to identify motor parameters correctly, etc. When motor 1 under V/f control is selected,

need to set related parameters group d1 well.

### 1: Sensor-less vector control 1

This helps achieve high-performance control without encoder and provides strong adaptability of load. Under this selection, please correctly set motor parameters of Group d0 and vector control parameters of Group d2. Sensor-less vector control 1 is robust vector control. If motor rotary tune is not able to be performed or permitted, sensor-less vector control 1 performance would be relatively ideal than sensor-less vector control 2.

### 2: Sensor-less vector control 2

This helps achieve high-performance control without encoder. This control technique is superior to sensor-less vector control 1. Under this selection, please correctly set motor parameters of Group d0 and vector control parameters of Group d2. Sensor-less vector control 2 is precise vector control and it requires motor rotary tune.

## 3: Closed-loop vector control

Closed-loop vector control and realize high-precise speed control, torque control, torque constraint, and simple servo drive functions, etc. When this control pattern is selected, please install PG (optical-electricity encoder or rotating transformer). Also PG parameters should be set well, in d6 group. In order to get an ideal performance, group d0 and d2 also need to set well.

### ATTENTION:

When vector control mode is selected, it is necessary to perform motor tune in order to obtain correct motor parameters before initial running. Upon the completion of normal process of motor tune, automatically acquired motor parameters will be stored into drive for control operation during running.

It should be noted when vector control is selected that one drive can only be used to drive one motor. The capacity gap between the drive and the motor should not be excessively big. Added to this, the power of motor could be two classes lower or one class higher than its matching drive. Failure to comply will be most likely to result in performance degradation or abnormal working.

## **Group A1 User-defined Display Parameters**

A1-00	User-defined displayed parameter 1	Range: A0-00~U1-26	Factory default:
A1-01	User-defined displayed parameter 2	Range: A0-00~U1-26	Factory default: A0-00
A1-02	User-defined displayed parameter 3	Range: A0-00~U1-26	Factory default: A0-00
A1-03	User-defined displayed parameter 4	Range: A0-00~U1-26	Factory default: A0-00
A1-04	User-defined displayed parameter 5	Range: A0-00~U1-26	Factory default: A0-00
A1-05	User-defined displayed parameter 6	Range: A0-00~U1-26	Factory default: A0-00
A1-06	User-defined displayed parameter 7	Range: A0-00~U1-26	Factory default: A0-00
A1-07	User-defined displayed parameter 8	Range: A0-00~U1-26	Factory default: A0-00
A1-08	User-defined displayed parameter 9	Range: A0-00~U1-26	Factory default: A0-00
A1-09	User-defined displayed parameter 10	Range: A0-00~U1-26	Factory default: A0-00
A1-10	User-defined displayed parameter 11	Range: A0-00~U1-26	Factory default: A0-00
A1-11	User-defined displayed parameter 12	Range: A0-00~U1-26	Factory default: A0-00
A1-12	User-defined displayed parameter 13	Range: A0-00~U1-26	Factory default: A0-00
A1-13	User-defined displayed parameter 14	Range: A0-00~U1-26	Factory default: A0-00
A1-14	User-defined displayed parameter 15	Range: A0-00~U1-26	Factory default: A0-00
A1-15	User-defined displayed parameter 16	Range: A0-00~U1-26	Factory default: A0-00
A1-16	User-defined displayed parameter 17	Range: A0-00~U1-26	Factory default: A0-00
A1-17	User-defined displayed parameter 18	Range: A0-00~U1-26	Factory default: A0-00

A1-18	User-defined displayed parameter 19	Range: A0-00~U1-26	Factory default: A0-00
A1-19	User-defined displayed parameter 20	Range: A0-00~U1-26	Factory default: A0-00

A1-00~A1-19 set values would not take effect unless A0-01 is set to 2

Setting range of thousands place: A, b, C, d, E, F, H, L, U

Setting range of hundreds place: 0~9;

Setting range of tens place: 0~9; Setting range of ones place: 0~9.

## Example:

To exclusively display parameters A0-00, A0-01, b0-01, E0-01 and F0-01, it is merely necessary to set A1-00 to b0-01, A1-01 to E0-01, A1-02 to F0-01 and A1-03 $\sim$ A1-19 to A0-00 and then set A0-01 to 2.

A1-20	Parameter group display /hide setting 1	Range: 0000~FFFF	Factory default: FFFF
A1-21	Parameter group display /hide setting 2	Range: 0000~FFFF	Factory default: FFFF

When A0-01 is set to '0' to display all parameters, only the parameters whose bit corresponding to A1-20 and A1-21 is 1 can be displayed.

The parameters that correspond to bit 15 (the highest bit of binary system)  $\sim$  bit 0 (the lowest bit of binary system) of A1-20 are shown as table 6-2.

Table 6-2

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8
E0	d6	d5	d4	d3	d2	d1	d0
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
C4	C3	C2	C1	C0	b2	b1	b0

The parameters that correspond to bit 15 (the highest bit of binary system)  $\sim$  bit 0 (the lowest bit of binary system) of A1-21 are shown as table 6-3:

## Table 6-3

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8
U2	U1	U0	L1	L0	H2	H1	H0
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
F6	F5	F4	F3	F2	F1	F0	E1

## **ATTENTION:**

Parameters of Groups A0 and A1 are always displayed and are not subject to A1-20 and A1-21 show/hide control.

## Example:

Besides parameter Groups A0 and A1, the groups b0, b1, b2, C0, C1, C2, C3, d0, d1 and E1 are also requested to display, just set:

A1-20 to 037F (A1-20 is 0000 0011 0111 1111 in binary) A1-21 to 0001 (A1-21 is 0000 0000 0000 0001 in binary)

A1-22	Fault masking	Range: 00~FF	Factory default: 08
-------	---------------	--------------	---------------------

0∼FF

Ones place: binary Bit3Bit2Bit1Bit0

Set Bit place to 0 is to unmask, while set it to 1 is to mask Bit0: GdP fault, Bit1: SP1 fault, Bit2: SP2 fault, Bit3: CPU fault

Tens place: binary Bit3Bit2Bit1Bit0

Set Bit place to 0 is to unmask, while set it to 1 is to mask Bit0: AIP fault, Bit1: OL3 fault, Bit2: oCR fault, Bit3: reserved


## **ATTENTION:**

For example: if GdP, SP1, SP2, and CPU faults need to be masked, then set ones place as hexadecimal F (set binary Bit3Bit2Bit1Bit0 to 1), meaning of tens place is similar.

## Group b Run Parameter Setting.

## Group b0 Frequency reference

Frequency reference is set by parameter Group b0. See Fig. 6-1 for logical relation of frequency reference.



b0-00	FREQ reference mode	Range: 0~4	Factory default:
50-00	TIVE & Telefelice filode	range. 0 4	0

## 0: Master frequency reference

Output frequency of drive is determined by master frequency reference source b0-01. Refer to parameters b0-01 and b0-02 for further information.

- 1: Master & auxiliary computation result
  - Frequency reference is the result of master & auxiliary computation. The master & auxiliary computation relation is determined by b0-07. Master frequency is set by b0-01, while auxiliary is set by b0-03.
- 2: Switch between master and auxiliary frequency reference When b0-00 is set to 2, the switch between master frequency reference, and master & auxiliary computation result can be realized through digital input terminal "frequency reference switchover". When terminal "frequency reference switchover" is disabled, frequency reference of the drive will be determined by b0-01. When terminal "frequency reference switchover" is enabled, frequency reference of the drive will be determined by b0-03 (Auxiliary FREQ reference source).
- 3: Switch between master frequency reference, and master & auxiliary computation result When b0-00 is set to 3, frequency reference is determined by master frequency reference, or master & auxiliary computation result through digital input terminal "frequency reference switchover". When terminal "frequency reference switchover" is disabled, frequency reference is determined by b0-01 (master frequency reference source). When terminal "frequency reference switchover" is enabled, frequency reference is determined by master & auxiliary computation result. The master & auxiliary computation relation is determined by b0-07.
- 4: Switch between auxiliary frequency reference, and master & auxiliary computation result When b0-00 is set to 4, frequency reference is determined by auxiliary frequency reference, or master & auxiliary computation result through digital input terminal "frequency reference switchover". When terminal "frequency reference switchover" is disabled, frequency reference is determined by b0-03 (auxiliary FREQ reference source). When terminal "frequency reference switchover" is enabled, frequency reference is determined by master & auxiliary computation result. The master & auxiliary computation relation is determined by b0-07.

b0-01	Master FREQ reference	Range: 0~9	Factory default:
	source		0

## 0: Digital setting (b0-02) + control panel $\land / \lor$ adjustment

When the drive is powered up, the value of b0-02 is taken as the master frequency reference which can be adjusted through A/V keys on control panel no matter the drive is running or in stop.

### ATTENTION:

Frequency adjustment via ^/v on control panel can be cleared through terminal "Clear UP/DOWN (including ^/v key) adjustment". Refer to C0-01~C0-10 for details.

### 1: Digital setting (b0-02) + terminal UP/DOWN adjustment

When the drive is powered up, the value of b0-02 is taken as the master frequency reference. This frequency can be adjusted via "terminal UP" and "terminal DOWN" no matter the drive is running or in stop.

When this parameter value is selected, following parameter setting should be performed:

- Set the two digital input terminals to "terminal UP" and "terminal DOWN" respectively. Refer to C0-01~C0-10 for further information.
- 2) Set terminal UP/DOWN frequency change step size (C0-18).
- 3) Set C0-17 (Terminal UP/DOWN frequency adjustment action).

### **ATTENTION:**

Frequency adjustment via terminal UP and DOWN can be cleared through terminal "Clear UP/DOWN (including ^/v key) adjustment". Refer to C0-01~C0-10 for details.

### 2: Analog input AI1

## 3: Analog input Al2

Al1 and Al2 are (0~10V) voltage input and (0~20mA) current input programmable. Voltage or current input can be selected through jumper switches S2 and S3 on control board. S4 should be used with S3, to select Al2 channel for normal analog input or motor temperature detection. When S3 and S4 are selected and shown as Figure 6-2, it's the normal analog voltage input. When S3 is jumped to "V" and S4 is jumped to "TMP", it's motor temperature input.



Fia. 6-2

Refer to specification of C2-00~C2-20 for corresponding relation between analog input and output frequency. See parameter Group C4 for automatic correction of analog input.

### 4: Analog input AI3

Al3 input is the -10V~+10V voltage input, and the positive and negative voltages determine the direction of the frequency reference.

Refer to detailed description of C2-00~C2-20 for corresponding relation between analog input

and output frequency. See parameter group C4 for automatic correction of analog input. When using external voltage/current analog input to the drive, the connection diagram is shown as Fig. 6-3:





Fig. 6-3

If 10V power supply inside the drive is used with potentiometer, the connection diagram is shown as Fig. 6-4. Note that the jumper switches should be jumped to voltage input side.



Fia. 6-4

## 5: X7/DI pulse input

If this parameter value selected, frequency reference will be determined by pulse frequency input via terminal X7/DI only. In such a case, C0-07 should be set to 24. Corresponding relation between pulse frequency and frequency reference is specified in C2-24~C2-27.

## 6: Process PID output

Frequency reference is determined by process closed-loop PID computation result. See parameter Group F0 for details.

## 7: PLC

Frequency reference is determined by simple PLC. See parameter Group F2 for details.

### 8: Multi-step speed

A total of 16-step speed settings can be realized through status combination of "Multi-step frequency terminal 1~4". See the table below for details. Set frequency can be switched via different combination of Multi-step frequency terminals no matter in running or in stop.

Table 6-4

Multi-step frequency terminal 4	Multi-step frequency terminal 3	Multi-step frequency terminal 2	Multi-step frequency terminal 1	Set frequency
OFF	OFF	OFF	OFF	Multi-step FREQ 0 (F1-00)
OFF	OFF	OFF	ON	Multi-step FREQ 1 (F1-01)
OFF	OFF	ON	OFF	Multi-step FREQ 2 (F1-04)
OFF	OFF	ON	ON	Multi-step FREQ 3 (F1-05)
OFF	ON	OFF	OFF	Multi-step FREQ 4 (F1-06)
OFF	ON	OFF	ON	Multi-step FREQ 5 (F1-07)
OFF	ON	ON	OFF	Multi-step FREQ 6 (F1-08)
OFF	ON	ON	ON	Multi-step FREQ 7 (F1-09)
ON	OFF	OFF	OFF	Multi-step FREQ 8 (F1-10)
ON	OFF	OFF	ON	Multi-step FREQ 9 (F1-11)
ON	OFF	ON	OFF	Multi-step FREQ 10 (F1-12)
ON	OFF	ON	ON	Multi-step FREQ 11 (F1-13)
ON	ON	OFF	OFF	Multi-step FREQ 12 (F1-14)
ON	ON	OFF	ON	Multi-step FREQ 13 (F1-15)
ON	ON	ON	OFF	Multi-step FREQ 14 (F1-16)
ON	ON	ON	ON	Multi-step FREQ 15 (F1-17)

### 9. Communication

The host computer/device is the master frequency reference source of the drive through standard RS485 communication interface on the drive.

Refer to Group H0 and appendix on this manual for further information about communication protocol, and programming, etc.

## 10: The orthogonal pulse input A+/A-, B+/B-

When two orthogonal pulse signals are input from the A+/A- and B+/B- terminals of the control board, the frequency reference is determined by the pulse signal frequency, and the maximum pulse frequency can reach 300 kHz. The direction of the motor rotation is determined by the phase of the A and B signals: When phase A leads phase B by 90°, it is running forward, and it's running reverse when phase B is ahead of phase A by 90°, regardless of the run direction command. The input pulse can be 5V or 12V signal. For details, please refer to "3.9.5 Encoder Terminal Instructions".

## 11: Pulse input A+/A- + terminal direction input

The frequency reference is determined by the pulse frequency input from the A+/A- terminals on the control board. The running direction is set by the "pulse frequency direction reference"

terminal of the digital input. When the terminal is disabled, it runs forward, and when the terminal is enabled, it runs reverse.

## ATTENTION:

Master frequency reference can be forcibly switched to b0-02 via terminal "master frequency reference switched to digital setting b0-02". When this terminal is disabled, master frequency reference is determined by b0-01. When terminal is enabled, master frequency reference shall be the value of b0-02.

b0-02	Digital setting of master	Range: lower limit frequency ~	Factory default:
	FREQ reference	upper limit frequency	50.00Hz

When master frequency reference source b0-01 is set to either 0 or 1, this parameter value will be the initial value of master frequency reference.

b0-03	Auxiliary FREQ	Danage 0, 40	Factory default:
	reference source	Range: 0~10	0

#### 0: No command

Auxiliary frequency reference is disabled, and auxiliary frequency is 0.

1: Digital setting (b0-04) + ^/v adjustment on control panel

When the drive is powered up, the value of b0-04 is auxiliary frequency reference, also can be adjusted through A/V on control panel no matter the drive is running or in stop status.

## ATTENTION:

When master frequency reference involves ^/v adjustment on control panel, ^/v involving auxiliary frequency reference shall be disabled.

2: Digital setting (b0-04) + terminal UP/DOWN adjustment

When the drive is powered up, the value of b0-04 is current auxiliary frequency reference. Whether the drive is running or stopped, current auxiliary Frequency reference can be adjusted through digital input terminals "UP" and "DOWN". Just set "terminal UP/DOWN frequency adjustment action" and "terminal UP/DOWN frequency change step size" through C0-17 and C0-18.

## **ATTENTION:**

When master frequency reference involves terminal UP/DOWN adjustment, UP/DOWN adjustment involving auxiliary frequency reference shall be disabled.

- 3: Analog input AI1
- 4: Analog input AI2
- 5: Analog input AI3

Al1 and Al2 can be either (0~10V) voltage input or (0~20mA) current input which can be switched by the jumper switch on control board. Al3 input is -10V~+10V input only, and the

positive and negative voltages determine the direction of the frequency reference.

### ATTENTION:

See b0-05 and b0-06 for information about frequency relation that corresponds to maximum value of analog input of auxiliary frequency reference.

### 6: X7/DI pulse input

Auxiliary frequency reference is determined by pulse frequency via terminal X7/DI only. In such a case, set X7 terminal to "pulse input" (set C0-06 to 24). Refer to C2-24~C2-27 for corresponding relationship between pulse frequency and frequency reference.

### ATTENTION:

See b0-05 and b0-06 for information about frequency relation that corresponds to maximum value of pulse input for auxiliary frequency reference.

## 7: Process PID output.

Auxiliary frequency reference is determined by process PID computation result. See parameter Group F0 for details.

### ATTENTION:

See b0-05 and b0-06 for information about frequency relation that corresponds to maximum value of process PID output for auxiliary frequency reference.

### 8: PLC

Auxiliary frequency reference is determined by simple PLC. See parameter Group F2 for details.

#### 9: Multi-step speed

A total of 16-step speed settings can be realized through status combination of "Multi-step frequency terminal 1~4". Auxiliary frequency reference can be switched via different combination of Multi-step frequency terminals no matter in running or in stop.

### 10: Communication

The host computer/device is the auxiliary frequency reference source of the drive through standard RS485 communication interface on the drive. Refer to Group H0 and appendix on this manual for further information about communication protocol, and programming, etc.

### ATTENTION:

Auxiliary frequency reference can be forcibly switched to b0-04 via terminal "auxiliary frequency reference switched to digital setting b0-04". When this terminal is disabled, auxiliary frequency reference is determined by b0-03. When terminal is enabled, auxiliary frequency reference shall be the value of b0-04.

b0-04	Digital setting of auxiliary FREQ reference	Range: lower limit frequency ~ upper limit frequency	Factory default: 0.00Hz
-------	---------------------------------------------	------------------------------------------------------	----------------------------

When auxiliary frequency reference is set to either 1 or 2, this parameter value should be the initial value of auxiliary frequency reference.

b0-05 Auxiliary FREQ range	Range: 0~1	Factory default: 0
----------------------------	------------	--------------------

- 0: Relative to maximum frequency
- 1: Relative to master frequency

See b0-06 specification for details.

PC 06	Auxilians FRFO coeff	Dongo: 0.00/ - 100.00/	Factory default:
b0-06	Auxiliary FREQ coeff	Range: 0.0%~100.0%	100.0%

When b0-03 selects Al1, Al2, Al3, X7/DI pulse input, or process PID output as auxiliary frequency reference source, b0-05 and b0-06 will determine the final output value of auxiliary frequency reference.

When b0-05 is set to 0 (relative to maximum frequency): When Al1, Al2, Al3, X7/DI pulse input is selected for auxiliary frequency reference, the maximum frequency that corresponds to the maximum value of the source should be (b0-08×b0-06).

## Example:

Select Al1 as auxiliary frequency reference source (set b0-03 to 3) and set Al1 to curve 1 (Ones place of C2-00 is 0) as shown in Fig. 6-5. In such a case, the frequency that corresponds to the curve 1 maximum input should be:  $(C2-02) \times [(b0-08) \times (b0-06)]$ .




Fig. 6-5

When X7/DI pulse input is selected as auxiliary frequency reference (set b0-03 to 6), the frequency that corresponds to maximum DI input should be: (C2-25) × [(b0-08) × (b0-06)].

When PID is selected for auxiliary frequency reference, the frequency that corresponds to maximum value of PID output should be (b0-08) × (b0-06). PID output diagrammatic sketch is as shown in Fig. 6-6.




Fig. 6-6

When b0-05 is set to 1 (relative to master frequency): When Al1, Al2, Al3, or X7/DI pulse input is selected for auxiliary frequency reference source, the frequency that corresponds to maximum value of these sources should be: [master frequency × (b0-06)].

## Example:

When selecting Al1 as auxiliary frequency reference source (set b0-03 to 3) and setting Al1 to curve 1 (Ones place of C2-00 is 0), the frequency that corresponds to curve 1 maximum input should be: (C2-02) × [master frequency × (b0-06)].

When X7/DI pulse input is selected as auxiliary frequency reference source (set b0-03 to 6), the frequency that corresponds to maximum DI input should be: (C2-25) × [master frequency × (b0-06)].

When PID is selected for auxiliary frequency reference, the frequency that corresponds to maximum value of PID output should be [master frequency × (b0-06)]. PID output diagram is as shown in Fig. 6-7.




Fig. 6-7

b0-07	Computation of master and auxiliary FREQ	Range: 0~3	Factory default: 0
-------	------------------------------------------	------------	--------------------

### 0: Master + auxiliary

The sum of master and auxiliary frequency is taken as frequency reference. Output result is subject to limitation of upper and lower limit frequency.

## 1: Master - auxiliary

The difference between master and auxiliary frequency is taken as frequency reference. Output result is subject to limitation of upper and lower limit frequency.

# 2: Max {master, auxiliary}

Master frequency or auxiliary frequency (whichever has a larger absolute value) is taken as frequency reference. Output result is subject to limitation of upper and lower limit frequency.

## 3: Min {master, auxiliary}

Master frequency or auxiliary frequency (whichever has a smaller absolute value) is taken as frequency reference. Output result is subject to limitation of upper and lower limit frequency.

b0-08	Maximum frequency	Range: Upper limit frequency ~600.00Hz	Factory default: 50.00Hz
b0-09	Upper limit frequency	Range: Lower limit frequency ~ maximum frequency	Factory default: 50.00Hz
b0-10	Lower limit frequency	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz

Maximum frequency of b0-08 is the maximum allowable output frequency of drive and is indicated by fmax in the figure.

B0-09 upper limit frequency is the user-defined maximum allowable run frequency and represented by fH in Fig. 6-8.

B0-10 lower limit frequency is user-defined minimum allowable run frequency and marked with fL in Fig. 6-8. In Fig. 6-8, fN represents rated frequency of motor while VN means the rated voltage of motor.




Fig. 6-8

## **ATTENTION:**

- Maximum frequency, upper limit frequency and lower limit frequency should be set with care
  in accordance with nameplate parameters of motor and operation requirements.
- Jog and motor tune is free from limitations of upper and lower limit frequency.
- In addition to limitation of upper limit frequency and lower limit frequency, the output frequency is also subject to limitations of start frequency, stop DC brake initial frequency, skip frequency and other parameter settings.
- The rank relation between maximum frequency, upper limit frequency and lower limit frequency is shown as Fig. 6-8.
- Upper and lower limit frequencies restrict actual output frequency to motor. If frequency
  reference is higher than upper limit frequency, the running would be at upper limit frequency.
  In case frequency reference is lower than lower limit frequency, the running should be in
  accordance with the setting of b0-11.

b0-11	Action when FREQ reference lower	Range: 0~2	Factory default: 0
	than lower limit FREQ		

## 0: Run at lower limit frequency

In case frequency reference is lower than lower limit frequency, the run should be at lower limit frequency.

## 1: Run at 0Hz

In case the frequency reference is lower than lower limit frequency, the run should be at 0Hz.

# 2: Stop

If frequency reference is lower than lower limit frequency, stop would be activated after the time delay set by b0-12. When lower limit frequency is 0, this limitation is invalid.

## ATTENTION:


This parameter is disabled under PID control mode.

b0-12	Time-delay of stop when FREQ reference lower than lower limit frequency	Range: 0.0s~6553.5s	Factory default: 0.0s
-------	-------------------------------------------------------------------------	---------------------	-----------------------

When b0-11 is set to 2, and frequency reference is lower than lower limit frequency, the drive will stop running after this parameter value.

b0-13	Lower limit of skip FREQ band 1	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz
b0-14	Upper limit of skip FREQ band 1	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz
b0-15	Lower limit of skip FREQ band 2	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz
b0-16	Upper limit of skip FREQ band 2	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz
b0-17	Lower limit of skip FREQ band 3	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz
b0-18	Upper limit of skip FREQ band 3	Range: 0.00Hz ~ upper limit frequency	Factory default: 0.00Hz

Skip frequency is a function designed to prevent the drive run at resonance zone of mechanical system. At most 3 skip zones can be defined. See Fig. 6-9.






Fig. 6-9

Once parameters of skip zones are set, the output frequency of the drive would automatically get out of these skip zones even if the frequency reference is within these zones.

### **ATTENTION:**

Output frequency of drive can normally pass through skip zones during Accel and Decel.

	b0-19	log fraguency	Range: 0.00Hz ~ upper limit	Factory default:
l	DU-19	Jog frequency	frequency	5.00Hz

This parameter sets the run frequency during jog. Jog Accel time is set by parameter b2-10 while its Decel time by parameter b2-11. Jog run command control could be performed through control panel, control terminals or communication input. Multifunction MF key can be set as forward jog or reverse jog key through parameter L0-00.

Jog can be realized using "forward jog terminal" and "reverse jog terminal" of DI, as well as via communication input. See drive communication protocol for further information. See Jog diagrammatic sketch 6-10.



Time

Fig. 6-10

#### Thereof:

F1 is jog frequency b0-19. t1 represents the ACC time from zero to jog frequency; t1 = (b2-10)  $\times$  f1/(b0-08); b0-08 is the maximum frequency. t2 is the DEC time from jog frequency to 0; t2 = (b2-11)  $\times$  f1/(b0-08).

## ATTENTION:

Jog frequency set value is free from limitations of upper and lower limit frequency. Jog is started from start frequency and its start is not subject to limitation by b1-05. When the jog frequency is set smaller than start frequency, the drive will run at 0Hz.

# Group b1 Start/Stop Control

b1-00	Run command	Range: 0~2	Factory default: 0
-------	-------------	------------	--------------------

This parameter sets run command source. Run commands include "start, stop, forward and reverse". etc.

## 0: Control panel control

Control run command through RUN, STOP/RESET and MF keys on control panel (set multifunction key MF to JOG by L0-00). Refer to Chapter 4 about the operation of control panel.

#### 1: Terminal control

Control run command via DI terminals. Perform FORWARD and REVERSE by DI terminals. The control mode are two-wire mode and three-wire mode selectable. See Group C0 for details of designation and wiring regulation of DI terminals.

### 2: Communication control

Master device is able to control run command through built-in RS485 serial communication interface of drive. Refer to parameters Group H0 and appendix for further information about programming.

Run command from control panel, terminals and communication can be switched by terminals "run command switched to control panel control", "run command switched to terminal control" and "run command switched to communication control".

Multifunction key MF can be set to "run command sources shifted" key through parameter L0-00. When MF key is pressed under this setting, run command will be shifted during control panel control, terminal control and communication control circularly.

	b1-01	Binding of run command	Danger 000 AAA	Factory default:
l	D1-01	and frequency reference	Range: 000 ~ AAA	000

This parameter defines the bundled combination of three run command sources and frequency reference sources with the purpose of facilitating simultaneous switching. For example: frequency reference source Al1 (ones place of b1-01 is set to 3) bundled with control panel control, while the frequency reference source X7/DI pulse input (ten's place of b1-01 is set to 6) bundled with terminal control. In such a case, when run command is controlled by control panel, frequency reference source would be Al1, while when run command is controlled via terminals, frequency reference source will be automatically switched to X7/DI pulse input.

- ◆ Ones place: frequency reference source bundled under control panel control
- 0: No binding
- 1: Digital setting (b0-02) + ^/v adjustment on control panel
- 2: Digital setting (b0-02) + terminal UP/DOWN adjustment
- 3: Analog input AI1
- 4: Analog input AI2
- 5: Analog input AI3
- 6: X6/DI pulse input
- 7: Process PID output
- 8: Simple PLC
- 9: Multi-step FREQ
- A: Communication input

Refer to parameter b0-01 for details regarding above-mentioned sources of frequency reference.

- ◆ Tens place: frequency reference source bundled under terminal control (same as ones place)
- Hundreds place: frequency reference source bundled under communication control (same as ones place)

## **ATTENTION:**

Different run command sources can be bundled with the same frequency reference source. The priority of frequency reference sources bundled with run command overrides Group b0.

b1-02	Run direction	Range: 0~1	Factory default: 0

This parameter applies to run command controlled by control panel, and disabled under terminal and communication control.

- 0: Forward
- 1: Reverse

b1-03 Reverse disabled	Range: 0~1	Factory default: 0
------------------------	------------	--------------------

- 0: Reverse enabled
- 1: Reverse disabled

In some applications, reverse is likely to result in equipment damage. This parameter is used to prevent reverse running.

b1-04	Dead time between	Dongo: 0.00 - 2600.00	Factory default:
D1-04	forward and reverse	Range: 0.0s ~ 3600.0s	0.0s

The dead time with 0Hz output during the transition from forward to reverse, or from reverse to forward is indicated by letter "t" in Fig. 6-11.




Fig. 6-11 Dead time between forward and reverse

This parameter takes effect during the process of transition from stop status to run status.

### 0: From start frequency

When drive starts to run from stop status, it starts from start frequency (b1-06) and keeps this frequency for a period of time set by b1-07, and then accelerated to frequency reference in accordance with the Accel method and time.

### 1: DC braking start

To make the motor stop completely, the drive will perform DC braking with a certain period of time, as specified by b1-08 and b1-09, then start from start frequency (b1-06), keeping a period of time as specified by b1-07, and then accelerate to frequency reference.

- 2: Flying start 1
- 3: Flying start 2
- 4: Flying start 3

When this parameter is set to 2~4, the drive will detect the motor rotary speed in order to perform a smooth start from the detected rotary speed. This start method is applicable to the restart on momentary power loss, like rotating fan, etc. When this parameter value is set to flying start 1, motor parameters and b1-10~b1-12 needs to be set correctly and appropriately. When it is set to flying start 2, option board EPC-VD2 must be required. When the parameter is set to flying start 3, please correctly set motor parameter of b1-10 ~ b1-12. There is no need of EPC-VD2 board, with high robustness, and insensitive to motor parameter. Flying start 3 has a higher accuracy, which is a more commonly used mode for software speed search.

b1-06	Start frequency	Range: 0.00Hz~upper limit frequency	Factory default: 0.00Hz
b1-07	Holding time of start frequency	Range: 0.0s~3600.0s	Factory default: 0.0s

Start frequency is initial output frequency of drive start from stop status. Start frequency holding time is the continuous run time with start frequency. After this holding time, the drive will accelerate to set frequency. Usually appropriate start frequency and holding time assure the starting torque of heavy-duty load.

Provided that set frequency is lower than start frequency, drive output frequency is 0 Hz. Start frequency and start frequency holding time take effect at the moment of motor start, as well as the transfer between forward and reverse. Accel time at Group b2 excludes the holding time of start frequency.

b1-08	DC braking current at start	Range: 0.0%~200.0%	Factory default: 0.0%
b1-09	DC braking time at start	Range: 0.00s~30.00s	Factory default: 0.00s

When the motor is started by the method "DC braking start", it is essential to set the these two parameters.100% corresponds to rated current of drive. If braking time is set to 0.0s, DC braking at start shall be deactivated.

b1-10	Flying start 1 current	Range: 0.0%~200.0%	Factory default: 100.0%
-------	------------------------	--------------------	-------------------------

When b1-05 is set to 2, flying start 1 current should be set appropriately. 100% corresponds to drive rated current. When drive output current is less than this parameter value, it is deemed that drive output frequency is the same as motor speed and the flying operation is finished.

b1-11	Flying start 1 Decel time	Range: 0.1s~20.0s	Factory default: 2.0s
-------	---------------------------	-------------------	-----------------------

This parameter takes effect when b1-05 is set to 2, flying start 1. This time setting refers to the time drive deceleration from maximum frequency to 0. The shorter the flying start Decel time is,

the faster the flying start will be. However, excessively rapid flying start brings about inaccuracy of flying start.

b1-12	Flying start adjustment	Range: 0.0%~100.0%	Factory default:
01-12	coeff	Range: 0.0%~100.0%	1.0%

When the start method is set to flying start (b1-05=2 or 3), a suitable flying start adjustment coeff can suppress the output current during the process of flying start thus improve the smoothness of flying start.

b1-13 Stop method Range: 0~2	Factory default: 0
------------------------------	--------------------

## 0: Ramp to stop

Upon the receipt of stop command, drive gradually decreases output frequency according to the set Decel time, and stop when frequency attains 0.

### 1: Coast to stop

Upon the receipt of stop command, drive will immediately lock the output and the motor will stop with its mechanical inertia.

## 2: Ramp to stop + DC brake

Upon the receipt of stop command, drive will decrease output frequency in accordance with the rate of Decel time setting. Once the output frequency attains set value of b1-14, DC braking will be enabled, and the drive will stop after the finish of DC braking.

b1-14	Start frequency of DC brake stop	• • • • • • • • • • • • • • • • • • • •	Factory default: 0.00Hz
b1-15	DC brake current	I Range: 0.0%~200.0%	Factory default: 0.0%
b1-16	DC brake time	I Range: 0.00s~30.00s	Factory default: 0.00s

During the process "ramp to stop + DC braking", DC brake would be started when output frequency attains set value of b1-14. B1-15 defines brake level, in amps, applied to the motor. 100% corresponds to rated current of drive. B1-16 sets the length of time that DC brake current is "injected" into the motor when b1-13 is set to 2. In case brake time is set to 0.0s, DC brake shall be disabled

If "DC brake stop" terminal is enabled, this terminal time duration or b1-16 set time, whichever is longer, would be taken as stop brake time.

b1-17	Overexcitation brake	Range: 0~1	Factor	default: 1

#### 0: Disabled

#### 1: Enabled

When overexcitation brake is enabled in case of stop by Decel, the motor shall transform the

electric energy generated during Decel into heat energy by increasing magnetic flux so as to attain rapid stop. If this parameter is enabled, the Decel time will be shortened. If overexcitation brake is disabled, the Decel current of motor will decrease and the Decel time will be lengthened.

b1-18 Dynamic brak	re Range: 0~1	Factory default: 0
--------------------	---------------	--------------------

### 0: Disabled

#### 1: Enabled

When dynamic brake is enabled, the electric energy generated during Decel shall be converted into heat energy consumed by braking resistor, so as to attain rapid Decel. This brake method applies to brake of high-inertia load or the situations that require quick stop. In such a case, it is necessary to select appropriate dynamic braking resistor and brake chopper. The drives equal and below 15kW are provided with a standard inbuilt brake chopper. Inbuilt brake chopper is optional for drives 18.5kW~45kW.

ĺ	b1-19	Dynamic brake	Denge: 650\/, 750\/	Factory default:
	D1-19	threshold voltage	Range: 650V~750V	720V

This parameter takes effect only to the drives with inbuilt brake chopper. If b1-18 is set to 1: when bus voltage of drive attains the value of b1-19, dynamic brake shall perform. The energy shall be rapidly consumed through braking resistor. This value is used to regulate the brake effect of brake chopper.

b1-20	Auto restart when power up again after power loss	Range: 0~1	Factory default: 0
-------	---------------------------------------------------	------------	--------------------

Defines the drive status when power up again after power loss during running

### 0: Disabled

The drive will not run automatically when power is up after power loss.

#### 1: Enabled.

When run command is controlled by control panel or communication, the drive will run automatically when power is up again after power loss. When run command is controlled by terminals, the drive will run automatically only if ON signal from run command terminal is detected

### ATTENTION:

Enable this parameter with caution for safety consideration.

b1-21	Time delay of auto restart	Range: 0.0s~10.0s	Factory default:
D1-21	when power up again	Range. 0.05~10.05	0.0s

This time setting should consider work restoration time of relative devices in the system when power is up again after power loss, on the premise that b1-20 is set to 1.

# Group b2 Accel/Decel Parameters

b2-00	Accel/Decel time resolution	Range: 0~2	Factory default: 1
-------	-----------------------------	------------	--------------------

0: 0.01s; the setting range of Accel/Decel time is 0.00s~600.00s

1: 0.1s; the setting range of Accel/Decel time is 0.0s~6000.0s

2: 1s; the setting range of Accel/Decel time is 0s~60000s

Accel/Decel time resolution takes effect on b2-01~b2-11.

b2-01	Accel time 1	Range: 0s~60000s	Factory default: 6.0s
b2-02	Decel time 1	Range: 0s~60000s	Factory default: 6.0s
b2-03	Accel time 2	Range: 0s~60000s	Factory default: 6.0s
b2-04	Decel time 2	Range: 0s~60000s	Factory default: 6.0s
b2-05	Accel time 3	Range: 0s~60000s	Factory default: 6.0s
b2-06	Decel time 3	Range: 0s~60000s	Factory default: 6.0s
b2-07	Accel time 4	Range: 0s~60000s	Factory default: 6.0s
b2-08	Decel time 4	Range: 0s~60000s	Factory default: 6.0s

These parameters b2-01~b2-08 set the rate of Accel/Decel for speed increase/decrease.

Maximum Freq (b0-08) / Accel time X = Accel Rate X
Maximum Freq (b0-08) / Decel time X = Decel Rate X

As the formula sets forth above, Accel time means required time for drive to Accelerate to maximum frequency b0-08 from zero frequency, while Decel time refers to the time required for drive to Decelerate to zero frequency from maximum frequency b0-08. These four types of Accel/Decel time can be selected through the ON/OFF combination of DI terminals "Accel/Decel time determinant 1" and "Accel/Decel time determinant 2". See Table 6-5.

Table 6-5

Accel/Decel time determinant 2	Accel/Decel time determinant 1	Accel/Decel time
OFF	OFF	Accel/Decel time 1(b2-01, b2-02)
OFF	ON	Accel/Decel time 2(b2-03, b2-04)
ON	OFF	Accel/Decel time 3(b2-05, b2-06)
ON	ON	Accel/Decel time 4(b2-07, b2-08)

# **ATTENTION:**

When the drive is running under simple PLC, the Accel time and Decel time are determined by simple PLC related parameters, not by the DI terminals. See Group F2 for details.

When Accel/Decel of broken-line style is selected, Accel/Decel time is automatically switched to Accel/Decel time 1 and 2 according to switching frequency (b2-13 and b2-14). Under this circumstance. Accel/Decel time selection terminals are disabled.

b2-09	Decel time for	Range: 0s~60000s	Factory default:	
02-09	emergency stop	Range. 0s~60000s	6.0s	l

In case of emergency stop via multifunction MF key on control panel (MF key has been set to emergency stop 1 through parameter L0-00), or via DI terminal "emergency stop", Decel is conducted according to this time. This parameter sets the rate of Decel for speed decrease, similar with b2-01~b2-08.

b2-10	Jog Accel time	Range: 0s~60000s	Factory default: 6.0s
b2-11	Jog Decel time	Range: 0s~60000s	Factory default: 6.0s

b2-10 and b2-11 set the rate of Accel/Decel of Jog, similar with b2-01~b2-08.

b2-12	Accel/Decele curve	Range: 0~4	Factory default: 0
-------	--------------------	------------	--------------------

### 0: Linear Accel/Decel

Outputs frequency increases or decreases with a constant rate as shown in Fig. 6-12.




Fig. 6-12

fmax is maximum frequency b0-08.

### 1: Broken-line Accel/Decel

Accel/Decel time is shifted based on output frequency during Accel/Decel. When output frequency during Accel is higher than or equal to b2-13 (Accel time switching frequency of broken-line Accel/Decel), b2-01 (Accel time 1) is enabled. When lower than b2-13, b2-03 (Accel time 2) will be enabled.

When output frequency during Decel is higher than or equal to b2-14 (Decel time switching frequency of broken-line Accel/Decel), b2-02 (Decel time 1) is enabled. When lower than b2-14, b2-04 (Decel time 2) will be enabled.

## **ATTENTION:**

When broken-line Accel/Decel is enabled, "Accel/Decel time determinant 1" and "Accel/Decel time determinant 2" will be invalid.

Broken-line Accel/Decel is as shown in Fig. 6-13.





Fig. 6-13

$$t1 = (b2-03) \times (b2-13)/(b0-08)$$
  $t2 = (b2-01) \times [f-(b2-13)]/(b0-08)$   
 $t3 = (b2-02) \times [f-(b2-14)]/(b0-08)$   $t4 = (b2-04) \times (b2-14)/(b0-08)$ 

f is current frequency reference, and b0-08 is maximum frequency.

#### 2: S-curve Accel/Decel A

By adding a period of S-curve time to the initial and ending segments of Accel/Decel, it can improve the smoothness of start/stop and prevent mechanical impact. See Fig. 6-14:



Accel/Decel rate changes gradually at the initial and ending segments of S-curve time. At the middle segment of S-curve, it is linear Accel/Decel rate, which is determined by enabled Accel/Decel time 1~4. Therefore, the actual Accel/Decel time is longer than linear Accel/Decel if this parameter value is selected.

Actual Accel time = linear Accel time + (Time of initial segment of Accel S-curve

+ Time of last segment of Accel S-curve)/2

Actual Decel time = linear Decel time + (Time of initial segment of Decel S-curve + Time of last segment of Decel S-curve)/2

## Example:

Assuming that the maximum frequency b0-08 is 50Hz and the Accel time set is 6s, the linear Accel time from initial status 10Hz to  $40Hz = 6s \times (40Hz-10Hz)/50Hz = 3.6s$ 


Assuming b2-15 = 0.20s and b2-16 = 0.40s, the actual Accel time under "S-curve Accel/Decel A" = 3.6s + (0.20s + 0.40s)/2 = 3.9s.

### ATTENTION:

Provided the above-noted calculated linear Accel time is less than (Time of initial segment of Accel S-curve + Time of last segment of Accel S-curve)/2, there will not be linear part. Decel is the same as above.

# 3: S-curve Accel/Decel B

Schematic diagram is shown as Fig. 6-15:



S-curve time at first segment of Accel is (b2-19×t1) in the figure, in which the Accel rate increases progressively. In this period, the S-curve time at last segment is (b2-20×t1) and the Accel rate decreases gradually. At the middle of t1, it is linear Accel with a constant rate which is adjusted automatically based on the setting of b2-19 and b2-20.

Decel period t2 is similar as above.

Make sure the sum of proportions of the first and last segments is no more than 100%, i.e. the sum of set values of b2-19 and b2-20 should not exceed 100.0%, while that of b2-21 and b2-22 should not exceed 100%.

## Example:

Assuming that the maximum frequency b0-08 is 50Hz and the Accel time setting is 6s, the linear Accel time required for Accel from initial status 10Hz to 40Hz = 6s × (40Hz-10Hz)/50Hz = 3.6s

Assuming that b2-19 = 20.0% and b2-20 = 30.0%, The first segment of Accel S-curve should be  $20.0\% \times 3.6s = 0.72s$ ; last segment of Accel S-curve should be  $30.0\% \times 3.6s = 1.08s$ ; linear Accel time at middle segment should be 3.6s - 0.72s - 1.08s = 1.8s.

Difference between S-curve Accel/Decel A and B: Middle-segment Accel/Decel rate of S-curve Accel/Decel A is determined by the selected Accel/Decel time 1~4, not subject to the effect of S-curve time span, therefore the total Accel/Decel time changes with the variation of setting of S-curve time.

When some certain Accel/Decel time is selected for S-curve Accel/Decel B, the total time of Accel/Decel is constant, but with different proportion of the first part and the last part, the rate of linear part as well as the shape of S-curve will change.

### 4: S-curve Accel/Decel C

The motor rated frequency is taken as inflection point of this S-curve, and the set Accel/Decel time is:

Accel/Decel rate = Motor rated frequency / Accel/Decel time  $(\sqrt{})$ 

NOT Accel/Decel rate = Maximum frequency / Accel/Decel time (x)

When set frequency is higher than motor rated frequency, the Accel/Decel time is automatically adjusted by reducing motor output torque. This is applicable to the situation in which short Accel/Decel time is required during the speed range higher than motor rated frequency. Diagram of S-curve C is shown as Fig. 6-16:




Fig. 6-16

f: Set Freq

fN: Motor rated frequency

b2-13	Accel time switching frequency of broken-line Accel/Decel	Range: 0.00Hz~maximum frequency	Factory default: 0.00Hz
b2-14	Decel time switching frequency of broken-line Accel/Decel	Range: 0.00Hz~maximum frequency	Factory default: 0.00Hz

### When b2-12 is set to 1:

b2-01 (Accel time 1) is enabled when output frequency during Accel is more than or equal to set value of b2-13, while b2-03 (Accel time 2) is enabled when output frequency during Accel is less than set value of b2-13.

B2- 02 (Decel time 1) is enabled when output frequency during Decel is more than or equal to set value of b2-14, while b2-04 (Decel time 2) is enabled when output frequency during Accel is less than set value of b2-14.

# **ATTENTION:**

When broken-line Accel/Decel is selected, terminals "Accel/Decel time determinant 1" and "Accel/Decel time determinant 2" will be disabled.

b2-15	Time of Accel S-curve first segment	Range: 0.00s~60.00s	Factory default: 0.20s
b2-16	Time of Accel S-curve last segment	Range: 0.00s~60.00s	Factory default: 0.20s
b2-17	Time of Decel S-curve first segment	Range: 0.00s~60.00s	Factory default: 0.20s
b2-18	Time of Decel S-curve last segment	Range: 0.00s~60.00s	Factory default: 0.20s

These four parameters are enabled when b2-12 is set to 2.

b2-19	Proportion of Accel S- curve first segment	Range: 0.0%~100.0%	Factory default: 20.0%
b2-20	Proportion of Accel S- curve last segment	Range: 0.0%~100.0%	Factory default: 20.0%
b2-21	Proportion of Decel S- curve first segment	Range: 0.0%~100.0%	Factory default: 20.0%
b2-22	Proportion of Decel S- curve last segment	Range: 0.0%~100.0%	Factory default: 20.0%

These four parameters are enabled when b2-12 is set to 3.

# **ATTENTION:**

The sum of the values of b2-19 and b2-20 should not exceed 100.0%. The sum of the values of b2-21 and b2-22 also should not exceed 100.0%.

# Group C Input & Output Terminals

# Group C0 Digital Input

C0-00	Enabled condition of run command terminals when power up	Range: 0~1	Factory default: 0
-------	----------------------------------------------------------	------------	--------------------

This parameter is only for digital terminals with parameter value 1~4 (forward/reverse jog, and forward/reverse run), and also is only for initial run after power up.

## 0: Trigger edge detected + ON detected

When run command is controlled by terminals, the drive will start to run when it detects that the terminal electric level jumps from OFF to ON and is kept ON after power up.

If run command terminal is in ON state before power up, the drive will not run after power up. Under this circumstance, only when the ON state is shifted to OFF and then ON again, and maintain ON, the drive will start running.

#### 1: ON detected

When run command is controlled by terminals, the drive will start to run when detecting the command terminal at ON state after power up.

### ATTENTION:

When "1: ON detected" selected, the drive will start to run after power up as long as ON of run command terminal detected. Make sure of the safety of personnel and equipment before this setting.

C0-01	Function of terminal X1	Range: 0~99	Factory default: 3
C0-02	Function of terminal X2	Range: 0~99	Factory default: 4
C0-03	Function of terminal X3	Range: 0~99	Factory default: 1
C0-04	Function of terminal X4	Range: 0~99	Factory default: 23
C0-05	Function of terminal X5	Range: 0~99	Factory default: 11
C0-06	Function of terminal X6	Range: 0~99	Factory default: 0
C0-07	Function of terminal X7/DI	Range: 0~99	Factory default: 0
C0-08	Function of terminal AI1 (Digital enabled)	Range: 0~99	Factory default: 0
C0-09	Function of terminal AI2 (Digital enabled)	Range: 0~99	Factory default: 0
C0-10	Function of terminal AI3 (Digital enabled)	Range: 0~99	Factory default: 0

Analog input terminals AI1, AI2 and AI3 can also be used as digital input terminals set by C0-08~C0-10. When AI1, AI2 and AI3 are used as analog input, C0-08~C0-10 shall be set to 0.

Parameter setting of digital input is as shown in Table 6-6:

**Table 6-6 Digital input functions** 

Set value	Function	Set value	Function
0	No function	37	Count input
1	JOG forward	38	Count clear
2	JOG reverse	39	Length count
3	Run forward (FWD)	40	Length clear
4	Run reverse (REV)	41	Zero-speed clamping enabled
5	Three-wire control	42	Reserved
6	Run suspended	43	Reserved
7	External stop	44	Reserved
8	Emergency stop	45	Reserved
9	Stop command + DC brake	46	Reserved
10	DC brake stop	47	Reserved
11	Coast to stop	48	Reserved
12	Terminal UP	49	Reserved
13	Terminal DOWN	50	Reserved
14	Clear UP/DOWN (including ^/ v key) adjustment	51	Position reference pulse input
15	Multi-step frequency terminal 1	52	Position reference direction input
16	Multi-step frequency terminal 2	53	Clear positioning pulse
17	Multi-step frequency terminal 3	54	Forward position offset enabled
18	Multi-step frequency terminal 4	55	Reverse position offset enabled
19	Accel/Decel time determinant 1	56	Pulse correction input
20	Accel/Decel time determinant 2	57	Pulse correction direction
21	Accel/Decel disabled (ramp stop not inclusive)	58	Reserved
22	External fault input	59	Reserved
23	Fault reset (RESET)	60~62	Reserved
24	Pulse input (valid only for X7/DI)	63	Simple PLC paused
25	Motor 1/2 switchover	64	Simple PLC disabled
26	Speed/Torque control switchover	65	Simple PLC stop memory clear

Set value	Function	Set value	Function
27	Run command switched to control panel control	66	Start wobble frequency
28	Run command switched to terminal control	67	Clear wobble frequency status
29	Run command switched to communication control	68	Run prohibited
30	FREQ reference mode shift	69	DC brake in run
31	Master FREQ reference switched to digital setting b0-02	70	Analog input curve switchover
32	Auxiliary FREQ reference switched to digital setting b0-04	71	Position control switched to disabled
33	PID adjustment direction	72	Pulse frequency direction reference
34	PID paused	73	Analog signal gain switchover
35	PID integration paused	74~99	Reserved
36	PID parameter switchover		

## 0: No function

## 1: JOG forward

Perform jog forward through terminals. Jog frequency is set by b0-19, jog Accel time set by b2-10, and jog Decel time set by b2-11. Refer to C0-00 for enabled conditions on initial power up.

### 2: JOG reverse

Perform jog reverse through terminals. Jog frequency is set by b0-19, jog Accel time set by b2-10, and jog Decel time set by b2-11. Refer to C0-00 for enabled conditions on initial power up.

## 3: Forward (FWD)

Terminals control forward running of the drive. Refer to C0-00 for enabled conditions on initial power up.

# 4: Reverse (REV)

Terminals control reverse running of the drive. Refer to C0-00 for enabled conditions on initial power up.

### 5: Three-wire control

There are two-wire control and three-wire control about Forward (FWD) and reverse (REV).

In case of three-wire control is enabled, "three-wire control" terminal is activated. For details, refer to C0-19 (FWD/REV terminal control mode).

## 6: Run suspended

When "running suspended" terminal is enabled during the running, the drive will block the output and perform zero-frequency running. Once "running suspended" terminal becomes disabled, the drive restores the running.

## 7: External stop

No matter which type of b1-00 is set to, the drive will stop by enabled "external stop" terminal, in the manner of Stop method.

## 8: Emergency stop

When "emergency shutdown" is enabled, the drive will stop in accordance with Decel time set by b2-09. Please set b2-09 to an appropriate value so as to minimize the Decel time for emergency stop.

### 9: Stop command + DC brake

The drive performs ramp-down stop when "stop command+ DC brake" terminal is enabled. It will perform DC brake when output frequency attains brake start frequency. Brake start frequency and brake current are set by b1-14 and b1-15. Brake time is determined by the maximum of b1-16 and the lasting time of this terminal.

## 10: DC brake stop

The drive performs "ramp to stop + DC brake" (same as b1-13 is set to 2) when "DC brake stop" is enabled, in the manner set by b1-14, b1-15 and b1-16.

## 11: Coast to stop

When "coast to stop" terminal is enabled, the drive will immediately cut off its output and the motor will coast to stop.

### 12. Terminal UP

## 13: Terminal DOWN

Terminals are used to increase and decrease the frequency reference. The frequency reference will be increased and decreased when "digital setting + terminal UP/DOWN adjustment" is enabled. The adjustment "step size" is set by C0-18. Refer to C0-17 for Terminal UP/DOWN frequency adjustment action.

## 14: UP/DOWN (including ^/v key) adjustment clear

When frequency reference is "digital setting + terminal UP/DOWN adjustment" or "digital setting + control panel ^/v adjustment", this enabled terminal will clear the adjusted value

via terminals UP/DOWN and keys ^/v, to digital set value b0-02 or b0-04.

- 15: Multi-step frequency terminal 1
- 16: Multi-step frequency terminal 2
- 17: Multi-step frequency terminal 3
- 18: Multi-step frequency terminal 4

16-step frequency can be attained via combination of multi-step frequency terminals 1~4, as shown in Table 6-7:

Table 6-7

Multi-step frequency terminal 4	Multi-step frequency terminal 3	Multi-step frequency terminal 2	Multi-step frequency terminal 1	Set frequency
OFF	OFF	OFF	OFF	Multi-step FREQ 0 (F1-00)
OFF	OFF	OFF	ON	Multi-step FREQ 1 (F1-01)
OFF	OFF	ON	OFF	Multi-step FREQ 2 (F1-04)
OFF	OFF	ON	ON	Multi-step FREQ 3 (F1-05)
OFF	ON	OFF	OFF	Multi-step FREQ 4 (F1-06)
OFF	ON	OFF	ON	Multi-step FREQ 5 (F1-07)
OFF	ON	ON	OFF	Multi-step FREQ 6 (F1-08)
OFF	ON	ON	ON	Multi-step FREQ 7 (F1-09)
ON	OFF	OFF	OFF	Multi-step FREQ 8 (F1-10)
ON	OFF	OFF	ON	Multi-step FREQ 9 (F1-11)
ON	OFF	ON	OFF	Multi-step FREQ 10 (F1-12)
ON	OFF	ON	ON	Multi-step FREQ 11 (F1-13)
ON	ON	OFF	OFF	Multi-step FREQ 12 (F1-14)
ON	ON	OFF	ON	Multi-step FREQ 13 (F1-15)
ON	ON	ON	OFF	Multi-step FREQ 14 (F1-16)
ON	ON	ON	ON	Multi-step FREQ 15 (F1-17)

## 19: Accel/Decel time determinant 1

### 20: Accel/Decel time determinant 2

Accel/Decel time determinant 1~2 can realize at most 4 Accel/Decel time settings through combination of different statuses as shown in Table 6-8. Accel/Decel time can be switched via different combinations during running.

Accel/Decel time Accel/Decel time Accel/Decel time determinant 2 determinant 1 Accel/Decel time 1 OFF OFF (b2-01, b2-02) Accel/Decel time 2 OFF ON (b2-03, b2-04) Accel/Decel time 3 ON OFF (b2-05, b2-06) Accel/Decel time 4 ON ON (b2-07, b2-08)

Table 6-8

### ATTENTION:

The selection of Accel/Decel time 1~4 is not determined by digital input terminals when the drive is running under simple PLC. See parameter Group F2 for details. When brokenline Accel/Decel is enabled, Accel/Decel time is automatically switched to Accel/Decel time 1 and 2 according to switching frequency (b2-13 and b2-14). In this case, Accel/Decel time determinant terminals are disabled.

## 21: Accel/Decel disabled (ramp stop not inclusive)

When "Accel/Decel disabled" terminal is enabled, the drive maintains the present output frequency and no longer responds to the change of frequency reference. But it will still perform ramp-down stop when receiving stop command. This terminal is disabled during normal ramp-down stop.

## 22: External fault input

This terminal is used to input the fault signal of external equipment, making the drive to perform fault monitoring and protection. When external fault signal is received, the drive shall display "Per" and stop running.

## 23: Fault reset (RESET)

When the drive fault occurs, this enabled terminal will reset the fault. This function is the same with RESET key on control panel.

### 24: Pulse input (valid only for X7/DI)

This is valid only for digital input terminal X7/DI. This terminal receives pulse signal as frequency reference. Refer to C2-24~C2-27 for the relationship between pulse signal and frequency reference.

When pulse input is selected as the frequency reference, X7/DI terminal must be set to "pulse input" (C0-07 is set to 24).

### 25: Motor 1/2 switchover

The loaded motor can be selected via this terminal as shown in Table 6-9:

Table 6-9

A0-08	Motor 1/2 switchover terminal	Loaded motor
0	OFF	Motor 1
0	ON	Motor 2
1	OFF	Motor 2
1	ON	Motor 1

Sets parameters of motor 1 in parameter groups d0~d2, and set parameters of motor 2 in groups d3~d5.

## 26: Speed/Torque control switch

Only sensor-less vector control 2 or closed-loop vector control supports torque control. Under any of the two control patterns, speed control and torque control can be switched by this terminal.

In addition, speed control and torque control can also be switched by setting parameter d2-00 (when motor 1 is the loaded one) or d5-00 (when motor 2 is the loaded one).

The correlation of speed control and torque control switched by parameter and terminal is shown in Table 6-10:

**Table 6-10** 

d2-00 (or d5-00)	Speed/Torque control switch terminal	Control mode
0	OFF	Speed control
0	ON	Torque control
1	OFF	Torque control
1	ON	Speed control

### 27: Run command switched to control panel control

This terminal should be enabled by trigger edge. When this terminal status is switched from OFF to ON, run command will be switched to control panel control.

### 28: Run command switched to terminal control

This terminal should be enabled by trigger edge. When this terminal status is switched from OFF to ON, run command will be switched to terminal control.

### 29: Run command switched to communication control

This terminal should be enabled by trigger edge. When this terminal is switched from OFF to ON, run command will be switched to communication control.

## 30: Frequency reference mode shift

When b0-00 is set to 2, 3 and 4, switch during various frequency reference modes can be performed via "FREQ reference mode shift" terminal.

When b0-00 is set to 2, this terminal shall shift between master frequency reference and auxiliary frequency reference.

When b0-00 is set to 3, this terminal shall shift between master frequency reference, and master & auxiliary computation result.

When b0-00 is set to 4, this terminal shall shift between auxiliary frequency reference, and master & auxiliary computation result.

## 31: Master frequency reference switched to digital setting b0-02

When this terminal is disabled, b0-01 determines master frequency reference. When it is enabled, master frequency reference is forcibly switched to the value of b0-02.

### **ATTENTION:**

This terminal is disabled when the binding of run command and frequency reference is set by b1-01.

## 32: Auxiliary frequency reference switched to digital setting b0-04

When this terminal is enabled, b0-03 determines auxiliary frequency reference. When it is enabled, auxiliary frequency reference is forcibly switched to the value of b0-04.

### 33: PID adjustment direction

The combination of this terminal and value of F0-04 (PID positive and negative adjustment), can determine the positive or negative characteristics of PID adjustment.

**Table 6-11** 

F0-04	PID adjustment direction terminal	Adjustment characteristic
0	OFF	Positive action
0	ON	Negative action
1	OFF	Negative action
1	ON	Positive action

### 34: PID paused

When this terminal is enabled, PID adjustment is paused, and the drive will maintain current output frequency. After this terminal becomes disabled, PID adjustment recovers.

### 35: PID integration paused

When this terminal is enabled, PID integrator stops its integration, and the current value is maintained. After this terminal becomes disabled, PID restores its integration.

## 36: PID parameter switchover

When F0-14 (PID parameter switch) is set to "2: switched by terminal", this terminal could be used to realize the switching between two groups of PID parameters. When this terminal is enabled, PID parameters are Kp1 and Ti1, Td1 which are determined by F0-08~F0-10. When this terminal is disabled, PID parameters are Kp2, Ti2 and Td2 which are determined by F0-11~F0-13.

### 37: Count input

The maximum frequency at count pulse input terminal is 200Hz, and the count value can be memorized in case of power loss. With the setting of F3-12 (set count value) and F3-13 (designated count value), this terminal can control digital output "set count value attained" and "designated count value attained".

#### 38: Count clear

Used with "count input" terminal, to clear pulse count value.

## 39: Length count

It is used for fixed-length control, and only takes effect on digital input terminal X6/DI. The length is calculated via pulse input. Please refer to specification of parameters F3-08~F3-11 for details. When the length is attained, digital output terminal "length attained" shall output effective signal. The current length value will be memorized on power loss.

### 40: Length clear

Used with "length count" terminal, to clear the length calculated.

## 41: Zero-speed clamping enabled

Zero-speed clamping function is valid only under sensor-less vector control, as well as F4-00 (position control mode) should be set to "2: zero-speed clamping (terminal enabled)". When the frequency reference of drive is lower than zero-speed clamping start frequency F4-04, also the motor speed is lower than the speed that corresponds to F4-04, the drive will record the position and perform lock immediately when receiving effective signal by terminal "zero-speed clamping enabled". Under this circumstance, the motor will always maintain this position no matter motor load changes or not. When terminal "zero-speed clamping enabled"

terminal is disabled, the motor will quit position locked status and run at set speed.

#### 42~50: Reserved

## 51: Position reference pulse input

This function is valid only under closed-loop vector control, as well as when F4-00 (position control mode) is set to "5: pulse train position control". When F4-33 is set to 0: X7/DI pulse input + terminal direction input, via this terminal command signal inputs, only valid for X7/DI terminal. Maximum frequency of X7/DI is 30kHz.

Under pulse train position control, pulse can also input via encoder 1 (local) setting and Encoder 2 (optional) setting.

# 52: Position reference direction input

This terminal is used with terminal "position reference pulse input", determining the direction of pulse input.

When this terminal is OFF, the input pulse train is forward direction. When this terminal is ON, the input pulse train is reverse.

## 53: Clear positioning pulse

This function is valid only under closed-loop vector control, as well as F4-00 (position control mode) is set to 5: pulse train position control. When this terminal is enabled, count value of input pulse train is cleared

### 54: Forward position offset enabled

## 55: Reverse position offset enabled

This function is valid only under closed-loop vector control, as well as when F4-00 (position control mode) is set to 5: pulse train position control. Both terminals are mainly used for phase adjustment when two or more motors are under synchronous running. Where motor position is synchronized, if terminal "forward position offset enabled" is in effect, the drive will control the motor phase to change forward progressively. If "reverse position offset enabled" terminal is valid, motor phase will change gradually reversely, adjusting relative position of the motors.

Both terminals shall be used with F4-38 (position offset change rate). When "position offset enable" terminal is valid in the case of F4-38, the change rate of phase adjustment is defined as the variation of pulse per second, of which the value is 4 times the number of pulses of encoder.

## 56: Pulse correction input

Only valid for the digital input terminal X7/DI. When F4-00 (position control mode) is set to 5: Pulse train position control, if C0-07 is set to 56, the position can be corrected by the X7

terminal input pulse. F4-38 is the pulse correction magnification at this time, and the correction direction is determined by the "pulse correction direction" terminal.

#### 57: Pulse correction direction

Used in conjunction with the "Pulse Correction Input" terminal. When this terminal is OFF, forward correction is performed; when this terminal is ON, reverse correction is performed.

### 58~62 Reserved

## 63: Simple PLC paused

When simple PLC is running and this terminal is enabled, the current PLC status (run time and step) will be memorized, and the drive will run at 0Hz. When this terminal is disabled, the drive restores its running from the memorized moment.

# 64: Simple PLC disabled

When simple PLC is running, and this terminal is enabled. The status of PLC will be cleared and the output frequency is 0Hz. When this terminal is disabled again, the drive resumes PLC running from step 0.

## 65: Simple PLC stop memory clear

Under simple PLC running, if this terminal is enabled in stop status, the memorized information of PLC running step, run time and run FREQ will be all cleared. Refer to parameter Group F2 for more information.

### 66: Start wobble frequency

This terminal takes effect only when F3-00 is set to 1: "wobble frequency function enabled" and F3-01 ones place is set to "started through terminal".

When this terminal is disabled, the drive runs at present frequency reference. When this terminal is enabled, the drive would activate wobble-frequency running immediately. Refer to Group F3 for details of wobble frequency.

## 67: Clear wobble frequency status

When the drive is running at wobble frequency, if this terminal is enabled, the memorized wobble frequency status will be cleared, no matter which wobble frequency start method (automatic/ via terminal) is taken. When this terminal is disabled, wobble frequency would resume. Refer to Group F3 for information of wobble frequency.

### 68: Run prohibited

When this terminal is enabled, the drive will coast to stop if it's running, and will prohibit start running if it's in a standby state. This terminal mainly applies to the situation where safety interlocking is required. Only after this terminal becomes disabled, the drive can be restarted.

### 69: DC brake in run

When this terminal is enabled, the drive will immediately fall into DC brake. After the terminal becomes disabled, the drive will be restored to normal state and ramp up to the frequency reference with the set ramp up time.

## ATTENTION:

When this terminal is enabled, output frequency does not need to decelerate to brake start frequency, but will directly inject DC whose value is set by b1-15.

## 70: Analog input curve switchover

When C2-00 is set to 3: curve 2 and curve 3 switchover, the analog input curve can be switched through this terminal. When this terminal is OFF, the analog curve 2 is selected; when it is ON, the analog curve 3 is selected.

### 71: Position control switched to disabled

When this terminal is ON, the position control is disabled and the drive runs at speed control mode.

### 72: Pulse frequency direction reference

When b0-01 is selected as 11: Pulse input A+/A- + terminal direction input, the direction is given by this terminal. When it is OFF, drive runs forward; when it is ON, it runs in reverse.

## 73: Analog signal gain switch

When this terminal is ON, the actual analog input value is multiplied by the factor C2-29 (analog gain switchover value) as the final input.

### 74~99: Reserved

C0-11	Filtering time of digital input terminal	Range: 0.000s~1.000s	Factory default: 0.010s
-------	------------------------------------------	----------------------	-------------------------

Set the filtering time of X1~X7 (when X7 is used as ordinary low-speed terminal), Al1, Al2 and Al3 (when used as digital input terminal). Interference immunity of digital input terminals can be improved by appropriate filtering time. However, the response time of digital input terminal will become slower when filtering time is increased.

### ATTENTION:

This filtering time takes no effect on X7/DI when X7/DI terminal is used as DI high-speed input terminal, while the filtering time of DI is determined by parameter C2-28.

C0-12	Delay time of terminal X1	Range: 0.0s~3600.0s	Factory default: 0.0s
C0-13	Delay time of terminal X2	Range: 0.0s~3600.0s	Factory default: 0.0s

The delayed response time of digital input terminals X1 and X2 is set by these two parameters.

### ATTENTION:

Terminal delay time C0-12 and C0-13 can be set with filtering time C0-11 at the same time. The drive will respond after the signals via X1 and X2 go through filtering time, and then delay time. Terminals X3~X7 and EX have no delay-time function.

	CO 44	Digital input terminal	Panga: 0000-1111	Factory default:
C0-14	enabled status setting 1	Range: 0000~1111	0000	

- ◆ Ones place: X1
- 0: Positive logic; ON when current passes through
- 1: Negative logic; ON when no current passes through
- ◆ Tens place: X2 (same as X1)
- ◆ Hundreds place: X3 (same as X1)
- ◆ Thousands place: X4 (same as X1)

C0-15	Digital input terminal	Range: 0000~1111	Factory default:
	enabled status setting 2		0000

- ♦ Ones place: X5
- 0: Positive logic; ON when current passes through
- 1: Negative logic; ON when no current passes through
- ◆ Tens place: X6 (same as X5)
- ◆ Hundreds place: X7 (same as X5)
- ◆ Thousands place: reserved

C0-16	Digital input terminal enabled status setting 3	Range: 0000~1111	Factory default: 0000
	enabled status setting 3		0000

This parameter sets the enabled condition of Al1, Al2 and EAI as digital input terminal (need to be defined by C0-08~C0-10).

- ◆ Ones place: Al1
- 0: Positive logic; < 3V, ON; > 7V, OFF
- 1: Negative logic; < 3V, OFF; > 7V, ON
- ◆ Tens place: Al2 (same as Al1)
- Hundreds place: Al3 (same as Al1)
- Thousands place: reserved

## ATTENTION:

When Al1~Al3 are used as analog input, do not use again as digital input. That is, C0-08~C0-10 should be set to 0.

ĺ	CO 47	Terminal UP/DOWN frequency	Danger 0000, 1111	Factory default:
C0-17	CU-17	adjustment action	Range: 0000~1111	0000

Ones place: at stop

0: Cleared

Terminal UP/DOWN frequency adjustment value is cleared when the drive stops.

1. Maintained

Terminal UP/DOWN frequency adjustment value is maintained when the drive stops.

- ◆ Tens place: on power loss
- 0: Cleared

Terminal UP/DOWN frequency adjustment value is cleared in case of power loss.

1. Maintained

Terminal UP/DOWN frequency adjustment value is saved in case of power loss.

- ◆ Hundreds place: integral function
- 0: No integral function

Adjustment step size is kept constant during terminal UP/DOWN adjustment, in compliance with C0-18.

1: Integral function enabled

When frequency is adjusted through terminal UP/DOWN, initial step size is set by C0-18. With the effective lasting time of the terminals, adjustment step size will increase gradually.

- ◆ Thousands place: run direction
- 0: Changing run direction prohibited

When the frequency is decreased to 0Hz via terminal UP/DOWN, the drive will run at 0Hz and won't change its run direction.

1: Changing run direction allowed

When the frequency is decreased to 0Hz via terminal UP/DOWN, the drive will change its run direction if this decrease is continued.

Ī	00.40	Terminal UP/DOWN frequency	Range:	Factory default:
C0-18	change step size	0.00Hz/s~100.00Hz/s	0.03Hz/s	

When frequency reference is "digital setting + terminal UP/DOWN adjustment", this parameter is used to set the step size of frequency adjustment UP/DOWN. The step size is defined as frequency change per second, and the smallest step size is 0.01 Hz/s.

C0-19	FWD/REV terminal control	Pango: 0-2	Factory default:
C0-19	mode	Range: 0~3	0

There are four different methods when run command is determined by FED/REV terminal. This terminal control mode takes no effect on JOG.

### 0: Two-wire mode 1

FWD terminal inputs forward run command, while REV terminal inputs reverse run command.




Fig. 6-17

# **Table 6-12**

FWD	REV	Run
		command
OFF	OFF	Stop
OFF	ON	Reverse
ON	OFF	Forward
ON	ON	Stop

## 1: Two-wire mode 2

FWD terminal inputs run command, while REV terminal inputs run direction.




Fig. 6-18

**Table 6-13** 

FWD	REV	Running
	1 ( _ 1	command
OFF	OFF	Stop
OFF	ON	Stop
ON	OFF	Forward
ON	ON	Reverse

## 2: Three-wire mode 1

FWD terminal controls forward run of the drive, REV terminal controls reverse running, and digital input terminal "three-wire run" controls the stop. Input signals of all these three terminals take effect when trigger edge is detected.




Fig. 6-19 Three-wire mode 1

SB1 is a STOP button, by pressing which the drive will stop;

SB2 is a FORWARD button, by pressing which forward run will be activated;

SB3 is a REVERSE button, by pressing which reverse run will be activated.

Xi is a digital input terminal. In this case, it is necessary to define the function of corresponding terminal as "three-wire run" terminal.

#### 3: Three-wire mode 2

FWD terminal controls the run, while run direction is determined by REV terminal. Digital input terminal "three-wire run" controls the stop.




Fig. 6-20 Three-wire mode 2

SB1 is a stop button, by pressing which the drive will stop;

SB2 is a RUN button, by pressing which the drive will run. When switch K is open, run is forward, while when it is closed, run is reverse.

Xi is a digital input terminal. In this case, it is necessary to define the function of corresponding terminal as "three-wire run" terminal.

C0-20	Option of virtual input	Range: 000~77F	Factory default:
00 20	terminal	range. eee 771	000

This parameter is a 10-bit binary numeral. The terminals that correspond respectively to bit10 (the highest bit of binary system) through bit0 (the lowest bit of binary system) are as follows:

**Table 6-14** 

Hur	Hundreds place Tens place		Ones place							
bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
AI3	Al2	Al1	Null	X7	X6	X5	X4	Х3	X2	X1

◆ Ones place: bit0~bit3: X1~X4
 0: Actual terminal takes effect

1: Virtual terminal takes effect

◆ Tens place: bit4~bit6: X5~X7

0: Actual terminal takes effect

1: Virtual terminal takes effect

♦ Hundreds place: bit8~bit10: Al1~Al3

0: Actual terminal takes effect

1: Virtual terminal takes effect

Virtual terminals simulate actual terminals via communication. Each bit represents one terminal. When selecting virtual terminal, corresponding bit should be set to 1 in C0-20, Under this circumstance the actual terminal is invalid.

C0-21	Enabled condition of run command terminal after	Range: 0~1	Factory default:0
	fault reset (RESET)		

This parameter only takes effect on run command terminals, i.e. digital input terminal set as 1~4 (JOG forward/reverse, run forward/reverse. See table 6-6), and only works for the run after fault reset.

0: Trigger edge detected + ON detected After the fault reset, the drive will start to run when an electric level jump from OFF to ON is detected and ON signal are maintained.

## 1: ON detected

The drive will run automatically if ON signal from run command terminal is detected. When this parameter value is set to 1, please make sure the status of run command terminals before fault reset operation. Failure to comply may result in equipment damage and/or personal injury.

# Group C1 Digital Output

C1-00	Y1 output function	Range: 0~99	Factory default: 0
C1-01	Y2/DO output function (when used as Y2)	Range: 0~99	Factory default: 0
C1-02	Relay 1 output function	Range: 0~99	Factory default: 14
C1-03	Relay 2 output function	I Range: 0~99	Factory default: 15

Define the functions of digital output terminals Y1 & Y2, relay 1 and relay 2. When used as high-speed pulse output, Y2/DO terminal's function are not set in C1-01 but in C3-02. Output terminal function selections are as follows:

**Table 6-15** 

Value	Corresponding function	Value	Corresponding function
0	No output		Drive thermal alarm
1	Drive undervoltage	18	Zero-current detection
2	Drive run preparation completed	19	X1
3	Drive is running	20	X2
4	Drive in 0Hz running (no output at	21	Motor 1/2 indication
	stop)		
5	Drive in 0Hz running (output at stop)	22	Set count value attained
6	Run direction		Designated count value attained
7	Frequency attained	24	Length attained
8	Upper limit frequency attained	25	Consecutive run time attained
9	Lower limit frequency attained	26	Accumulative run time attained
10	Frequency higher than FDT 1	27	Brake control
11	Frequency higher than FDT 2	28	Positioning finished
12	Speed being restricted (torque control mode)		Positioning imminent

Value	Corresponding function	Value	Corresponding function	
13	Torque being restricted (speed control mode)	30	PLC step completed	
14	Fault output		PLC cycle completed	
15	Alarm output	32	Wobble frequency attains to upper or lower limit frequency	
16	Drive (motor) overloaded alarm	33	Set frequency attains to upper / lower limit frequency	

## 0: No output

Output terminal is disabled, and there is no output.

## 1: Drive undervoltage

When DC bus voltage is lower than the level of undervoltage, output ON signal and LED control panel displays "LoU".

## 2: Drive run preparation completed

The output of ON signal indicates that the drive is free of fault, under this circumstance, the drive is ready to accept run command.

## 3: Drive is running

The output is ON when the drive is running, and output is OFF when drive stopped.

## 4: Drive in 0Hz running (no output at stop)

When running at 0Hz, this corresponding terminal outputs ON signal. No ON signal will be output at stop.

## 5: Drive in 0Hz running (output at stop)

Under V/f control, Outputs ON signal when is running at 0Hz and also outputs ON signal at stop.

## 6: Run direction

Outputs OFF signal under forward run and outputs ON signal under reverse run.

## 7: Frequency attained

When the deviation of output frequency from frequency reference is less than the value of C1-14 (Detective width of frequency attained), outputs ON.

## 8: Upper limit frequency attained

When output frequency attains b0-09 (upper limit frequency), outputs ON.

## 9: Lower limit frequency attained

When output frequency attains b0-10 (lower limit frequency), outputs ON.

## 10: Frequency higher than FDT 1

Terminal outputs ON signal when output frequency exceeds C1-10 (FDT1 upper value) and will not output OFF signal unless output frequency drops to below C1-11 (FDT1 lower value).

## 11: Frequency higher than FDT 2

Terminal outputs ON when output frequency exceeds C1-12 (FDT2 upper value) and will not output OFF unless output frequency drops to below C1-13 (FDT2 lower value).

12: Speed being restricted (torque control mode)

This takes effect only in the mode of sensor-less vector control 2 or closed-loop vector control modes. If the motor speed attains the speed limit value, terminal outputs ON signal.

13: Torque being restricted (speed control mode)

This takes effect only in the mode of sensor-less vector control 1, sensor-less vector control 2 and closed-loop vector control. If output torque attains the limit value of drive torque or brake torque, terminal outputs ON.

14: Fault output

When the drive is in fault, it outputs ON.

15: Alarm output

When inverter gives an alarm. ON signal is output.

16: Drive (motor) overloaded alarm

In case drive output current exceeds E1-04 (overload alarm threshold) and its last time exceeds E1-05 (overload alarm activated time that exceeding threshold), outputs ON. Refer to parameters E1-03~E1-05 for information with regard to drive (motor) overloaded alarm.

#### ATTENTION:

In case of either drive is overloaded or motor is overloaded, it also will output ON.

17: Drive thermal alarm

When drive internally detected temperature exceeds E1-13 (Drive overheat alarm threshold), ON signal will be output.

18: Zero-current detection

When drive output current is less than the value of C1-15 (effective proportion of zero current detected) and the lasting time attains the value of C1-16 (Zero current detected time), ON signal will be output.

19: X1

Output the status of X1.

20: X2

Output the status of X2.

21: Motor 1/2 indication

When motor 1 is selected, outputs OFF. When motor 2 is selected, outputs ON.

22: Set count value attained

Refer to the specification of parameter F3-12.

23: Designated count value attained

Refer to the specification of parameter F3-13.

24: Length attained

Refer to the specification of parameters F3-08~F3-11.

25: Consecutive run time attained

When consecutive run time attains the value of E0-03, corresponding terminal outputs ON. Consecutive run time is cleared when stop.

#### 26: Accumulative run time attained

When accumulative run time attains the value of E0-04, corresponding terminal outputs ON. Accumulative run time is maintained when stop.

#### 27: Brake control

Refer to the specification of parameters E0-05~E0-11 for details.

## 28: Positioning finished

Under the mode of angular positioning or simple feed, when the difference between the detected position by encoder and command position is less than F4-01, also the lasting time attains value of F4-02, this terminal outputs ON as finish of positioning.

## 29: Positioning imminent

Under pulse train position control, When the difference between the pulse detected by encoder and command pulse is less than value of F4-01, this terminal outputs ON.

#### 30: PLC step completed

Upon the completion of current step of simple PLC running, ON signal with the width of 500ms will be output.

### 31: PLC cycle completed

Upon the completion of a cycle of simple PLC running, ON signal with a width of 500ms will be output.

## 32: Wobble frequency attains to upper or lower limit frequency

When drive output frequency attains upper limit frequency b0-09 or lower limit frequency b0-10 under wobble frequency running, ON signal will be output.

## 33: The upper/lower limit of set frequency obtained

## 34~99: Reserved

C1-04	Y1 output delay time	Range: 0.0s~3600.0s	Factory default: 0.0s
C1-05	Y2 output delay time	Range: 0.0s~3600.0s	Factory default: 0.0s
C1-06	Relay 1 output delay time	Range: 0.0s~3600.0s	Factory default: 0.0s
C1-07	Relay 2 output delay time	Range: 0.0s~3600.0s	Factory default: 0.0s

These four parameters define the delay response time of digital output terminals Y1 & Y2, relay 1 and relay 2.

#### ATTENTION:

When Y2/DO terminal is used as high-speed pulse output (set by C3-02), delay time set by C1-05 is disabled.

C1-08	Enabled state of digital output	Range: 0000~1111	Factory default: 0000
-------	---------------------------------	------------------	-----------------------

Ones place: Y1

0: Positive logic; ON when current passes through

1: Negative logic; ON when no current passes through

Tens place: Y2 (same as Y1)Hundreds place: relay 1 output

0: Positive logic; ON when there is coil excitation

1: Negative logic; ON when there is no coil excitation

◆ Thousands place: relay 2 output (same as relay 1)

Wiring diagram of digital output terminal is shown as Fig. 6-21:




Fig. 6-21

C1-09	Detected object of frequency	Range: 00~11	Factory default:
C1-09	doubling technology(FDT)	Range. 00~11	00

- ◆ Ones place: FDT1 detective object
- 0: Set value of speed (frequency after Accel/Decel)

FDT1 output frequency is the frequency reference after Accel/Decel.

1: Detected speed value

FDT1 output frequency is actually detected or identified frequency. If the drive is under V/f pattern, it should be output frequency.

- ◆ Tens place: FDT2 detective object
- 0: Set value of speed (frequency after Accel/Decel)

FDT2 output frequency is the frequency reference after Accel/Decel.

1: Detected speed value

FDT2 output frequency is actually detected or identified frequency. If the drive is under V/f pattern, it should be output frequency.

C1-10	FDT1 upper value	Range: 0.00Hz~maximum FREQ	Factory default: 50.00Hz
C1-11	FDT1 lower value	Range: 0.00Hz~ maximum FREQ	Factory default: 49.00Hz
C1-12	FDT2 upper value	Range: 0.00Hz~ maximum FREQ	Factory default: 25.00Hz
C1-13	FDT2 lower value	Range: 0.00Hz~ maximum FREQ	Factory default: 24.00Hz

These parameters should be set with digital output terminals "FDT1" and "FDT2".

Take FDT1 for example, the drive outputs ON signal when output frequency exceeds upper bound of FDT1 and will not output OFF signal unless output frequency drops to below lower bound of FDT1. Please set C1-10 to be larger to some certain extent than C1-11, avoiding status change frequently. See Fig. 6-22:





Fig. 6-22

C1-14	Detection width of	Range: 0.00Hz~ maximum	Factory default:
C1-14	frequency attained	FREQ	2.50Hz

This parameter should be set with digital output terminal "frequency attained". When the difference between output frequency and frequency reference is less than this value, terminal "frequency attained" outputs ON. See Fig. 6-23:



Fia. 6-23

C1-15	Zero current detection level	Range: 0.0%~50.0%	Factory default: 5.0%
C1-16	Zero current detection time	Range: 0.01s~50.00s	Factory default: 0.50s

The two parameters should be set with digital output terminal "zero current detection". When the drive output current is less than the value set by C1-15 and its lasting time attains the value of C1-16, terminal "zero current detection" outputs ON signal. See Fig. 6-24:




Fig. 6-24

## Group C2 Analog and Pulse Input

C2-00	Analog input ourse	Range: 0000~0333	Factory default:
02-00	Analog input curve	Range. 0000~0333	0210

Curves of analog input AI1, AI2 and AI3 are selected by this parameter.

- ◆ Ones place: Al1 input curve
- 0: Curve 1 (2 points)
  Defined by C2-01~C2-04.
- 1: Curve 2 (4 points)
  Defined by C2-05~C2-12.
- 2: curve 3 (4 points)
  Defined by C2-13~C2-20.
- 3: Curve 2 and curve 3 switchover

Curve 2 and curve 3 selection can be switched via terminal "analog input curve switchover". When this terminal is deactivated, curve 2 takes effect, while when this terminal is activated, curve 3 will work.

- Tens place: Al2 input curve
   Same as specification of Al1.
- Hundreds place: Al3 input curve Same as specification of Al1.
- ◆ Thousands place: reserved

C2-01	Curve 1 maximum input	Range: curve 1 minimum input ~110.0%	Factory default: 100.0%
(22-02	Corresponding set value of curve 1 maximum input	Range: -100.0%~100.0%	Factory default: 100.0%
C2-03	Curve 1 minimum input	, and the second	Factory default: 0.0%
(:)-()4	Corresponding set value of curve 1 minimum input	IRange: -100 0%~100 0%	Factory default: 0.0%

Curve 1 is defined by above-noted 4 parameters. Input values C2-01 and C2-03:

Al1~Al2 are 0~10V or 0~20mA programmable by jumper on control board.

If 0~10V is selected: 0V corresponds to 0%, while 10V corresponds to 100%.

If 0~20mA is selected: 0mA corresponds to 0%, while 20mA corresponds to 100%.

Al3 only supports -10V~10V input; for Al3, -10V corresponds to -100%, while 10V corresponds to 100%.

Corresponding set values C2-02 and C2-04:

When the corresponding set value is frequency: 100% is the maximum frequency, while -100%

is the maximum negative frequency.

When the corresponding set value is current: 100% means 2 times the rated current of drive while "less than or equal to 0%" corresponds to zero current.

When corresponding set value is torque: 100% means 2 times the rated torque, while -100% means negative "2 times the rated torque".

When the corresponding set value is output voltage (e.g. the voltage setting in case of V/f separated pattern): 100% corresponds to rated voltage of motor. "less than or equal to 0%" corresponds to 0V voltage.

## Curve diagram is shown as below:





Fig. 6-25

Fia. 6-26




C2-05	Curve 2 maximum input	Range: input of curve 2 inflection point A~110.0%	Factory default: 100.0%
C2-06	Corresponding set value of curve 2 maximum input	Range: -100.0%~100.0%	Factory default: 100.0%
C2-07	Input of curve 2 inflection point A	Input of curve 2 inflection point B ~ curve 2 maximum input	Factory default: 0.0%
C2-08	Set value corresponding to input of curve 2 inflection point A	Range: -100.0%~100.0%	Factory default: 0.0%
C2-09	Input of curve 2 inflection point B	Range: curve 2 minimum input ~ input of curve 2 inflection point A	Factory default: 0.0%
C2-10	Set value corresponding to input of curve 2 inflection point B	Range: -100.0%~100.0%	Factory default: 0.0%
C2-11	Curve 2 minimum input	Range: -110.0%~ input of curve 2 inflection point B	Factory default: 0.0%
C2-12	Set value corresponding to curve 2 minimum input	Range: -100.0%~100.0%	Factory default: 0.0%

Description of input value of curve 2: Voltage input:

- 1) With regard to Al1 and the Al2, 0% corresponds to 0V or 0mA, while 100% corresponds to 10V or 20mA.
- 2) Regarding to Al3, -100% corresponds to -10V, while 100% corresponds to 10V.

Curve 2 is defined by C2-05~C2-12. The input of curve 2 and the definition of corresponding set value is the same as Al1. The difference is that curve 1 is a straight line while curve 2 is a broken line with two inflection points. Diagram of curve 2 is shown as below:



C2-13	Curve 3 maximum input	Range: input of curve 3 inflection point A~110.0%	Factory default: 100.0%
C2-14	Set value corresponding to curve 3 maximum input	Range: -100.0%~100.0%	Factory default: 100.0%
C2-15	Input of curve 3 inflection point A	Range: input of curve 3 inflection point B~ curve 3 maximum input	Factory default: 0.0%
C2-16	Set value corresponding to input of curve 3 inflection point A	Range: -100.0%~100.0%	Factory default: 0.0%
C2-17	Input of curve 3 inflection point B	Range: curve 3 minimum input~ input of curve 3 inflection point A	Factory default: 0.0%
C2-18	Set value corresponding to input of curve 3 inflection point B	Range: -100.0%~100.0%	Factory default: 0.0%
C2-19	Curve 3 minimum input	Range: -110.0%~ input of curve 3 inflection point B	Factory default: 0.0%
C2-20	Set value corresponding to curve 3 minimum input	Range: -100.0%~100.0%	Factory default: 0.0%

Curve 3 is defined by C2-13~C2-20. The usage of curve 3 is the same as that of curve 2.

C2-21	Al1 terminal filtering time	Range: 0.000s~10.000s	Factory default: 0.1s
C2-22	Al2 terminal filtering time	Range: 0.000s~10.000s	Factory default: 0.1
C2-23	AI3 terminal filtering time	Range: 0.000s~10.000s	Factory default: 0.1s

C2-21~C2-23 define the filtering time of analog input terminals Al1, Al2 and Al3. Long filtering time results in strong immunity from interference but slow response, while short filtering time brings rapid response but weak immunity from interference.

C2-24	DI maximum input	Range: C2-26~300.0kHz	Factory default: 50.0kHz
C2-25	Set value corresponding to DI maximum input	Range: -100.0%~100.0%	Factory default: 100.0%
C2-26	DI minimum input	Range: 0.0kHz~C2-24	Factory default: 0.0kHz
C2-27	Set value corresponding to DI minimum input	Range: -100.0%~100.0%	Factory default: 0.0%

When digital input terminal X7/DI receives pulse signal as frequency reference, the relation

between input pulse signal and set frequency is defined by curves set by C2-24~C2-27.

C2-24 and C2-26 represent the range of DI input pulse frequency, 50kHz at maximum.

C2-25 and C2-27 are the set values of frequency that corresponds to DI input pulse frequency: 100% corresponds to positive maximum frequency while -100% corresponds to negative maximum frequency.

#### ATTENTION:

When pulse input is selected as the frequency reference, X7/DI terminal shall be set to "pulse input" function (C0-07 is set to 24).

C2-28	DI filtering time	Range: 0.000s~1.000s	Factory default:
02-20	Di liitering time	Nange. 0.000s*1.000s	0.001s

Defines the filtering time of terminal X7/DI. Longer the filtering time is set, stronger the anti-noise capability is, but slower response time. Shorter the filtering time is set, quicker the response time will be, but weaker anti-noise capability.

C2-29	Analog switchover gain	Range: 0.0Hz~100.0%	Factory default:
02-23	Analog Switchover gain	Kange. 0.0112 100.070	100%

Used in conjunction with the "73: Analog signal gain switchover" terminal function. Refer to the description of analog signal gain switchover function.

# Group C3 Analog and Pulse Output

C3-00	AO1 output function	Range: 0~99	Factory default: 2
C3-01	AO2 output function	Range: 0~99	Factory default: 1
C3-02	Y2/DO output function (when used as DO)	Range: 0~99	Factory default: 0

AO1 and AO2 are analog output terminals. When used as high-speed pulse output DO, Y2/DO terminal's functions are set in C3-02.

Voltage output or current output of AO1 and AO2 can be selected through jumper switch S5 and S6. It is voltage output as shown in fig. 6-33



Fig. 6-33

Output range of DO pulse frequency is 0~C3-09 (maximum output pulse frequency).

The ranges of corresponding digital output of AO1, AO2 and DO are as shown in the table 6-16.

**Table 6-16** 

Parameter value	Function	Range
0	No output	No output
1	Set frequency	0~maximum frequency
2	Output frequency	0~maximum frequency
3	Output current	0~2 times the rated current of drive
4	Output torque	0~2 times the rated torque
5	Output voltage	0~2 times the rated voltage of motor
6	Output power	0~ 2 times the rated power
7	Bus voltage	0~1000V
8	Torque command	0~2 times the rated torque
9	Torque current	0~2 times the rated current of motor
10	Magnetic flux current	0~2 times the rated current of motor
11	Al1	0~10V / 0~20mA
12	Al2	0~10V / 0~20mA
13	Al3	-10V~10V
14	Reserved	Reserved
15	DI	0~50kHz
16	Communication input percentage	0~65535
17	Output frequency before compensation	0~maximum frequency
18	Output current (relative to motor rated current)	0~2 times rated output current of the motor
19	Output torque (direction hinted)	-2 times rated torque ~ 2 times rated torque
20	Set torque (direction hinted)	-2 times rated torque ~ 2 times rated torque

C3-03	AO1 offset	Range: -100.0%~100.0%	Factory default: 0.0%
C3-04	AO1 gain	Range: -2.000~2.000	Factory default: 1.000

When users need to change AO1 measuring range or correct the meter error, it can be realized by setting of C3-03 and C3-04. When using factory default set: 0~10V (or 0~20mA) of AO1 corresponds to "0~maximun". See table 6-16 for details. By expressing standard output of AO1 as x, the adjusted AO1 output as y, the gain as k, and the offset as b (100% of offset corresponds to 10V or 20mA), there is the equation: y=kx+b

## Example:

Set C3-00 to 2: output frequency. Standard AO1 output: AO1 outputs 0V when output frequency is 0, and outputs 10V when output frequency is maximum frequency. If AO1 is requested to output 2V when output frequency is 0Hz, and to output 8V when output frequency is the maximum frequency.

There is:  $2=k\times0+b$ ;  $8=k\times10+b$ . Through these two equations, we obtain: k=0.6, b=2V, i.e. C3-03 is set to 20.0% while C3-04 is set to 0.600.

Additional examples are shown as below:




Fig. 6-34 Influence of AO1 gain against output




Fig. 6-35 Influence of AO1 offset against output

C3-05 AO1 filtering time	Range: 0.0s~10.0s	Factory default: 0.0s
--------------------------	-------------------	-----------------------

Defines output filtering time of AO1 terminal.

C3-06	AO2 offset	Range: -100.0%~100.0%	Factory default: 0.0%
C3-07	AO2 gain	Range: -2.000~2.000	Factory default: 1.000

C3-08	AO2 filtering time	Range: 0.0s~10.0s	Factory default: 0.0s
-------	--------------------	-------------------	-----------------------

Adjustment method of AO2 output curve is the same as AO1.

C3-09	DO maximum output pulse	Dongo, 0.4kHz, F0.0kHz	Factory default:
C3-09	frequency	Range: 0.1kHz~50.0kHz	50.0kHz

This parameter sets the maximum output frequency when Y2/DO terminal is selected as highspeed pulse output.

C3-10	DO output center point	Range: 0~2	Factory default: 0
-------	------------------------	------------	--------------------

There are three different center point modes when Y2/DO terminal is selected as high-speed pulse output.

## 0: No center point.

DO pulse frequency output range 0~(C3-09) corresponds to "0~maximum", as shown in Fig. 6-36:






Fig. 6-36

1: Center point is (C3-09)/2, and the corresponding parameter value is positive when frequency is higher than center point. The value that corresponds to DO pulse frequency at center point is 0. DO pulse frequency C3-09 corresponds to the positive maximum value, while DO pulse frequency 0Hz corresponds to the negative maximum value. See Fig. 6-37:



Fia. 6-37

2: Center point is (C3-09)/2, and the corresponding parameter value is positive when frequency is lower than center point. The value that corresponds to DO pulse frequency at center point is 0. When set to 0, DO pulse corresponds to the positive maximum value, while when set to C3-09, DO pulse frequency corresponds to the negative maximum value. See Fig. 6-38:



Maximum negative corresponding value

Fig. 6-38

C3-11	DO output filtering time	Range: 0.00s~10.00s	Factory default: 0.00s
-------	--------------------------	---------------------	------------------------

Sets the filtering time of DO high-speed pulse output. Filtering can change the change rate of output pulse frequency. The longer the filtering time is, the lower the change rate of output pulse frequency would be.

# **Group C4** Automatic Correction of Analog Input

Parameter Group C4 is used to perform automatic correction of analog input channels, obtaining the gain and offset of corresponding channel automatically. They can automatically modify the measuring range of corresponding channel or correct meter error.

0: No correction

No correction to any analog input.

1: Correct AI1

Automatically correct analog AI1.

2: Correct AI2

Automatically correct analog Al2.

3: Correct AI3

Automatically correct analog Al3.

C4-01	Sampling value of Al1 calibration point 1	Range: 0.00V~10.00V	Factory default: 1.00V
C4-02	Input value of AI1 calibration point 1	Range: 0.00V~10.00V	Factory default: 1.00V
C4-03	Sampling value of Al1 calibration point 2	Range: 0.00V~10.00V	Factory default: 9.00V
C4-04	Input value of AI1 calibration point 2	Range: 0.00V~10.00V	Factory default: 9.00V
C4-05	Sampling value of Al2 calibration point 1	Range: 0.00V~10.00V	Factory default: 1.00V
C4-06	Input value of Al2 calibration point 1	Range: 0.00V~10.00V	Factory default: 1.00V
C4-07	Sampling value of Al2 calibration point 2	Range: 0.00V~10.00V	Factory default: 9.00V
C4-08	Input value of AI2 calibration point 2	Range: 0.00V~10.00V	Factory default: 9.00V
C4-09	Sampling value of Al3 calibration point 1	Range: -10.00V~10.00V	Factory default: 1.00V
C4-10	Input value of Al3 calibration point 1	Range: -10.00V~10.00V	Factory default: 1.00V
C4-11	Sampling value of Al3 calibration point 2	Range: -10.00V~10.00V	Factory default: 9.00V
C4-12	Input value of Al3 calibration point 2	Range: -10.00V~10.00V	Factory default: 9.00V

Take AI2 for example, automatic correction is as follows

- Set C4-00 to 2 in stop status and press ENT key to confirm. In this way, Al2 is selected as correction channel.
- 2) Input a relatively low analog voltage (e.g. about 1V) via Al2 terminal, and input the theoretical value of this analog voltage by C4-06 after the stabilization of this voltage input, and then press ENT key to confirm.
- 3) Input a relatively high analog voltage (e.g. about 9V) via AI2 terminal, and input the theoretical value of this analog voltage by C4-08 after the stabilization of this voltage input, and then press ENT key to confirm.
- 4) Upon the successful correction, C4-00 parameter will be restored to zero.

## ATTENTION:

Set the theoretical value or actual value of analog voltage in C4-06 and C4-08. This value can be either the set value of analog output of peripheral equipment, or the actual voltage value of analog input measured by a multimeter or other instruments. C4-05 and C4-07 are the sampling values of analog input voltage. These values are for reference only. Do not write the value of C4-05 directly into C4-06, or write the value of C4-07 directly into C4-08.

## **Group d Motor and Control Parameters**

## Group d0 Parameters of Motor 1

When motor 1 is selected as current load motor, please set motor parameters in Group d0.

d0-00	Type of motor 1	Range: 0~2	Factory default: 1
-------	-----------------	------------	--------------------

- 0: Ordinary motor
- 1: Variable frequency motor
- 2: Synchronous motor

The major difference between ordinary motor and variable frequency motor lies in the handling of motor overload protection. Under low speed run, ordinary motor has poor heat dissipation, so motor overload protection shall be derated at low speed. Since fan-based heat dissipation of variable frequency motor is not affected by motor speed, low-speed overload protection is not necessarily derated. Therefore, please set d0-00 to 0 when driving ordinary asynchronous motor so as to protect the motor reliably.

d0-01	Power rating of motor 1	Range: 0.4kW~6553.5kW	Factory default:
40 01		rango. o.+kvv oooo.okvv	model dependent
d0-02	Rated voltage of motor 1	Range: 0V~480V	Factory default: 380V
d0-03	Rated current of motor 1	I Range: 0 0A~6553 5A	Factory default:
u0-03			model dependent
d0-04	Rated frequency of motor 1	Range:0.00Hz~maximum	Factory default:
u0-04		frequency	50.00Hz

d0-05	Pole number of motor 1	Range: 1~80	Factory default: 4
d0-06	Rated speed of motor 1	Danger O. GEE2E r/min	Factory default:
uu-uo	Rated speed of motor 1	Range: 0~65535 r/min	model dependent

No matter it is synchronous motor or asynchronous motor, above-noted motor parameters must be set correctly according to motor nameplate. Please select the motor that suits the power rating of the drive, or the control performance of the drive will drop obviously.

d0-07	Stator resistance R1 of asynchronous motor 1	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d0-08	Leakage inductance L1 of asynchronous motor 1	Range: 0.1mH~6553.5mH	Factory default: model dependent
d0-09	Rotor resistance R2 of asynchronous motor 1	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d0-10	Mutual inductance L2 of asynchronous motor 1	Range: 0.1mH~6553.5mH	Factory default: model dependent
d0-11	No-load current of asynchronous motor 1	Range: 0.0A~6553.5A	Factory default: model dependent
d0-12	Flux weakening coeff 1 of asynchronous motor 1	Range: 0.0000~1.0000	Factory default: model dependent
d0-13	Flux weakening coeff 2 of asynchronous motor 1	Range: 0.0000~1.0000	Factory default: model dependent
d0-14	Flux weakening coeff 3 of asynchronous motor 1	Range: 0.0000~1.0000	Factory default: model dependent

The drive needs above-noted parameters to control its matching motor. If the parameters of motor 1 is known, just input the actual value into d0-07~d0-14 correspondingly.

After the autotune of motor 1, above-noted parameters are automatically updated and saved. Parameters d0-07~d0-09 are obtained through static tune, and parameters d0-07~d0-14 are obtained through rotary tune. If above-noted parameters are unknown and it is not allowed to perform motor tune, please input the parameters manually by referring to parameters of kindred motors.

If motor power rating d0-01 is changed, d0-02~d0-14 will be automatically restored to default setting of the standard motor.

d0-15	Stator resistance of synch motor 1	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d0-16	Direct-axis inductance of synch motor 1	Range: 0.1mH~6553.5mH	Factory default: model dependent
d0-17	Quadrature axis inductance of synch motor 1	Range: 0.1mH~6553.5mH	Factory default: model dependent
d0-18	Counter-EMF constant of synch motor 1	Range: 0~1000	Factory default: model dependent

When d0-00 is set to 2, it is necessary to use above parameters. If the parameters of synchronous motor 1 are known, please input the corresponding alleged values into d0-15~d0-18.

Above-noted parameters are automatically updated and saved after motor 1 tune. If d0-01 is changed, d0-02~d0-06 and d0-15~d0-18 are automatically restored to default settings of the standard motor.

Sets the output current of tune of synchronous motor 1. 100% corresponds to rated current of motor.

d0-20 Initial angle of synch motor 1	Range: 0°~360.0°	Factory default: 0.0°
--------------------------------------	------------------	--------------------------

This is the initial angle of encoder installed in synchronous motor 1. It will be automatically updated and saved after autotune.

d0-21	Z-pulse initial angle of synch motor 1	0000~FFFF	Factory default:
	synch motor 1		0000

This is the Z-pulse initial angle of encoder installed in synchronous motor 1.

d0-22	Tune of motor 1	Range: 0~4	Factory default: 0

Parameters for controlling the motor performance are automatically obtained through motor tune, and the result will be automatically saved upon the completion of motor tune.

Be sure to correctly enter motor 1 parameters d0-01~d0-06 before motor tune. And if it's a synchronous motor, d0-19 should also be set to an appropriate value.

- 0: No motor tune
- 1: Static tune of async motor

Static tune applies to the cases where rotary tune cannot be favorably performed due to the fact that it is impossible to disengage the motor from its load. After d0-22 is set to 1 and confirmed, press the key RUN to start static tune. D0-22 will be restored to 0 upon the successful completion of tune. In this way, parameters d0-07~d0-09 are obtained.

## 2: Rotary autotune of async motor

To perform rotary tune, it is essential to disengage the motor from its load. Motor tune is prohibited when motor is loaded. After d0-22 is set to 2 and confirmed, press RUN to perform static tune, upon the completion of which, the motor would accelerate to a fixed frequency in the set ramp-up time, maintaining a period of time, and then stop by ramp down according to the set ramp down time. In this way, motor tune comes to an end, and d0-22 will be restored to 0. Parameters d0-07~d0-14 have been obtained after the successful completion of rotary tune.

To perform rotary motor tune, please set appropriate ramp-up and ramp-down time (i.e. Accel/Decel time. If overcurrent or overvoltage fault occurs during motor tune, please prolong Accel/Decel time accordingly.

## 3: Static tune of synch motor

To perform static motor tune, it is essential to disengage the motor from its load. Motor tune is prohibited when motor is loaded. Set d0-22 to 3, then press RUN to start the static tune of synchronous motor. Upon the completion, d0-22 is restored to 0

## 4: Rotary tune of synch motor

To perform rotary motor tune, it is essential to disengage the motor from its load. Motor tune is prohibited when motor is loaded. Set d0-22 to 4, then press RUN to start the rotary tune of synchronous motor. Upon the completion, d0-22 is restored to 0; at this point, the parameters d0-15~d0-18 and d0-20 are obtained.

It is recommended synchronous motor tune be performed twice. The tune is deemed successful if the difference of d0-20 between the two autotune is less than 3.0°. If the two values of d0-20 differ greatly, please find out the problem of encoder and after that perform motor tune again.

When synchronous motor tune is selected, please set appropriate accel/decel time. Once overcurrent or overvoltage fault occurs during motor tune, please extend the accel/decel time duly.

### ATTENTION:

Please make sure the motor is in a stationary status before motor tune, otherwise, motor tune cannot be performed normally. Control panel displays "TUNE", and RUN indicator light is ON during motor tune. RUN indicator light is OFF upon the completion of motor tune.

Once the motor tune fails, the fault code "tUN" shall be displayed.

d0-23	Overload protection of motor 1	Range: 0~2	Factory default: 1
-------	--------------------------------	------------	--------------------

Determines the overload protection mode of motor 1.

### 0: No protection

Once 0 is selected, it would be impossible to perform motor overload protection. Please take care.

### 1: Judged by motor current

Provide overload protection judged from output current and its lasting time. Overload protection detection time is set by d0-24.

### 2: Judged by temperature transducer

Input motor temperature sensor signal through analog input channel set by d0-25. The signal voltage is compared with the protection threshold set by d0-26. If it is higher than protection threshold, motor overheat fault "oH2" could be displayed.

40.24	Overload protection	Danger 0 1min, 15 0min	Factory default:
d0-24	detection time of motor 1	Range: 0.1min~15.0min	5.0min

When d0-23 is set to "1: judged by motor current", overload protection time is determined by this parameter on the basis of the run current being 150% of motor rated current. An alarm of motor overload fault "oL2" shall be displayed once the lasting time exceeds this parameter value. Protection time when the run current is other value is automatically calculated according to inverse time lag characteristic curve. See Fig. 6-39.




Fig. 6-39 Motor protection curve for ordinary motor running at 50Hz

Overload protection is performed for variable frequency asynchronous motor or synchronous motor according to the curve as shown in Fig. 6-39 at either high or low rotation speed. Due to the fact that fan-based heat dissipation of ordinary motors becomes poor at low speed, the protection is derated at low speed.

**Example:** when d0-24 is set to 10.0 minutes, and the motor is running at 10Hz input, motor overload fault "oL2" shall be displayed when the run current is 150% of the motor rated current with lasting time 4 minutes. See Fig. 6-40.




Fig. 6-40 Overload protection curve for ordinary motor running at 10Hz

d0-25	Temperature transducer signal input of motor 1	Range: 0~2	Factory default: 1
-------	------------------------------------------------	------------	--------------------

0: AI1

1: AI2

2: AI3

When d0-23 is set to "2: judged by temperature transducer", the analog signal input channel of motor 1 temperature transducer is set by this parameter. The drive compares the signal input value via this analog channel with the thermal protection threshold set by d0-26. If it is bigger than the threshold, the drive will immediately give an alarm of motor overheat fault "oH2". Protection through temperature sensor has no characteristic of inverse time lag curve.

#### ATTENTION:

Only Al2 channel supports temperature sensor input so far, when using this function, S3 needs to be jumped to "V" and S4 to "TMP".

d0-26	Thermal protection threshold of	Range: 0.00V~10.00V	Factory default:
u0-20	motor 1 temperature transducer	Nange. 0.00 V 10.00 V	10.00V

This parameter works together with d0-25, and this parameter value, corresponding to motor 1 overheat protection point, needs to be calculated in accordance with the type of temperature sensor. Please consult GTAKE technical service engineer for this parameter value setting. When the input analog signal through the channel selected by d0-25 is bigger than this threshold, the drive will immediately trip with motor overheat fault "oH2".

d0-27	SW rotary speed track Kp	Range: 0.00∼655.35	Factory default: 0.00
d0-28	SW rotary speed track Ki	Range: 0.00∼655.35	Factory default: 2.00

Set as factory default.

# Group d1 V/f Control Parameters of Motor 1

Set control parameters in Group d1 when motor 1 is selected as current load motor on which V/f control is performed.

d1-00 V/f curve setting	Range: 0~6	Factory default: 0
-------------------------	------------	--------------------

Set the relation between output voltage and output frequency of the drive when motor 1 is under V/f control.

#### 0: Linear V/f

Applies to general constant-torque load. When drive output frequency is 0, output voltage will be 0, while when output frequency is rated frequency of motor, the output voltage would be rated voltage of motor.

## 1: Broken line V/f (determined by d1-01~d1-08)

Applies to spin drier, centrifuge, industrial washing machine and other special loads. When drive output frequency is 0, output voltage will be 0, while when output frequency is rated frequency of motor, the output voltage would be rated voltage of motor. What is different is this pattern can set 4 inflection points by d1-01~d1-08. See Fig. 6-41.




Fig. 6-41 User-defined various segments V/f curve

V0, V1, V2, V3 and f0, f1, f2 and f3 in the figure are voltage values and frequency values set by parameters d1-01~d1-08.

- 2: 1.2<sup>nd</sup> power
- 3: 1.4th power
- 4: 1.6<sup>th</sup> power
- 5: 1.8th power
- 6: 2.0th power

Parameter values 2~6 apply to torque-dropped loads such as fans and water pumps. See Fig. 6-42.




Fig. 6-42 1.2~2.0 power V/f curve

d1-01	V/f frequency value f3	Range: 0.00Hz~rated frequency of motor	Factory default: 50.00Hz
d1-02	V/f voltage value V3	Range: 0.0%~100.0%	Factory default: 100.0%
d1-03	V/f frequency value f2	Range: d1-05~d1-01	Factory default: 0.00Hz
d1-04	V/f voltage value V2	Range: 0.0%~100.0%	Factory default: 0.0%
d1-05	V/f frequency value f1	Range: d1-07~d1-03	Factory default: 0.00Hz
d1-06	V/f voltage value V1	Range: 0.0%~100.0%	Factory default: 0.0%
d1-07	V/f frequency value f0	Range: 0.00Hz~d1-05	Factory default: 0.00Hz
d1-08	V/f voltage value V0	Range: 0.0%~100.0%	Factory default: 0.0%

d1-01~d1-08 is used for broken line V/f mode. Voltage value 100% corresponds to rated voltage of motor. Please suitably set the values of frequency and voltage at knees on the basis of characteristics of motor and load. Improper setting may rise output current even burn the motor.

d1-09 Torque boost Range: 0.0%~30.0% Factory default 0.0%
-----------------------------------------------------------

Under V/f pattern, output voltage at low frequency can be compensated by this parameter,

improving the torque output. 0.0% corresponds to automatic torque boost, and drive output voltage is automatically compensated via detection of load current. Automatic torque boost is valid only for linear V/f pattern.

100% of torque boost corresponds to rated voltage of motor. A non-zero value means the output voltage rises on the basis of V/f curve and this takes effect at parameter values 0~6 of d1-00. It is suggested this parameter value be gradually increased from zero until the start requirement is met. Boost value is not suggested to be set to a relatively big one, as it is likely to bring about a bigger drive current and higher motor temperature.

Torque boost diagram is shown in Fig. 6-43:




Fig. 6-43

d1-10	Slip compensation gain	Range: 0.0%~400.0%	Factory default:
u1-10	One compensation gain	Range: 0.070 400.070	100.0%

Used under V/f control. When the motor is driving a driven load, motor speed drops with the increase of load. When the motor is driving a power generating load, motor speed will increase with the increase of load. Appropriate slip compensation gain can maintain constant motor speed when the motor load is changing.

To ensure the performance of slip compensation gain, setting motor rated speed d0-06 is essential. The difference between d0-06 and the motor run speed without load is the rated slip. Through real-time detection of motor load, slip compensation automatically adjusts the drive output frequency on the basis of rated slip and motor load, reducing the impact of changing load on motor speed.

Gain adjustment method: please make the adjustment around 100%. When motor is driving driven load: if motor speed is relatively lower, the gain should be appropriately increased; if motor speed is relatively higher, reduce the gain appropriately. When motor is driving a power

generating load: if motor speed is relatively lower, the gain should be decreased; if motor speed is relatively higher, increase the gain appropriately.

Diagram of slip compensation gain is shown as Fig. 6-44 and 6-45.




Fig. 6-44 Diagram of slip compensation on driven load




Fig. 6-45 Diagram of slip compensation on power generating load

d1-11	Droop control	Range: 0.00Hz~10.00Hz	Factory default:
u1-11	Droop control	Range: 0.00H2~10.00H2	0.00Hz

In case several drives drive one load, different drives may bear different proportion of the load. Through the setting of this parameter, the uniform load distribution on these drives could be attained

The drive takes real-time detection of its load. Output frequency is automatically dropped

according to the load and this parameter value, reducing itself borne load proportion. Parameter value of d1-11 corresponds to drop frequency with rated load.

d1-12	Current limitation mode	Range: 0~5	Factory default: 1
-------	-------------------------	------------	--------------------

- 0: Disabled
- 1: Set by d1-13
- 2: Set by AI1
- 3: Set by AI2
- 4: Set by AI3

Drive output current is limited by analog input in the range of "0~200% x rated current of drive".

5: Set by X7/DI

Drive output current is limited by X6/DI pulse input in the range of "0~200% x rated current of drive".

When a non-zero value is set by d1-12, the current limitation is enabled. When output current rises dramatically because of sharp change of load, instant adjustment of output frequency will keep the output frequency below the set limitation. When the load is reduced, output frequency will recover promptly. If the setting speed or motor load change dramatically, this function can effectively reduce over-current fault.

When current limitation is enabled, the output frequency at constant speed may change at times and the Accel/Decel time may probably be automatically prolonged. Therefore, this function should not be used where output frequency or Accel/Decel time is not allowed to change.

41 12	Digital setting of current	Banga: 20.0% - 200.0%	Factory default:
d1-13 limit value	limit value	Range: 20.0%~200.0%	160.0%

When d1-12 is set to "1: set by d1-13", the drive keeps output current less than this current limit value through instantaneous adjustment of output frequency. 100% current limit value corresponds to rated current of the drive. If this parameter value is set to a relatively big one, it will increase the chances of over-current. If this parameter value is set to a relatively small one, it will affect the loaded capability of the drive.

d1-14	Current limit coeff on flux	Dance: 0.001, 1.000	Factory default:
	weakening	Range: 0.001~1.000	0.500

When the drive runs at the frequency higher than rated frequency of motor, Accel/Decel characteristic and output torque can be effectively improved by setting this parameter appropriately.

d1-15	Energy saving percentage	Range: 0%~40.0%	Factory default: 0.0%
-------	--------------------------	-----------------	-----------------------

During no-load or light-load application, load current is detected so as to appropriately reduce output voltage, reducing the copper loss and iron loss of motor with the purpose of energy saving. The larger the energy-saving percentage is, the better the energy-saving effect will be, but the response will be slower. This parameter is applicable to loads such as fan and pump or light-load for a long time. Where rapid change is required, this parameter is suggested to be default set 0.0%.

d1-16	V/f oscillation suppression gain 1	Range: 0~3000	Factory default: 66
d1-17	V/f oscillation suppression gain 2	Range: 0~3000	Factory default: 0

Under V/f control, speed and current oscillation is likely to occur due to load vibration, and may lead to system failure even over current protection. This is particularly obvious during no-load or light-load applications. The appropriate setting of parameter values of d1-16 and d1-17 would effectively suppress speed and current oscillation. In many case it is not necessary to modify the default setting. Please make progressive change around default setting, since excessive setting will influence V/f control performance.

## Group d2 Vector Control Parameters of Motor 1

Set control parameters in Group d2 when motor 1 is selected as current load motor on which sensor-less vector control or closed-loop vector control is performed.

d2-00 Speed/torque control Range: 0~1 Factory
-----------------------------------------------

Under sensor-less vector control 2 or closed-loop vector control support torque control pattern, speed control and torque control can be programmed by this parameter.

Added to this, the switchover between speed control and torque control can also be realized by digital input terminal "speed/torque control switchover". The relation of the switchover via terminal and parameter is shown in Table 6-17:

_			_		_
Ta	h	Δ	Æ.	-1	7

d2-00	Speed/torque control switch terminal	Control mode
0	OFF	Speed control
0	ON	Torque control
1	OFF	Torque control
1	ON	Speed control

Under speed control, output torque of motor will match load automatically. In order to avoid overcurrent fault caused by excessive output torque, it is necessary to set appropriate torque limit value and keep output torque of motor within this limit. Please refer to the specification of d2-12~d2-16 for torque limit.

Under torque control, torque can be set by different sources by d2-19. Under torque control, motor speed is determined by the difference between set torque and load torque. When the set torque is bigger than load torque, motor will be accelerated continuously. When the set torque is smaller than load torque, motor will be decelerated continuously. When the set torque is matching load torque well, the speed of motor will be maintained. Therefore, it is necessary to set limit value of forward or reverse speed during torque control so as to prevent over-run caused by continuous acceleration of motor. Please set the speed limit in d2-21~d2-24 under torque control.

## **ATTENTION:**

Jog mode will run in the manner of speed control, and torque control is disabled.


d2-01	ASR high-speed proportional gain Kp1	Range: 0.0~20.0	Factory default: 2.0
d2-02	ASR high-speed integration time Ti1	Range: 0.000s~8.000s	Factory default: 0.200
d2-03	ASR low-speed proportional gain Kp2	Range: 0.0~20.0	Factory default: 2.0
d2-04	ASR low-speed integration time Ti2	Range: 0.000s~8.000s	Factory default: 0.200
d2-05	ASR switching frequency 1	Range: 0.00Hz~d2-06	Factory default: 5.00Hz
d2-06	ASR switching frequency 2	Range: d2-05~upper limiting frequency	Factory default: 10.00Hz

Under sensor-less vector control (SVC) or closed-loop vector control, motor speed is kept at set value by automatic speed regulator (ASR). ASR parameters should be set in d2-01~d2-06.

The proportional gain Kp and integration time Ti of ASR can be set through d2-01~d2-04 so as to change the speed response characteristic under SVC. Increment of proportional gain Kp can bring in fast response of the system. However, bigger Kp value will bring about larger system oscillation

Reduction of integration time Ti can also quicken response time, but small Ti value will result in big system overshooting and may easily bring about oscillation. Principle for adjustment of proportional gain Kp and integration time Ti: proportional gain Kp is usually adjusted prior, maximizing Kp at the premise of ensuring the system is subject to no oscillation, and then adjust integration time Ti to provide the system with both instant response characteristic and less overshooting.

D2-01~d2-02 are the proportional gain and integration time of the drive at high speed. D2-03~d2-04 are the proportional gain and integration time of the drive at low speed. Distinction between high speed and low speed is determined by d2-05~d2-06. The diagram is as shown in Fig. 6-46.



ASR parameters are normally adjusted in the following order: select appropriate switching frequency. Adjust proportional gain d2 -01 and integration time d2-02 at high speed, ensuring the system has no oscillation and meets the requirements of dynamic response characteristics. Adjust proportional gain d2-03 and integration time d2-04 at low speed, ensuring there is no oscillation at low speed and requirements of dynamic response characteristics are met.

## ATTENTION:

Inappropriate parameters of Kp, Ti may bring about overcurrent or overvoltage faults. Usually fine adjustment should be performed close to factory default parameter.

d2-07	ASR input filtering time	Range: 0.0ms~500.0ms	Factory default: 0.3ms
-------	--------------------------	----------------------	------------------------

Sets the input filtering time of ASR. No need to modify its default setting if there is no special requirement.

d	12-08	ASR output filtering time	Range: 0.0ms~500.0ms	Factory default: 0.3ms
---	-------	---------------------------	----------------------	------------------------

Sets the output filtering time of ASR. No need to modify its default setting if there is no special requirement.

d2-09	D-axis ACR proportion coefficient Kp	Range: 0.000~8.000	Factory default: 1.000
d2-10	D-axis ACR integration coefficient Ki	Range: 0.000~8.000	Factory default: 1.000

These two parameters determine the characteristics of automatic current regulator (ACR) under SVC or closed-loop VC pattern. Increment of proportion coefficient and/or integration coefficient can shorten torque response time. Reduction of proportion coefficient and/or integration coefficient can increase the stability of the system. Inappropriate setting may bring about system oscillation. Factory default is not needed to be changed in most cases.

d2-11	Pre-excitation time	Range: 0.000s~5.000s	Factory default: 0.200s
-------	---------------------	----------------------	-------------------------

Applies to asynchronous motor. To attain quick start, it is necessary to perform pre-excitation before the running of motor, and the pre-excitation time is set by this parameter. Properly establish stable flux prior and then ramp up quickly. The set value of 0.000s means "no pre-excitation" and ramp up at the moment of the receipt of run command. Pre-excitation time is not included in Accel/Decel time. Factory default is suggested to maintain in most cases.

d2-12	Driven torque restriction source	Range: 0~5	Factory default: 0
-------	----------------------------------	------------	--------------------

Under the pattern of SVC or closed-loop VC speed control, and when the motor is driving a driven load, it usually needs to restrict the output torque of the motor. This parameter sets the limitation command source.

### 0: d2-14 digital setting

Restricts output torque through digital set parameter d2-14. 100% corresponds to motor rated torque.

- 1: AI1
- 2: AI2
- 3· AI3

Limits the torque through analog input. The limited range is "0~200%r x rated torque".

4: X7/DI pulse input

Restrict the torque through X7/DI pulse input. The limited range is "0~200%r x rated torque".

5: Communication

A superior device sets the limitation value of the output torque through standard RS485

communication interface at the drive. Refer to parameter Group H0 and appendix for details of communication.

d2-13	Braking torque restriction source	Range: 0~5	Factory default: 0
-------	-----------------------------------	------------	--------------------

Under the pattern of SVC or closed-loop VC speed control, and when the motor is driving a power generating load, it needs to restrict the output brake torque of the motor. This parameter sets the limitation command source.

## 0: d2-15 digital setting

Restricts output brake torque through digital set parameter d2-15. 100% corresponds to rated torque of the motor.

- 1: AI1
- 2: AI2
- 3: AI3

Limits the torque through analog input. The limited range is "0~200%r x rated torque".

## 4: X7/DI pulse input

Restricts the torque through X7/DI pulse input. The limited range is "0~200%r x rated torque".

#### 5: Communication

A superior device sets the limitation value of the output torque through standard RS485 communication interface at the drive. Refer to parameter Group H0 and appendix for details of communication.

torque innit value	d2-14	Digital setting of driven torque limit value	Range: 0.0%~200.0%	Factory default: 180.0%
--------------------	-------	----------------------------------------------	--------------------	-------------------------

When d2-12 is set to 0, this parameter value limits the maximum output driven torque. 100% corresponds to rated torque of the motor.

When d2-13 is set to 0, this parameter value limits the maximum output brake torque. 100% corresponds to rated torque of the motor.

	d2-16	Torque limit coefficient in	Danger 0.00/ - 100.00/	Factory default:
l	02-16	flux weakening	Range: 0.0%~100.0%	50.0%

Under the pattern of SVC or closed-loop VC speed control, and when the drive is running at frequency higher than rated frequency (flux weakening zone), appropriate torque limit coefficient can effectively improve the performance of output torque and Accel/Decel characteristics.

d2-17 Driven sl	ip compensation gain	Range: 10.0%~300.0%	Factory default: 100.0%
-----------------	----------------------	---------------------	-------------------------

Under SVC or closed-loop VC pattern, adjustment of this parameter value can improve the speed accuracy when driving driven load. If the load is becoming heavier and the motor speed is relatively lower, set a bigger value, while the motor speed is relatively higher, set a smaller value.

d2-18	Brake slip compensation gain	Range: 10.0%~300.0%	Factory default: 100.0%
-------	------------------------------	---------------------	-------------------------

Under SVC or closed-loop VC pattern, adjustment of this parameter value can improve the speed accuracy when driving power generating load. If the load is becoming heavier and the motor speed is relatively higher, set a bigger value, while the motor speed is relatively lower, set a smaller value.

d2-19	Torque reference source	Range: 0~5	Factory default: 0
-------	-------------------------	------------	--------------------

In torque control of vector control pattern, the torque reference source can be set by this parameter.

- 0: Set by d2-20
  - Set the torque by d2-20. 100% corresponds to rated torque of motor.
- 1: Analog input AI1
- 2: Analog input Al2
- 3: Analog input AI3

Set the torque by analog input. Torque Setting range: 0~200% of rated torque.

- 4: X7/DI pulse input
  - Set the torque by X7/DI pulse input. Torque reference range: 0~200% of rated torque.
- 5: Communication

Upper computer/device sets the torque by communication. Please refer to Group H0 and appendix notes for further information of communication.

d2-20	Digital setting of torque	Range: -200.0%~200.0%	Factory default: 0.0%
-------	---------------------------	-----------------------	-----------------------

When d2-19 is set to 0, the value of this parameter decides the torque. 100% corresponds to rated torque of motor.

d2-21	Forward speed limitation source under torque control	Range: 0~5	Factory default: 0
-------	------------------------------------------------------	------------	--------------------

Under torque control, if the set torque is bigger than load torque, motor speed will increase continuously. To avoid over-run, maximum speed should be set to keep motor speed in limited range. This parameter sets the source for limiting the maximum speed of forward run.

0: Set by d2-23

Limited value of maximum forward speed is set by d2-23.

1: Analog input AI1

- 2: Analog input Al2
- 3: Analog input AI3

Limited value of maximum forward speed is set by analog input.

4: X7/DI pulse input

Limited value of maximum forward speed is set through X7/DI pulse input.

5. Communication

Upper computer/device sets the limited value of maximum forward speed via inbuilt standard RS485 communication interface. Please refer to Group H0 and appendix notes for further information of communication

d2-22	Reverse speed limitation source under torque control	Range: 0~5	Factory default: 0
-------	------------------------------------------------------	------------	--------------------

Under torque control, if the set torque is bigger than load torque, motor speed will increase continuously. To avoid over-run, a maximum speed should be set to keep motor speed in the limited range. This parameter is to select the source of limiting the maximum speed of reverse running.

0: Set by d2-24

Limited value of maximum reverse speed is set by d2-24.

- 1: Analog input AI1
- 2: Analog input AI2
- 3: Analog input AI3

Limited value of maximum reverse speed is set by analog input.

4: X7/DI pulse input

Limited value of maximum reverse speed is set by X7/DI pulse input.

5: Communication

Upper computer/device sets the limited value of maximum reverse speed via inbuilt standard RS485 communication interface. Please refer to Group H0 and appendix notes for further information of communication.

d2-23	Forward speed limited value	Range: 0.00Hz~maximum	Factory default:
uz-23	under torque control	frequency	50.00Hz

When d2-21 is set to 0, the limited value of forward speed is set by this parameter.

d2-24	Reverse speed limited value	Range: 0.00Hz~maximum	Factory default:
uz-24	under torque control	frequency	50.00Hz

When d2-22 is set to 0, the limited value of reverse speed is set by this parameter...

d2-25	Set torque accel/decel time	Range: 0.00s~120.00s	Factory default: 0.10s
-------	-----------------------------	----------------------	---------------------------

In torque control mode, this parameter sets the time required for increasing the torque from 0 to rated torque or decreasing it from the rated to 0. That is to say, this parameter value defines

d2-26	Low-frequency torque switching frequency 1	Range: 0.0%~d2-06	Factory default: 0.00Hz
d2-27	Low-frequency torque switching frequency 2	Range: d2-05~upper limit frequency	Factory default: 10.00Hz
d2-28	Low-frequency torque	Range: 0.0%~200.0%	Factory default: 120.0%

This parameter is used for torque switching under low frequency, when d2-26=0, the function is invalid; when d2-26 $\neq$ 0, set different torques according to different frequencies. The function is only valid for synchronous motors.

d2-29	Q-axis ACR proportion coefficient Kp	Range: 0.000~8.000	Factory default: 1.000
d2-30	Q-axis ACR integration coefficient Ki	Range: 0.000~8.000	Factory default: 1.000

This parameter is used to set Q-axis automatic current regulator (ACR) parameter of vector control. Increment of proportion coefficient and/or integration coefficient can shorten torque response time. Reduction of proportion coefficient and/or integration coefficient can increase the stability of the system. Inappropriate setting may bring about system oscillation. Factory default is not needed to be changed in most cases.

# Group d3 Parameters of Motor 2

When motor 2 is selected as current loaded motor, set motor parameters in Group d3. The specification of Group d3 of motor 2 is the same with that of Group d0 of motor 1.

d3-00	Type of motor 2	Range: 0~2	Factory default: 0
d3-01	Power rating of motor 2	Range: 0.4kW~6553.5kW	Factory default: model dependent
d3-02	Rated voltage of motor 2	Range: 0V~480V	Factory default: 380V
d3-03	Rated current of motor 2	Range: 0.0A~6553.5A	Factory default: model dependent
d3-04	Rated frequency of motor 2	Range: 0.00Hz~ maximum frequency	Factory default: 50.00Hz
d3-05	Pole number of motor 2	Range: 0~80	Factory default: 4
d3-06	Rated speed of motor 2	Range: 0r/min ~65535r/min	Factory default: model dependent

d3-07	Stator resistance R1 of async motor 2	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d3-08	Leakage inductance L1 of async motor 2	Range: 0.1mH~6553.5mH	Factory default: model dependent
d3-09	Rotor resistance R2 of async motor 2	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d3-10	Mutual inductance L2 of asynchronous motor 2	Range: 0.1mH~6553.5mH	Factory default: model dependent
d3-11	No-load current of async motor 2	Range: 0.0A~6553.5A	Factory default: model dependent
d3-12	Flux weakening coeff 1 of async motor 2	Range: 0.0000~1.0000	Factory default: model dependent
d3-13	Flux weakening coeff 2 of async motor 2	Range: 0.0000~1.0000	Factory default: model dependent
d3-14	Flux weakening coeff 3 of async motor 2	Range: 0.0000~1.0000	Factory default: model dependent
d3-15	Stator resistance of synch motor 2	Range: 0.001Ω~65.535Ω	Factory default: model dependent
d3-16	Direct-axis inductance of synch motor 2	Range: 0.1mH~6553.5mH	Factory default: model dependent
d3-17	Quadrature axis inductance of synch motor 2	Range: 0.1mH~6553.5mH	Factory default: model dependent
d3-18	Counter-EMF constant of synch motor 2	Range: 0~1000	Factory default: model dependent
d3-19	Autotune current of synch motor 2	Range: 0.0%~100.0%	Factory default: 30.0%
d3-20	Initial angle of synch motor 2	Range: 0°~360.0°	Factory default: 0.0°
d3-21	Z-pulse initial angle of synch motor 2	Range: 0~FFFF	Factory default:0
d3-22	Autotune of motor 2	Range: 0~4	Factory default: 0
d3-23	Overload protection mode of motor 2	Range: 0~2	Factory default: 1
d3-24	Overload protection detection time of motor 2	Range: 0.1min~15.0min	Factory default: 5.0min

d3-25	Temperature transducer signal input of motor 2	Range: 0~2	Factory default: 1
43.36	Thermal protection threshold of motor 2 temperature transducer	Range: 0.00V~10.00V	Factory default: 10.00V

# Group d4 V/f Control Parameters of Motor 2

When motor 2 is selected as current loaded motor, under V/f control pattern, please set control parameters in Group d4. The specification of V/f control parameters Group d4 of motor 2 is the same with that of V/f control parameters Group d1 of motor 1.

d4-00	V/f curve setting	Range: 0~6	Factory default: 0
d4-01	V/f frequency value f3	Range: 0.00Hz~rated frequency of motor	Factory default: 50.00Hz
d4-02	V/f voltage value V3	Range: 0.0%~100.0%	Factory default: 100.0%
d4-03	V/f frequency value f2	Range: d4-05~d4-01	Factory default: 0.00Hz
d4-04	V/f voltage value V2	Range: 0.0%~100.0%	Factory default: 0.0%
d4-05	V/f frequency value f1	Range: d4-07~d4-03	Factory default: 0.00Hz
d4-06	V/f voltage value V1	Range: 0.0%~100.0%	Factory default: 0.0%
d4-07	V/f frequency value f0	Range: 0.00Hz~d4-05	Factory default: 0.00Hz
d4-08	V/f voltage value V0	Range: 0.0%~100.0%	Factory default: 0.0%
d4-09	Torque boost	Range: 0.0%~30.0%	Factory default: 0.0%
d4-10	Slip compensation gain	Range: 0.0%~300.0%	Factory default: 100.0%
d4-11	Droop control	Range: 0.00Hz~10.00Hz	Factory default: 0.00Hz
d4-12	Current limitation mode	Range: 0~5	Factory default: 1
d4-13	Digital setting of current limit value	Range: 20.0%~200.0%	Factory default: 160.0%
d4-14	Current limit coeff on flux weakening	Range: 0.001~1.000	Factory default: 0.500
d4-15	Energy saving percentage	Range: 0.0%~40.0%	Factory default: 0.0%
d4-16	V/f oscillation suppression gain 1	Range: 0~3000	Factory default: 16
d4-17	V/f oscillation suppression gain 2	Range: 0~3000	Factory default: 20

# Group d5 Vector Control Parameters of Motor 2

When motor 2 is selected as current loaded motor under vector control, please set parameters in Group d5. The specification of vector control parameters Group d5 of motor 2 is the same with that of vector control parameters Group d2 of motor 1.

d5-00	Speed/torque control	Range: 0~1	Factory default: 0
d5-01	ASR high-speed proportional gain Kp1	Range: 0.0~20.0	Factory default: 2.0
d5-02	ASR high-speed integration time Ti1	Range: 0.000s~8.000s	Factory default: 0.200
d5-03	ASR low-speed proportional gain Kp2	Range: 0.0~20.0	Factory default: 2.0
d5-04	ASR low-speed integration time Ti2	Range: 0.000s~8.000s	Factory default: 0.20
d5-05	ASR switching frequency 1	Range: 0.00Hz~d5-06	Factory default: 5.00Hz
d5-06	ASR switching frequency 2	Range: d5-05~upper limiting frequency	Factory default: 10.00Hz
d5-07	ASR input filtering time	Range: 0.0ms~500.0ms	Factory default: 0.3ms
d5-08	ASR output filtering time	Range: 0.0ms~500.0ms	Factory default: 0.3ms
d5-09	ACR proportion coeff Kp	Range: 0.000~4.000	Factory default: 1.000
d5-10	ACR integration coeff Ki	Range: 0.000~4.000	Factory default: 1.000
d5-11	Pre-excitation time	Range: 0.000s~5.000s	Factory default: 0.200s
d5-12	Driven torque restriction source	Range: 0~5	Factory default: 0
d5-13	Braking torque restriction source	Range: 0~5	Factory default: 0
d5-14	Digital setting of driven torque limit value	Range: 0.0%~200.0%	Factory default: 180.0%
d5-15	Digital setting of braking torque limit value	Range: 0.0%~200.0%	Factory default: 180.0%
d5-16	Torque limit coefficient in flux weakening	Range: 0.0%~100.0%	Factory default: 50.0%

		_	
d5-17	Driven slip compensation gain	Range:	Factory default:
uo 11	2117 on oup compensation gain	10.0%~300.0%	100.0%
		Range:	Factory default:
d5-18	Brake slip compensation gain	10.0%~300.0%	100.0%
d5-19	Torque reference source	Range: 0~5	Factory default: 0
		Range: -	, .
d5-20	Digital setting of torque	· ·	Factory default: 0.0%
		200.0%~200.0%	-
d5-21	Forward speed limitation source	Range: 0~5	Factory default: 0
u3-21	under torque control	Range. 0~5	raciory default. 0
	Reverse speed limitation source		
d5-22	under torque control	Range: 0~5	Factory default: 0
	ander terque control	D	
	Forward speed limited value	Range:	Factory default:
d5-23	under torque control	0.00Hz~maximum	50.00Hz
		frequency	
		Range:	
d5-24	Reverse speed limited value	0.00Hz~maximum	Factory default:
	under torque control	frequency 50	50.00Hz
		nequency	F t
d5-25	Set torque accel/decel time	Range: 0.00s~120.00s	Factory default:
		<b>5</b>	0.10s
-15.00	Static friction torque	D	F t 1 - f   t - 0 - 00/
d5-26	compensation	Range: 0.0%~100.0%	Factory default: 0.0%
	Sliding friction torque		
d5-27	compensation	Range: 0.0%~100.0%	Factory default: 0.0%
	'		
d5-28	Rotary inertia compensation	Range: 0.000~1.000	Factory default:
40 20	coeff		0.000

# **Group d6 Encoder Parameters**

d6-00	Speed feedback encoder options	Range: 00~11	Factory default: 00
-------	--------------------------------	--------------	---------------------

When it is under closed-loop vector control, it is necessary to use encoder and properly set encoder parameters. Select encoder signal input channel as speed feedback by this parameter.

Encoder 1 is for local input. There are phase A and B pulse signal inputs but no Z signal input on control board. Local input supports differential, OC or push-pull encoder signal. If only speed feedback signal is required, local input can be used. If it needs to perform position control or use rotary transformer or other types of inputs, please use expansion PG card.

Encoder 2 is used with expansion PG card. When inputting signal via expansion PG card, please

select the type of encoder by d6-06.

This parameter sets input channel of encoder with speed feedback signal. In pulse train position control, set the input channel of command pulse by F4-33. F4-33 and d6-00 cannot be the same encoder

Parameters of encoder 1 are set by d6-01~d6-05.

Parameters of encoder 2 are set by d6-06~d6-11.

Ones place: motor 1 speed feedback encoder option

0: encoder 1 (local)

Encoder signal input via control board, which doesn't support Z signal input.

1: encoder 2 (expansion PG card input)

Encoder signal input through expansion PG card.

◆ Tens place: motor 2 speed feedback encoder option

0: encoder 1 (local)

Encoder signal input via control board, which does not support Z signal input.

1: encoder 2 (expansion PG card input)

Encoder signal input through expansion PG card.

d6-01 Resolution of enco	er 1 Range: 1~10000	Factory default: 1024
--------------------------	---------------------	--------------------------

In closed-loop vector control pattern, this parameter should be set according to the encoder resolution (pulse/rotation).

d6-02 Direction of encoder 1	Range: 0~1	Factory default: 0
------------------------------	------------	--------------------

# 0: Forward

During forward rotation of motor, phase A is the lead phase (in case of reversal rotation, phase B is leading)

#### 1: Reverse

During forward rotation of motor, phase B is the lead phase (in case of reversal rotation, phase A is leading)

If output signals of phases A and B of encoder 1 fail to match with run direction of motor, output connection of phases A and B shall be exchanged. Also, we can modify the set value of d6-02 instead.

46-U3	Numerator of the ratio of motor speed to encoder 1 speed	Range: 0~65535	Factory default: 1000
d6-04	Denominator of the ratio of motor speed to encoder 1 speed	Range: 0~65535	Factory default: 1000

When encoder is not mounted on motor, vector control with PG can also be performed over

motor by properly setting speed ratio. This parameter is defined as the ratio of motor rotation speed to encoder rotation speed.

## l.e., d6-03 : d6-04 = motor rotation speed : encoder rotation speed

For example: when the speed reducing ratio between motor and motor spindle on machine is 3:1, which means that the motor spindle will turn a circle as the motor rotates by three circles. Encoder and motor spindle is connected at a transmission ratio of 1:1. Therefore, set d6-03 to 3000, and set d6-04 to 1000 in this case.

If encoder is directly mounted on motor, just need to set d6-03 equal to d6-04, like the default. Please set based on actual transmission ratio, or the drive won't work correctly.

d6-05	Encoder 1 disconnection	Danga, 0.0a, 9.0a	Factory default:
uo-05	detected time	Range: 0.0s~8.0s	0.0s

This parameter takes effect under closed-loop vector control. When the motor is running at none-zero speed, if the drive fails to detect input signals of phases A and B of the encoder in the span of time set by d6-05, the drive will treat abnormality happened to the PG. The drive reports fault "CLL" and coast to stop. When this parameter is set to 0.0s, the detection is disabled.

d6-06	Type of encoder 2	Range: 0~3	Factory default: 0
-------	-------------------	------------	--------------------

- 0: 0: ABZ encoder
- 1: UVW encoder
- 2: Resolver
- 3: SINCOS encoder

Please refer to "Chapter 3 Installation and Wiring" for usage information of encoder.

d6-07	Resolution of encoder 2	Range: 1~10000	Factory default: 1024
-------	-------------------------	----------------	--------------------------

When expansion PG card is used to receive encoder signal, the encoder resolution (pulse/rotation) is set by d6-07. It should be set properly, or the motor won't work normally. When resolver type is used, the resolver resolution should be set as: 1024 × pole-pairs number of resolver.

	d6-08	Direction of encoder 2	Range: 00~11	Factory default: 00	
--	-------	------------------------	--------------	---------------------	--

- Ones place: AB direction
- 0: Forward

In forward rotation, phase A is the lead phase (in reversal rotation, phase B is leading)

1: Reverse
In forward rotation, phase B is the lead phase (in reversal rotation, phase A is leading)

If output signals of phases A and B of encoder 2 fail to match with run direction of motor, output connection of phases A and B shall be exchanged. Or modify the value of d6-08 instead of exchanging wires. This parameter is available for both asynchronous motor and synchronous motor.

When choosing closed-loop vector control mode via A0-09, after rotary tune of asynchronous motor or synchronous motor autotune, AB direction can be obtained automatically.

- ◆ Tens place: UVW direction
- 0: Forward
- 1: Reverse

It is only applicable to synchronous motor using UVW encoder as feedback and the UVW direction can be obtained automatically after synch motor tune.

d6-09	Numerator of the ratio of motor speed to encoder 2 speed	Range: 0~65535	Factory default: 1000
d6-10	Denominator of the ratio of motor speed to encoder 2 speed	Range: 0~65535	Factory default: 1000

Refer to similar specification of d6-03 and d6-04.

d6-11	Encoder 2 disconnection	Range: 0.0s~8.0s	Factory default:
uo-11	detected time	Range. 0.05~6.05	0.0s

## Refer to similar specification of d6-05

d6-12 Over-speed (OS) and excessive speed deviation (DEV) action	Range: 00~11	Factory default: 11
------------------------------------------------------------------	--------------	---------------------

This parameter only takes effect under closed-loop vector control with PG.

- Ones place: action in over-speed (OS)
- 0: Coast to stop, with fault reported

When the drive detects that the motor speed exceeds the value of d6-13, and lasts the time set by d6-14. The drive will coast to stop and report fault "oSP".

- 1: Run continued
  - d6-13 and d6-14 are disabled. The drive neither stops nor reports the fault.
- ◆ Tens place: action in excessive speed deviation (DEV)
- 0: Coast to stop, with fault reported

When the drive detects that the deviation of motor speed from the set speed is bigger than the value set by d6-15, and the lasting time attains d6-16, the drive will coast to stop and report fault "SPL".

1: Run continued

d6-15 and d6-16 are disabled. The drive neither stops nor reports the fault.

d6-13	Detected value of over-speed (OS)	I Range: 0.0~120.0%	Factory default: 120.0%
d6-14	Detected time of over-speed (OS)	I Range: 0.00s~20.00s	Factory default: 0.50s

When ones place of d6-12 is set to 0, these two parameters are enabled.

l d6-15	Detected value of excessive speed deviation (DEV)	Range: 0.0~50.0%	Factory default: 10.0%
l d6-16	Detected time of excessive speed deviation (DEV)	Range: 0.00s~20.00s	Factory default: 1.00s

When tens place of d6-12 is set to 0, and the drive detects that the deviation of motor speed from the set speed is bigger than the value set by d6-15, and the lasting time attains d6-16, the drive will coast to stop and report fault "SPL".

## **Group E** Enhanced Function and Protection Parameters

## Group E0 Enhanced Function

E0-00	Switching FREQ	Range: 0.7kHz~16.0kHz	Factory default: Model dependent
-------	----------------	-----------------------	-------------------------------------

With lower switching frequency, output current of the drive produces higher harmonics, motor loss increases, and temperature and motor noise rise, but drive temperature, drive leakage current, and drive interference to external devices are lower or less.

With higher switching frequency, drive temperature will rise, drive leakage current is bigger, and drive interference to external devices is bigger. However, motor loss and noise will be lower, and motor temperature will drop.

The table below specifies the setting range and factory default of PWM switching frequency of the drives at different power ratings:

**Table 6-18** 

Power rating of the drives	Setting Range	Factory Default
≤15kW	0.7k~16k	8k
18.5kW~45kW	0.7k~10k	4k
55kW~75kW	0.7k~8k	3k
≥90kW	0.7k~3k	2k

Tips for PWM switching frequency setting:

<sup>1)</sup> When the motor line is too long, reduce switching frequency.

- 2) When torque at low speed is unstable, reduce switching frequency.
- If the drive produces severe interference to surrounding equipment, reduce switching frequency.
- 4) Leakage current of the drive is big, reduce switching frequency.
- 5) Drive temperature rise is relatively high, reduce switching frequency.
- 6) Motor temperature rise is relatively high, increase switching frequency.
- 7) Motor noise is relatively big, increase switching frequency.

E0-01	PWM optimization	Range: 0000~1121	Factory default:
L0-01	i vvivi optiiiiizatioii	Nange. 0000 1121	0100

- ◆ Ones place: PWM switching frequency adjusted with temperature
- 0: Self-adaption
- 1: No adjustment

When self-adaption of PWM switching frequency is selected, the drive will automatically reduce switching frequency with the temperature rise, protecting itself against overheat. Set to 1 where PWM switching frequency change is not allowed.

- ◆ Tens place: PWM modulation mode
- 0: five-segment and seven-segment automatic switchover
- 1: five-segment mode
- 2: seven-segment mode

This selection is valid only for V/f control. When five-segment mode is selected, the drive has low temperature rise but relatively higher output current harmonic. Under seven-segment mode, it has relatively higher temperature rise but lower output current harmonic. Under SVC or closed-loop VC pattern, PWM is seven-segment mode.

- Hundreds place: over-modulation adjustment
- 0: Disabled
- 1: Enabled

At low grid voltage or long-term heavy-duty operation, over-modulation can improve the voltage utilization and enhance the maximum voltage output capacity of the drive. This parameter takes effect only for V/f control, while over-modulation is enabled all the time under SVC or closed-loop VC pattern.

- Thousands place: PWM switching frequency relation with output frequency
- 0: Self-adaption
- 1: No adaption

When this bit is set to 0, the drive running at low speed automatically reduces its switching frequency, so as to improve the motor load carrying capacity at low speed. Please set this bit to 1 if PWM switching frequency change is not allowed.

E0-02	Action when run time	Panga, 000, 111	Factory default:
E0-02	attained	Range: 000~111	000

- ◆ Ones place: action when consecutive run time attained
- 0. Run continued

When consecutive run time of the drive attains the set value of E0-03, the drive will continue to run.

1: Stop and fault reported

When consecutive run time of the drive attains the set value of E0-03, the drive will report fault code "to2" and coast to stop. Digital output terminal "consecutive run time attained" will output ON. When E0-03 is set to 0, this parameter value is enabled.

- ◆ Tens place: action when accumulative run time attained
- 0: Run continued

When the drive accumulative run time of attains the set value of E0-04, the drive will continue to run.

1: Stop and fault reported

When the accumulative run time of the drive attains the set value of E0-04, the drive will report fault code "to3" and coast to stop. Digital output terminal "accumulative run time attained" will output ON. When E0-04 is set to 0, this parameter value is enabled.

- Hundreds place: unit of run time:
- 0: Second
- 1: Hour

Sets the unit of E0-03 consecutive run time and E0-04 accumulative run time.

E0-03	Consecutive run time	Danger 0.0, 6000 0a/h)	Factory default:
E0-03	setting	Range: 0.0~6000.0s(h)	0.0 s(h)

When consecutive run time attains this set value, the drive will perform the action set by ones place of E0-02. Time unit is set at hundreds place of E0-02. When this parameter value is set to 0, this function is disabled.

E0-04	Accumulative run time	Dangar 0.0, 6000 0a/h)	Factory default:
E0-04	setting	Range: 0.0~6000.0s(h)	0.0 s(h)

When accumulative run time of attains this set value, the drive will perform the action set by tens place of E0-02. Time unit is set at hundreds place of E0-02. When this parameter value is set to 0, this function is disabled.

E0-05 Mech	anical brake control	Range: 0~1	Factory default: 0
------------	----------------------	------------	--------------------

0: Disabled

1: Enabled

Process of mechanical brake control is as shown in Fig. 6-47 below:






Fig. 6-47

- Upon the receipt of run command, the drive will accelerate to the mechanical brake open frequency set by E0-06.
- When frequency attains the value as set by E0-06, digital output terminal "mechanical brake control" outputs ON to control the mechanical brake open.
- Perform constant-speed running at mechanical brake open frequency. During this period, the drive keeps the output current no higher than the current as set by E0-07.
- 4) When the run time at mechanical brake open frequency attains set value of E0-08, the drive will accelerate to set frequency.
- Upon the receipt of stop command, the drive decelerate to mechanical brake close frequency set by E0-09 and maintains constant-speed running at this frequency.
- 6) When the run frequency attains the set value of E0-09, waiting a period of time set by E0-10, then digital output terminal "mechanical brake control" will output OFF signal to control mechanical brake close.
- 7) When the time of output OFF signal "mechanical brake control" attains the set value of E0-11, the drive will block the output and stop.

E0-06 Mechanical brake op	Mechanical brake open	Range: 0.00Hz~10.00Hz	Factory default:
E0-00	frequency	Range. 0.00H2~10.00H2	2.50Hz

When frequency attains this value, digital output terminal "mechanical brake control" outputs ON signal to control the open of mechanical brake. This value can be set the same value as rated slip frequency of motor. Under V/f control, it could be set to a relatively large one.

E0-07	Mechanical brake open current	Range: 0.0%~200.0%	Factory default: 120.0%
-------	-------------------------------	--------------------	-------------------------

Current is limited to this value before the drive starts its acceleration from mechanical brake open frequency, i.e., before mechanical brake mechanism is opened.

E0-08	Accel delay time after	Range: 0.0s~10.0s	Factory default:
E0-06	brake open	Range. 0.05~10.05	1.0s

After digital output terminal "mechanical brake control" outputs ON signal, the drive will delay its Accel with this time. Accelerated run will be started after this set time is elapsed. Please set this parameter value in compliance with the time required for mechanism open of mechanical brake.

E0-09	Mechanical brake	Dongo: 0.00Llz: 10.00Llz	Factory default:
E0-09	frequency	Range: 0.00Hz~10.00Hz	2.00Hz

Upon the receipt of stop command, the drive decelerates to mechanical brake close frequency set by E0-09 and maintains constant-speed running at this frequency, waiting for the output of mechanical brake control signal.

E0-10	Mechanical brake close	Range: 0.0s~10.0s	Factory default:
	waiting time	3	0.0s

When the run frequency attains mechanical brake close frequency, after this waiting time, digital output terminal "mechanical brake control" outputs OFF signal to control the mechanical brake close.

E0-11	Mechanical brake close	Range: 0.0s~10.0s	Factory default:
	holding time		1.0s

When the digital output terminal "mechanical brake control" outputs OFF signal, the frequency will be maintained the time set by E0-11 to ensure complete mechanism close. Then, the drive will block the output and stop.

#### **Group E1 Protection Parameters**

E1-00	Overvoltage stall	Range: 0~2	Factory default: 1
	O voi voitago otaii	rtango. o z	i dotory doradit.

- 0: Prohibited
- 1: Allowed
- 2: Only valid for decel

When the motor is decelerating with a high-inertia load or short-term regenerative braking occurs during the running, the energy feedback to the drive may raise DC bus voltage, and thus resulting in overvoltage protection.

When this parameter value is set to 1, the drive will detect its bus voltage and compare with parameter set by E1-01. If the bus voltage exceeds value of E1-01, drive output frequency shall be adjusted instantaneously and the deceleration time shall be automatically prolonged, to maintain the stability of DC bus voltage. Set this parameter to 0 if frequency fluctuation or Decel time prolonging is not allowed.

This value is a percentage compared to standard DC bus voltage.

E1-02 Undervoltage stall	Range: 0~1	Factory default: 0
--------------------------	------------	--------------------

#### 0: Disabled

#### 1: Enabled

Under momentary voltage drop or momentary power loss, the drive will accordingly drop output frequency, and compensate the voltage drop via the energy feedback from load, so as to maintain consecutive running, no trip. This function applies to fans and centrifugal pumps and such.

E1-03	Overload alarm	Range: 000~111	Factory default:
2.00	o vonoda diami	range. 555 TT	000

Ones place: detection option

#### 0: Always detect

Overload alarm works all the time during drive running.

1: Detect at constant speed only

Overload pre-alarm only works during constant-speed running of inverter.

◆ Tens place: compared with

### 0: Rated current of motor

Compared object is the rated current relative to motor, and display "oL2" when the alarm is given under this setting

1: Drive rated current

Compared object is the rated current of drive, and display "oL1" when the alarm is given under this setting.

- ◆ Hundreds place: drive action
- 0: No alarm and run continued

When drive output current exceeds the level set by E1-04 and the lasting time attains parameter value of E1-05, the drive will alarm but continue its running.

1: Alarm and coast to stop

When drive output current exceeds the level set by E1-04 and the lasting time attains parameter value of E1-05, the drive will display overload fault and coast to stop.

F1-04	Overload alarm threshold	Range: 20.0%~200.0%	Factory default:
L1-04	Overload alaitii tillesiloid	Nange. 20.0 /6 - 200.0 /6	180.0%

When tens place of E1-03 is set to 0, this parameter value is a percentage compared to rated current of motor. When tens place of E1-03 is set to 1, this parameter value is a percentage compared to rated current of drive.

E1-05	Overload alarm activated	Range: 0.1s~60.0s	Factory default:
⊏1-05	time	Range. 0.15~00.05	5.0s

Sets the lasting time that overload alarm is activated when output current of drive is bigger than the threshold set by E1-04.

E1-06	Protection action 1	Range: 0000~1111	Factory default: 0000
E1-07	Protection action 2	Range: 0000~3111	Factory default: 3001

These two parameters set the protection action of the drive in the following abnormal status. Specification of E1-06:

- ◆ Ones place: encoder disconnected (CLL)
- 0: Alarm and coast to stop
- 1: Alarm but run continued
- ◆ Tens place: PIM temperature measurement circuit fault (oH3)
- 0: Alarm and coast to stop
- 1: Alarm but run continued
- Hundreds place: EEPROM read/write fault (EPr)
- 0: Alarm and coast to stop
- 1: Alarm but run continued
- ◆ Thousands place: port communication abnormal (TrC)
- 0: Alarm and coast to stop
- 1: Alarm but run continued

Specification of E1- 07:

- ◆ Ones place: abnormal power supply at run (SUE)
- 0: Alarm and coast to stop
- 1. Alarm but run continued
- ◆ Tens place: current detection circuit failed (CtC)
- 0: Alarm and coast to stop
- 1: Alarm but run continued
- Hundreds place: abnormal contactor (CCL)
- 0: Alarm and coast to stop
- 1: Alarm but run continued
- ◆ Thousands place: input supply fault /output phase loss (ISF, oPL)
- 0: Protection for neither input supply fault nor output phase loss
- 1: No protection for input supply fault, protection enabled for output phase loss
- 2: Protection enabled for input supply fault, no protection for output phase loss
- 3: Protection enabled both for input supply fault and output phase loss

#### ATTENTION:

Please set "protection action" with caution since inappropriate setting may extend the fault.

E1-08	Fault memory after power loss	Range: 0~1	Factory default: 0
-------	-------------------------------	------------	--------------------

Determine whether or not the previous fault code is to be memorized and displayed upon the

power up of the drive after power loss.

- 0: Not memorized after power loss
- 1: Memorized after power loss

### **ATTENTION:**

Undervoltage fault "LoU" is not memorized after power loss.

E1-09	Fault auto-reset times	Range: 0~20	Factory default: 0
E1-10	Auto-reset interval	Range: 2.0s~20.0s	Factory default: 2.0s

When a fault occurs during the running, the drive will run at 0Hz with the time set by E1-10, and then the fault will be reset and the drive continues to run. Fault auto-reset times is set by E1-09. Automatic reset is prohibited and fault protection shall be executed immediately when E1-09 is set to 0.

#### ATTENTION:

- 1) Automatic fault reset is not performed at the following types of faults:
  - Module protection "FAL"
  - Autotune failed "tUN"
  - Current detection circuit failed "CtC"
  - Output ground short-circuit protection "GdP"
  - Inverter module overload protection "oL3"
  - Option board 1 connection abnormal "EC1"
  - Option board 2 connection abnormal "EC2"
  - Control board flat cable abnormal "dLC"
  - External equipment error "PEr"
  - Consecutive run time attained "to2"
  - Accumulative run time attained fault "to3"
  - Power supply abnormal at run "SUE"
  - Parameter copy fault "CPy"
  - Software version compatibility failure "SFt"
  - CPU interference fault "CPU"
  - Overcurrent benchmark error "oCr"
  - 5V power supply out-of-limit "SP1"
  - Undervoltage protection "LoU"
  - PID feedback loss "Plo"
- Please use automatic fault reset function with caution, or fault expansion may occur.

E1-11	Relay action on drive fault	Range: 000~111	Factory default:
□1-11	Relay action on universalit	Range: 000~111	010

Ones place: when undervoltage fault occurs

- 0: No action
- 1: Action enabled

Set whether or not fault relay acts when undervoltage occurs.

- ◆ Tens place: when fault locked
- 0: No action
- 1: Action enabled

Set whether or not the relay acts when the fault locked at latest power loss after power up.

- ♦ Hundred's place: time of automatic reset
- 0: No action
- 1. Action enabled

Set whether or not the relay is to operate when fault occurs in automatic reset status.

E1-12	Cooling fan control	Range: 0~1	Factory default: 0
-------	---------------------	------------	--------------------

#### 0: Auto run

The fans run all the time during the running. Determine if the fans continue to run or stop according to module temperature after stop.

1: Always run after power up

The fans run all the time after applying power to the drive.


E1-13	Drive overheat alarm  Range: 0.0°C~100.0°C	Factory default:	
E1-13	threshold	Range. 0.0 C~ 100.0 C	80.0℃

This parameter sets the threshold of drive overheat alarm.

# Group F Application

# Group F0 Process PID

The purpose of process PID control is to make feedback value consistent with the set value. PID control diagram is as shown in Fig. 6-48.



F0-00	PID reference	Range: 0~5	Factory default: 0
-------	---------------	------------	--------------------

Selects the setting source of PID control.

- 0: F0-01 digital setting
- 1: AI1
- 2: AI2
- 3: AI3
- 4: X7/DI pulse input
- 5: Communication

F0-01	PID digital setting	Range: 0.0%~100.0%	Factory default: 50.0%
-------	---------------------	--------------------	------------------------

When F0-00 is set to 0, this parameter value is taken as set value of PID.

F0-02 PID feedba	Range: 0~8	Factory default: 0
------------------	------------	--------------------

Selects the feedback source of PID control.

- 0. AI1
- 1: AI2
- 2: AI3
- 3: AI1+AI2
- 4: AI1-AI2
- 5: max {AI1, AI2}
- 6: min {Al1, Al2}
- 7: X7/DI pulse input
- 8: Communication

F0-03	PID adjustment	Range: 00~11	Factory default:
	i ib adjacament	range. oo m	10

- Ones place: output frequency
- 0: Must be the same direction as set run direction

When PID frequency output direction is opposite to run command direction, PID output is 0.

1: Opposite direction allowed

PID frequency output direction can be opposite to run command direction, and PID output performs normally.

- ◆ Tens place: integration selection
- 0: Integral continued when frequency attains upper/lower frequency
  Under PID control, when output frequency attains upper/lower limit of frequency or parameter
  value of F0-23 (maximum frequency if it is opposite to rotary set direction), PID integral continues.
  This mode requires longer time of quitting saturation.
- 1: Integral stopped when frequency attains upper/lower limit
  Under PID control, when output frequency attains upper/lower limit of frequency or parameter

value of F0-23 (maximum frequency if it is opposite to rotary set direction), PID integral will cease. This mode can guit integral saturation status rapidly.

F0-04 PID po	itive and negative ent	Range: 0~1	Factory default: 0
--------------	------------------------	------------	--------------------

## 0: Positive adjustment

## 1: Negative adjustment

This parameter can be used with digital input terminal "PID adjustment direction" to select positive or negative adjustment of PID.

**Table 6-19** 

F0-04	PID adjustment direction	Adjustment
	terminal	
0	OFF	Positive
0	ON	Negative
1	OFF	Negative
1	ON	Positive

Positive adjustment: when feedback signal is smaller than PID reference, output frequency of the drive will rise to reach PID balance.

when feedback signal is bigger than PID reference, output frequency of the drive will drop to reach PID balance.

Negative adjustment: when feedback signal is smaller than PID reference, output frequency of the drive will drop to reach PID balance.

when feedback signal is bigger than PID reference, output frequency of the drive will rise to reach PID balance.

F0-05	Filtering time of PID reference	Range: 0.00s~60.00s	Factory default: 0.00s
F0-06	Filtering time of PID feedback	Range: 0.00s~60.00s	Factory default: 0.00s
F0-07	Filtering time of PID output	Range: 0.00s~60.00s	Factory default: 0.00s

Sets the filtering time of PID reference, feedback and output.

F0-08	Proportional gain Kp1	Range: 0.0~200.0	Factory default: 50.0
F0-09	Integration time Ti1	Range: 0.000s~50.000s	Factory default: 0.500s
F0-10	Derivative time Td1	Range: 0.000s~50.000s	Factory default: 0.000s

Process PID is provided with two groups of proportion, integral and derivative parameters set by F0-14. F0-08~F0-10 are the first group of parameters.

Proportional gain Kp: dynamic response of the system can be quickened by increasing proportional gain Kp. However, excessive Kp value would bring about system oscillation. Only proportional gain control cannot eliminate steady state error.

Integration time: dynamic response of the system can be quickened by reducing integration time Ti. However, excessively small Ti value would result in serious system overshooting and may easily bring about oscillation. Integral control can be used to eliminate steady state error but is unable to control sharp changes.

Derivative time Td: it can predict the change trend of offset and thus can rapidly respond to the change, improving dynamic performance. However, this is vulnerable to interference. Please use derivative control with caution.

F0-11	Proportional gain Kp2	Range: 0.0~200.0	Factory default: 50.0
F0-12	Integration time Ti2	Range: 0.000s~50.000s	Factory default: 0.500s
F0-13	Derivative time Td2	Range: 0.000s~50.000s	Factory default: 0.000s

Process PID is provided with two groups of proportion, integral and derivative parameters set by F0-14. F0-11~ F0-13 is the second group of parameters.

F0-14	PID parameter switchover	Range: 0~2	Factory default: 0
-------	--------------------------	------------	--------------------

Process PID is provided with two groups of proportional, integral and derivative parameters, which is set by this parameter.

- 0: No switch, determined by parameters Kp1, Ti1 and Td1 Always determined by Kp1, Ti1 and Td1 set at F0-08~F0-10.
- 1: Auto switched on the basis of input offset

  When the offset between setting and feedback is less than the set value of F0-15, PID

  adjustment is determined by Kp1, Ti1 and Td1. When the offset between setting and feedback
  is bigger than the set value of F0-15, PID adjustment is determined by Kp2, Ti2 and Td2 set
  at F0-11~F0-13.
- 2: Switched by terminal

  When digital input terminal "PID parameters switch" is OFF, it is determined by Kp1, Ti1 and
  Td1. When "PID parameters switch" is ON. it is determined by Kp2. Ti2 and Td2

F0-15 Input offset under PID auto	Range: 0.0%~100.0%	Factory default: 20.0%
-----------------------------------	--------------------	------------------------

When F0-14 is set to 1, this parameter sets the switching point of the two groups of PID parameters. When the offset between setting and feedback is less than this set value, it is determined by Kp1, Ti1 and Td1. When the offset between setting and feedback is bigger than this set value, it is determined by Kp2, Ti2 and Td2.

F0-16	Sampling period T	Range: 0.001s~50.000s	Factory default: 0.002s
			0.0023

Sampling period aims at feedback. PID controller performs the sampling and compute once in each sampling period. The longer the sampling period T is, the slower the response time will be.

F0-17	PID offset limit	Range: 0.0%~100.0%	Factory default:
		9	0.0%

If the offset between PID feedback and setting is more than this set value, PID regulator will implement regulation. If the offset between PID feedback and setting is less than this set value, PID will stop the regulation and the PID controller output will be kept unchanged. This function can improve the stability of PID performance.

F0-18 PID derivative limit Range: 0.0%~100.0% Factory de 0.5%	
---------------------------------------------------------------	--

Sets derivative output limit of PID control.

F0-19	PID initial value	Range: 0.0%~100.0%	Factory default: 0.0%
F0-20	Holding time of PID initial value	Range: 0.0s~3600.0s	Factory default: 0.0s

PID does not make adjustment when the drive starts its running, but outputs the value set by F0-19 and maintains the holding time set by F0-20, then starts PID adjustment. When F0-20 is set to 0, PID initial value is disabled. This function makes PID adjustment get into stable status fast.

F0-21	PID feedback loss detection value	Range: 0.0%~100.0%	Factory default: 0.0%
F0-22	PID feedback loss detection time	Range: 0.0s~30.0s	Factory default: 1.0s

When offset between feedback and setting of PID is bigger than set value of F0-21 and the lasting time attains the set time of F0-22, the drive reports fault "Plo". If F0-22 is set to 0,

feedback loss detection is disabled.

F0-23	Cutoff FREQ when opposite to	Range: 0.00Hz~maximum	Factory default:
FU-23	rotary set direction	frequency	50.00Hz

When run command direction is forward, while PID output is reverse, the maximum reverse frequency will be determined by F0-23. When run command direction is reverse, while PID output is forward, the maximum forward frequency will be determined by F0-23.

F0-24	PID computation option	Range: 0~1	Factory default: 0
-------	------------------------	------------	--------------------

- 0: No computation in stop status
- 1: Computation continued in stop status

# Group F1 Multi-step Frequency

F1-00	Frequency set source of multi-step 0	Range: 0~8	Factory default: 0
-------	--------------------------------------	------------	--------------------

- 0: Digital setting F1-02
- 1: Digital setting b0-02 + control panel A/V adjustment
- 2: Digital setting b0-02 + terminal UP/DOWN adjustment
- 3: AI1
- 4: AI2
- 5: AI3
- 6: X7/DI pulse input
- 7: Process PID output
- 8: Communication

At most 16-step of frequency can be set through the combination of "multi-step frequency terminals 1~4" of digital input. Multi-step frequency 2~15 are only digital setting while a number of setting sources can be selected for multi-step frequency 0~1. Parameter value of F1-00 determines command source of step 0.

F1-01	Frequency set source of multi-step 1	Range: 0~8	Factory default: 0
-------	--------------------------------------	------------	--------------------

- 0: Digital setting F1-03
- 1: Digital setting b0-04 + control panel A/V adjustment
- 2: Digital setting b0-04 + terminal UP/DOWN adjustment
- 3: AI1
- 4: AI2
- 5: AI3
- 6: X7/DI pulse input
- 7: Process PID output

#### 8: Communication

At most 16-step of frequency can be set through the combination of "multi-step frequency terminals 1~4" of digital input. Multi-step frequency 2~15 are only digital setting while a number of setting sources can be selected for multi-step frequency 0~1. Parameter value of F1-01 determines command source of step 1.

F1-02	Multi-step frequency 0	Range: -100.0%~100.0%	Factory default:
1 1-02	Watti-step frequency o	Trange: -100.070 100.070	0.0%
F1-03	Multi-step frequency 1	Range: -100.0%~100.0%	Factory default: 0.0%
F1-04	Multi-step frequency 2	Range: -100.0%~100.0%	Factory default: 0.0%
F1-05	Multi-step frequency 3	Range: -100.0%~100.0%	Factory default: 0.0%
F1-06	Multi-step frequency 4	Range: -100.0%~100.0%	Factory default: 0.0%
F1-07	Multi-step frequency 5	Range: -100.0%~100.0%	Factory default: 0.0%
F1-08	Multi-step frequency 6	Range: -100.0%~100.0%	Factory default: 0.0%
F1-09	Multi-step frequency 7	Range: -100.0%~100.0%	Factory default: 0.0%
F1-10	Multi-step frequency 8	Range: -100.0%~100.0%	Factory default: 0.0%
F1-11	Multi-step frequency 9	Range: -100.0%~100.0%	Factory default: 0.0%
F1-12	Multi-step frequency 10	Range: -100.0%~100.0%	Factory default: 0.0%
F1-13	Multi-step frequency 11	Range: -100.0%~100.0%	Factory default: 0.0%
F1-14	Multi-step frequency 12	Range: -100.0%~100.0%	Factory default: 0.0%
F1-15	Multi-step frequency 13	Range: -100.0%~100.0%	Factory default: 0.0%
F1-16	Multi-step frequency 14	Range: -100.0%~100.0%	Factory default: 0.0%
F1-17	Multi-step frequency 15	Range: -100.0%~100.0%	Factory default: 0.0%

### ATTENTION:

F1-02~F1-17 is relevant to upper limit b0-09

At most 16 steps of multi-step frequency can be set by different status combinations of "multi-step frequency terminals 1~4" of digital input, as shown in Table 6-20.

**Table 6-20** 

Multi-step terminal 4	Multi-step terminal 3	Multi-step terminal 2	Multi-step terminal 1	Set frequency
OFF	OFF	OFF	OFF	Multi-step frequency 0 (F1-00)
OFF	OFF	OFF	ON	Multi-step frequency 1 (F1-01)
OFF	OFF	ON	OFF	Multi-step frequency 2 (F1-04)
OFF	OFF	ON	ON	Multi-step frequency 3 (F1-05)
OFF	ON	OFF	OFF	Multi-step frequency 4 (F1-06)
OFF	ON	OFF	ON	Multi-step frequency 5 (F1-07)
OFF	ON	ON	OFF	Multi-step frequency 6 (F1-08)
OFF	ON	ON	ON	Multi-step frequency 7 (F1-09)
ON	OFF	OFF	OFF	Multi-step frequency 8 (F1-10)
ON	OFF	OFF	ON	Multi-step frequency 9 (F1-11)
ON	OFF	ON	OFF	Multi-step frequency 10 (F1-12)
ON	OFF	ON	ON	Multi-step frequency 11 (F1-13)
ON	ON	OFF	OFF	Multi-step frequency 12 (F1-14)
ON	ON	OFF	ON	Multi-step frequency 13 (F1-15)
ON	ON	ON	OFF	Multi-step frequency 14 (F1-16)
ON	ON	ON	ON	Multi-step frequency 15 (F1-17)

# Group F2 Simple PLC

Simple PLC is a multi-step frequency generator. The drive can automatically change run frequency and direction based on run time so as to meet on-site technological requirements. Flow chart is shown as Fig. 6-49.




Fig. 6-49

a0~a15 are the Accel times of steps, while d0~d15 are the Decel times. f0~f15 are the set frequencies of steps while T0~T15 are the run times.

Upon the completion of current step of simple PLC, digital output terminal "PLC step completed" outputs ON signal, 500ms. When simple PLC finishes a run cycle, digital output terminal "PLC cycle completed" outputs ON signal, 500ms.

F2-00	Simple PLC run mode	Range: 0000~1212	Factory default:
1 2-00	omple i Lo run mode	Nange. 0000 1212	0000

Ones place: PLC run mode

#### 0: Stop after a single cycle

PLC stops upon the completion of one cycle and it won't be started unless another run command is given, shown as Fig. 6-50.




Fig. 6-50

1: Continue to run with the last frequency after a single cycle

After the completion of one cycle, PLC maintains the run frequency and direction of the last
step. See the figure below:




Fig. 6-51

### 2: Cycle repeated

PLC automatically starts the another cycle after finishing one cycle until there is a stop command, shown as Fig. 6-52.




Fig. 6-52

- ◆ Tens place: power loss memory
- 0: No memory on power loss

The drive does not memorize PLC run status on power loss and starts the run from step 0 after power up again.

1: Memorized on power loss

The drive saves PLC run status on power loss, including the running step, run frequency and finished run time at the moment of power loss. After the next power up, the run will be continued in accordance with the memorized status.

- ♦ Hundreds place: started mode
- 0: Run from the first step "multi-step frequency 0"

When restarted after stop, the drive will start to run from "step 0".

1: Continue to run from the step of stop (or fault)

At the moment drive stop, the drive automatically records the run time of current step. When restarted, the drive will gets into this step, continue to run the remanent time with the frequency of this step, shown as Fig. 6-53.




Fig. 6-53

2: Continue to run from the step and frequency at which the run stopped (or fault occurred)

At the moment of stop, the drive not only records the run time of current step, but also records the run frequency at the moment of stop. When restarted, it will restore the run frequency that was recorded at the moment of stop, and then continue to run the remnant step, as shown in Fig. 6-54:




Fig. 6-54

- ◆ Thousands place: unit of simple PLC run time
- 0: Second
- 1: Minute

Sets the unit of run time and Accel/Decel time of simple PLC.

F2-01 Setting of	ulti-step 0 Range: 000~3	Factory default: 000
------------------	--------------------------	----------------------

♦ Ones place: frequency reference

Sets the frequency reference of step 0 of simple PLC.

- 0: Multi-step frequency 0 (F1-02)
- 1. AI1
- 2· AI2
- 3. AI3
- 4: X7/DI pulse input
- 5: Process PID output
- 6: Multi-step frequency
- 7: Communication
- ◆ Tens place: run direction

Sets the run direction for step 0 of simple PLC.

- 0: Forward
- 1. Reverse
- 2: Determined by run command
- ◆ Hundreds place: Accel/Decel time option

Sets the Accel/Decel time step 0.

- 0: Accel/Decel time 1
- 1: Accel/Decel time 2
- 2: Accel/Decel time 3
- 3: Accel/Decel time 4

The Accel/Decel time of simple PLC running is set here, not determined by digital input terminal "Accel/Decel time determinant 1~2". In addition, Accel/Decel time unit is set through thousands place of F2-00 and is independent of the setting of b2-00.

F2-02	Run time of step 0	Range: 0.0~6000.0s(min)	Factory default:
FZ <b>-</b> UZ	Run time of step o	Range: 0.0~0000.0s(min)	0.0s

Sets the run time for step 0 of simple PLC and the time unit is set by thousands place of F2-00.

F2-03	Setting of step 1	Range: 000~327	Factory default: 000	
-------	-------------------	----------------	----------------------	--

- Ones place: frequency reference
- 0: Multi-step frequency 1 (F1-03)
- 1~7: same as F2-01
- ◆ Tens place: run direction (same as F2-01)
- ◆ Hundreds place: Accel/Decel time option (same as F2-01)

#### **GK820 User Manual**

F2-04	Run time of step 1	Range: 0.0~6000.0s(min)	Factory default: 0.0s
-------	--------------------	-------------------------	-----------------------

Sets the run time for step 1 of simple PLC and the time unit is set by thousands place of F2-00.

F2-05	Setting of step 2	Range: 000~327	Factory default:
			000

Ones place: frequency reference

0: Multi-step frequency 2 (F1-04)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-06 Run time of step 2	Range: 0.0~6000.0s(min)	Factory default: 0.0s
--------------------------	-------------------------	-----------------------

Sets the run time of step 2. The time unit is set by thousands place of F2-00.

F2-07	Setting of step 3	Range: 000~327	Factory default: 000
-------	-------------------	----------------	----------------------

♦ Ones place: frequency reference

0: Multi-step frequency 3 (F1-05)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-08	Run time of step 3	Range: 0.0~6000.0s(min)	Factory default:
1 2-00	rtuir time or step o	range: 0.0*-0000.0s(min)	0.0s

Sets the run time of step 3 of simple PLC. The time unit is set by thousands place of F2-00.

F2-09 Setting of step 4 Range: 000~327 Factory of 000
-------------------------------------------------------

Ones place: frequency reference

0: Multi-step frequency 4 (F1-06)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-10	Run time of step 4	Range: 0.0~6000.0s(min)	Factory default:
F2-10	Run time of step 4	Range: 0.0~0000.0s(min)	0.0s

Sets the run time of step 4 of simple PLC. The time unit is set by thousands place of F2-00.

F2-11	Setting of step 5	Range: 000~327	Factory default: 000
-------	-------------------	----------------	----------------------

♦ Ones place: frequency reference

0: Multi-step frequency 5 (F1-07)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

♦ Hundreds place: Accel/Decel time option (same as F2-01)

F2-12	Run time of step 5	Range: 0.0~6000.0s(min)	Factory default:
12-12	Run time of step 5	range: 0.0-0000.0s(min)	0.0s

Sets the run time of step 5 of simple PLC. The time unit is set by thousands place of F2-00.

F2-13	Setting of step 6	Panga: 000-227	Factory default:	l	
	FZ-13	Setting of Step 6	Range: 000~327	000	l

♦ Ones place: frequency reference

0: Multi-step frequency 6 (F1-08)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-14	Run time of step 6	Range: 0.0~6000.0s(min)	Factory default: 0.0s
-------	--------------------	-------------------------	-----------------------

Sets the run time of step 6 of simple PLC. The time unit is set by thousands place of F2-00.

F2-15	Setting of step 7	Range: 000~327	Factory default:
12-13	Setting of step 7	Nange. 000~321	000

Ones place: frequency reference

0: Multi-step frequency 7 (F1-09)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-16	Run time of step 7	Range: 0.0~6000.0s(min)	Factory default:
1 2-10	run une or step r	range: 0.0 0000.03(IIIII)	0.0s

Sets the run time of step 7 of simple PLC. The time unit is set by thousands place of F2-00.

#### **GK820 User Manual**

F2-17 Sett	ting of step 8	Range: 000~327	Factory default: 000
------------	----------------	----------------	----------------------

♦ Ones place: frequency reference

0: Multi-step frequency 8 (F1-10)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-18	Run time of step 8	Range: 0.0~6000.0s(min)	Factory default:
12-10	Run time of step o	range: 0.0*-0000.0s(min)	0.0s

Sets the run time of step 8 of simple PLC. The time unit is set by thousands place of F2-00.

F2-19	Setting of step 9	Range: 000~327	Factory default: 000
-------	-------------------	----------------	----------------------

♦ Ones place: frequency reference

0: Multi-step frequency 9 (F1-11)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundred's place: Accel/Decel time option (same as F2-01)

F2-20	Run time of step 9	Range: 0.0~6000.0s(min)	Factory default:
1 2-20	Null time of step 9	range: 0.0*-0000.0s(min)	0.0s

Sets the run time for step 9 of simple PLC. The time unit is set by thousands place of F2-00.

F2-21 Setting of step 10	Range: 000~327	Factory default: 000
--------------------------	----------------	----------------------

♦ Ones place: frequency reference

0: Multi-step frequency 10 (F1-12)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-22	Run time of step 10	Range: 0.0~6000.0s(min)	Factory default: 0.0s
-------	---------------------	-------------------------	-----------------------

Sets the run time of step 10 of simple PLC. The time unit is set by thousands place of F2-00.

F2-23	Setting of step 11	Range: 000~327	Factory default: 000
-------	--------------------	----------------	-------------------------

♦ Ones place: frequency reference

0: Multi-step frequency 11 (F1-13)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-24	Run time of step 11	Range: 0.0~6000.0s(min)	Factory default:
1 2-24	ran time of step 11	range: 0.0*-0000.0s(min)	0.0s

Sets the run time of step 11 of simple PLC. The time unit is set by thousands place of F2-00.

F2-25	Setting of step 12	Range: 000~327	Factory default:
12-23	Setting of step 12	Range. 000°321	000

Ones place: frequency reference

0: Multi-step frequency 12 (F1-14)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

♦ Hundreds place: Accel/Decel time option (same as F2-01)

F2-26 Run time of step	Range: 0.0~6000.0s(min)	Factory default: 0.0s
------------------------	-------------------------	-----------------------

Sets the run time of step 12 of simple PLC. The time unit is set by thousands place of F2-00.

♦ Ones place: frequency reference

0: The time unit is set by thousands place of F2-00.

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-28	Run time of step 13	Range: 0.0~6000.0s(min)	Factory default:
1 2-20	Null time of step 15	range: 0.0 10000.03(IIIIII)	0.0s

Sets the run time of segment 13 of simple PLC. The time unit is set by thousands place of F2-00.

#### **GK820 User Manual**

F2-29	Setting of step 14	Range: 000~327	Factory default: 000
-------	--------------------	----------------	-------------------------

◆ Ones place: frequency reference 0: Multi-step frequency 14 (F1-16)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-30	Run time of step 14	Range: 0.0~6000.0s(min)	Factory default: 0.0s
-------	---------------------	-------------------------	-----------------------

Sets the run time of step 14 of simple PLC. The time unit is set by thousands place of F2-00.

F2-31	Setting of step 15	Range: 000~327	Factory default:
12-31	Setting of step 13	Range. 000°321	000

Ones place: frequency reference

0: Multi-step frequency 15 (F1-17)

1~7: same as F2-01

◆ Tens place: run direction (same as F2-01)

◆ Hundreds place: Accel/Decel time option (same as F2-01)

F2-32	Run time of step 15	Range: 0.0~6000.0s(min)	Factory default:
12-32	Run time of step 15	rvarige: 0.0**0000.0s(IIIIII)	0.0s

Sets the run time for step 15 of simple PLC. The time unit is set by thousands place of F2-00.

#### ATTENTION:

Digital input terminals "simple PLC paused", "simple PLC disabled" and "simple PLC stop memory clear" can be used during the running of simple PLC. See specification of digital input of Group C0 for details.

## **Group F3** Wobble Frequency and Fixed Length Count

Wobble frequency function is usually used in textile and chemical fiber industries where traverse motion is required. Wobble frequency control process is as follows: accelerate to the prefrequency of wobble frequency function according to the current Accel time. Maintain this frequency for a period of time and run to center frequency of wobble frequency according to the current Accel/Decel time (i.e. the set frequency set by parameter group b0). Then run in a cyclic manner according to wobble frequency amplitude, hopping frequency, wobble frequency cycle time, and frequency ramp up time. When a stop command is given, the drive will ramp down to stop according to the set Decel time.




Fig. 6-55

"a" is the set Accel time (ramp up time), and "d" is the set Decel time (ramp down time).

F3-00	Wobble frequency function setting	Range: 0~1	Factory default: 0
-------	-----------------------------------	------------	--------------------

0: Wobble frequency function disabled

1: Wobble frequency function enabled

F3-01	Wobble frequency run setting	Range: 0000~1111	Factory default: 0000
-------	------------------------------	------------------	-----------------------

- Ones place: started method
- 0: Automatically

Run at pre-frequency of wobble frequency set by F3-02, maintain Pre-frequency holding time set by F3-03, and then automatically get into wobble frequency running.

- 1: Started by terminal
  - Digital input terminal "start wobble frequency" controls the running of wobble frequency. When terminal inputs ON, the drive gets into wobble frequency running. When terminal inputs OFF, the drive exits wobble frequency and runs at pre-frequency of wobble frequency. Under this mode, Pre-frequency holding time is enabled.
- ◆ Tens place: amplitude control
- 0: Relative to center frequency

  Amplitude = F3-04 x current frequency reference.
- 1: Relative to maximum frequency

Amplitude =  $F3-04 \times maximum frequency b0-08$ .

◆ Hundreds place: wobble frequency memorized when stop

## 0: Memory enabled

The drive memorizes the current wobble frequency state when stop. When restarted, drive continues to run the wobble frequency with the memorized state at latest stop. Pre-frequency of wobble frequency F3-02 is enabled at restart.

## 1: Memory disabled

When the drive is started, it restarts wobble frequency running. Run at pre-frequency of wobble frequency F3-02, maintain this frequency for pre-frequency holding time F3-03, and then automatically gets into wobble frequency control.

◆ Thousands place: wobble frequency memorized on power loss

## 0: Memory enabled

Automatically save the wobble frequency state on power loss. This function takes effect only under wobble frequency running.

#### 1: Memory disabled

Drive clears wobble frequency status on power loss.

F3-02	Pre-wobble frequency	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
F3-03	Pre-wobble frequency holding time	Range: 0.0s~3600.0s	Factory default: 0.0s

During the running of wobble frequency, F3-02 is the run frequency before the drive begins to run at wobble frequency, while F3-03 is the holding time of pre-wobble frequency. When F3-03 is set to 0, pre-frequency is disabled.

F3-04	Wobble frequency	Range: 0.0%~50.0%	Factory default:
F3-04	amplitude	Range. 0.0%~30.0%	0.0%

The percentage is relative to center frequency or maximum frequency and determined by the tens place of F3-01. Center frequency is the frequency reference set by parameters of Group b0.

Run frequency of wobble frequency is not only subject to this amplitude, but is also restricted by upper limit and lower limit of frequency.

F3-05	Hop frequency	Range: 0.0%~50.0%	Factory default: 0.0%
-------	---------------	-------------------	-----------------------

Hop frequency =  $F3-05 \times amplitude$ .

F3-06	Cycle of wobble frequency	Range: 0.0s~999.9s	Factory default: 0.0s
-------	---------------------------	--------------------	-----------------------

The time of the completion of a complete process of wobble frequency

F3-07	Triangular wave ramp-up time	Range: 0.0%~100.0%	Factory default:
1 3-07	mangular wave ramp-up time	Range. 0.070 100.070	0.0%

Sets the wobble frequency run time of ramp-up segment.

Triangular wave ramp up time = F3-07 × F3-06

Wobble frequency ramp-down time = F3-06 - triangular wave ramp-up time

## ATTENTION:

The current wobble frequency status can be cleared by digital input terminal "clear wobble frequency status " in stop status. If the output frequency exceeds upper limit frequency or lower limit frequency during the running at wobble frequency, digital output terminal " wobble frequency attains to upper or lower limit frequency " outputs ON signal.

Parameters F3-08~F3-11 are for fixed-length stop.

F3-08	Length unit	Range: 0~1	Factory default: 0
-------	-------------	------------	--------------------

0: m

1: 10m

F3-09	Longth potting	Panga: 0-65525	Factory default:
F3-09	Length setting	Range: 0~65535	1000

Sets the length value of fixed-length stop. When set to 0, fixed-length stop function is enabled, but the actual length is still calculated. When it is detected the actual length attains this set value, digital output terminal "length attained" will output ON signal and perform the command set by F3-11.

F3-10	Pulse number per meter	Range: 0.1~6553.5	Factory default: 100.0
-------	------------------------	-------------------	------------------------

Input pulse is received via digital input terminal "length count"; the pulse number per meter is set here.

F3-11	Action when the length attained	Range: 0~1	Factory default: 0
-------	---------------------------------	------------	--------------------

0: Not stop

1: Stop

This parameter sets the action of the drive when actual length attains the length set by F3-09. Actual length can be cleared through digital input terminal "length clear".

#### ATTENTION:

When actual length is detected to attain the set length, digital output terminal "length attained" outputs ON signal no matter the drive is set to stop or not stop. Actual length is saved at power loss and can be read in both stop and run.

F3-12	Set count value	Range: 1~65535	Factory default: 1000
F3-13	Designated count value	Range: 1~65535	Factory default: 1000

The two parameters are used with digital input terminal "count input" and digital output terminals "set count value attained" and "designated count value attained". Input pulse through digital input terminal "count input". When the number of pulses attain the value set by F3-12, the terminal outputs ON. With the completion of the value of F3-12, the terminal "designated count value attained" outputs OFF.

When the number of input pulses attains the designated count value of F3-13, terminal "designated count value attained" will output ON. Upon the completion of set count value of F3-12, terminal "designated count value attained" outputs OFF.

For example: F3-12= 10, F3-13= 7. Fig. 6-56:




Fig. 6-56

#### ATTENTION:

Actual count value can be cleared through digital input terminal "count clear". Actual count value is saved at power loss.

## Group F4 Position Control.

Position control is valid only in closed-loop vector control. Position control includes zero-speed clamping, angular positioning, simple feed control, and pulse train position control.

F4-00	Position control mode	Range: 0~2; 5	Factory default: 0
-------	-----------------------	---------------	--------------------

## 0: Non-position control

No position control. The drive runs in the mode of speed control or torque control.

1: Zero-speed clamping (frequency attained valid)

If the set frequency of drive is lower than zero-speed clamping start frequency F4-04, and the motor speed is lower than the speed that corresponds to F4-04, the drive will get into zero-speed clamping locked status. In this circumstance, the motor will always maintain this position whether or not motor load changes. When the set frequency is higher than start frequency of zero-speed clamping, the drive quits zero-speed clamping locked status and runs at the set speed.

2: Zero-speed clamping (terminal enabled)

When the set frequency of the drive is lower than start frequency F4-04 of zero-speed clamping, and the motor speed is lower than the speed that corresponds to F4-04, the drive will record the position and lock immediately when receiving effective signal of digital input terminal "zero-speed clamping enabled". In this circumstance, the motor will always maintain this position whether or not motor load changes. When "zero-speed clamping enabled" terminal is disabled, the motor will quit position locked status and run at set speed.

Pulse train position control
 Perform pulse tracking control.

F4-01	Positioning complete width	Range: 0~3000	Factory default: 10
F4-02	Positioning complete time	Range: 0.000s~40.000s	Factory default: 0.200s

In angular positioning or simple feed control, when the error between encoder detected position and set position is less than the set value of F4-01, and the duration reaches the set value of F4-02, the positioning is deemed completed, and digital output terminal "angular positioning completed" outputs ON signal.

In pulse train position control, when the error between the pulse number detected by encoder and the set pulse number is less than the value of F4-01, digital output terminal "positioning approaching" outputs ON signal.

F4-03	Position loop gain	Range: 0.000~40.000	Factory default: 1.000
-------	--------------------	---------------------	------------------------

This parameter value is the proportional gain of position regulator in position control. Increasing this parameter value improves the efficiency of position control and increase the holding force at the stop of zero-speed clamping. However, excessive value may cause oscillation and overshooting.

This parameter is used for zero-speed clamping, angular positioning, simple feed and pulse train position control.

F4-04	Zero-speed clamping start	Range: 0.00Hz ~ upper limit	Factory default:
Г4 <b>-</b> 04	frequency	frequency	1.00Hz

When F4-00 is set to 1, zero-speed clamping is enabled by set frequency and motor speed. In other words, if the set frequency of the drive is lower than zero-speed clamping start frequency F4-04, and the motor speed is lower than the speed that corresponds to F4-04, the drive will get into zero-speed clamping locked status. In this circumstance, the motor will always maintain this position whether or not motor load changes. When the set frequency is higher than start frequency of zero-speed clamping, the drive will quite zero-speed clamping locked status and runs at the set speed.

When F4-00 is set to 2, zero-speed clamping is enabled by terminal. In other words, when the set frequency of the drive is lower than zero-speed clamping start frequency F4-04, and the motor speed is lower than the speed that corresponds to F4-04, the drive will record the position and perform lock immediately when receiving effective signal from digital input terminal "zero-speed clamping enabled". In this circumstance, the motor will always maintain this position whether or not motor load changes. When "zero-speed clamping enabled" terminal is disabled, the motor will quit position locked status and run at set speed.

As the precondition for the drive getting into zero-speed clamping, zero-speed clamping start frequency shall not be set to an big value since a big start frequency may bring about torque and/or current shock, even overcurrent fault.

F4-33	Position reference mode	Range: 0~8	Factory default: 0
-------	-------------------------	------------	--------------------

0: X7/DI pulse input + terminal direction input

Input the set pulsing signal through digital input terminal "position reference pulse input", only valid for X7/DI terminal. When set pulse is input through X7/DI terminal, the maximum pulse frequency is 30kHz. Input the direction through "position reference direction input" terminal. When this terminal is OFF, the input pulse train is in forward direction; when this terminal is ON, the input pulse train is in reverse direction.

- 1: Encoder 1 setting, phase A/B pulse. Phase A that is 90°ahead of phase B corresponds to forward.
- 2: Encoder 1 setting, phase A/B pulse. Phase B that is 90°ahead of phase A corresponds to forward.
- 3: Encoder 1 setting, phase A is pulse, phase B is direction (low level forward, high level reverse).
- 4: Encoder 1 setting, phase A is pulse, phase B is direction (high level forward, low level reverse). Encoder 1 setting as stated in 1~4 is pulse signal input A+, A-, B+ and B- on control board.
- 5: Encoder 2 setting, phase A/B pulse, phase A that is 90°ahead of phase B corresponds to forward.
- 6: Encoder 2 setting, phase A/B pulse, phase B that is 90°ahead of phase A corresponds to forward.
- 7: Encoder 2 setting, phase A is pulse, phase B is direction (low level forward, high level reverse).
- 8: Encoder 2 setting, phase A is pulse, phase B is direction (high level forward, low level reverse).

Encoder 2 setting as stated in 5~8 is pulsing signal input via A+, A-, B+ and B- on optional board.

F4-34	Numerator of electronic gear ratio	Range: 1~30000	Factory default: 1000
F4-35	Denominator of electronic gear ratio	Range: 1~30000	Factory default: 1000

The ratio of variation of command(set) pulse to feedback pulse can be changed through electronic gear.

Numerator : denominator = variation of feedback pulse per unit time : variation of pulse reference per unit time.

For example: every time when command changes by 8 pulses, the motor is required to rotate by 5 pulses, thus set F4-34=5, and F4-35=8.

## □ ATTENTION:

If position feedback encoder is not mounted on motor shaft, d6-03, d6-04 (when encoder 1 is selected) or d6-09 and d6-10 (when encoder 2 is selected) should be correctly set so as to ensure the normal operation of vector control with PG, and then properly set the numerator and denominator of electronic gear ratio based on the ratio of variation of set pulse to feedback pulse.

F4-36	Feed-forward gain	Range: 0.000~7.000	Factory default: 1.000
-------	-------------------	--------------------	---------------------------

When the frequency of command pulse changes, if lagging of the tracking of feedback pulse occurs, please increase the value of feed-forward gain gradually. In the contrary case, please decrease the value of feed-forward gain gradually. It is not necessary to adjust it under normal circumstances. If necessary, please perform fine adjustment around factory default value.

F4-37 Feed-forward filtering time Range: 0.000s~7.000s 0.001s	F4-37	Feed-forward filtering time	Range: 0.000s~7.000s	Factory default: 0.001s
---------------------------------------------------------------	-------	-----------------------------	----------------------	-------------------------

Filters the command pulse signal. Longer filtering time contributes to better interference immunity but may result in lagging of position tracking.

F4-38	Position offset change rate	Range: 0~9999	Factory default: 800
-------	-----------------------------	---------------	----------------------

It is mainly used to adjust the phase between set and feedback, with terminals "forward position offset enabled" and "reverse position offset enabled". When position is synchronized, if "forward position offset enabled" terminal is enabled, the drive will control the motor phase for progressive change in forward direction, and If "reverse position offset enabled" terminal is enabled, motor phase will gradually change in reverse direction, to adjust relative position between the set and feedback

F4-38 is the change rate of phase adjustment when "position offset enabled" terminal is enabled, defined as the variation of pulse per second whose value is 4 times the encoder resolution.

When C0-07 is set to 56: Pulse correction input, the position can also be modified through X7 terminal input. Under this circumstance, F4-38 is the pulse correction ratio, that is to say, the correction value is number of X7 input pulse multiplied by F4-38 set value.

F4-39	Electronic gear change	Range: 0~9999	Factory default:
F4-39	rate	Range. 0~9999	1000

F4-34 (numerator of electronic gear ratio) and F4-35 (denominator of electronic gear ratio) can be changed in real-time during drive running. F4-39 is the electronic gear change rate, the bigger it is, the quicker the transition, but it might cause shock. If set small value, the change is steady, but the transition process is long.

F4-40	Output amplitude limit of	Range: 0.0%~100.0%	Factory default:
F4-40	position-loop	Range: 0.0%~100.0%	10.0%

Sets the output amplitude limit of position-loop.

F4-41	Position control	Dance: 0000 1111	Factory default:
Γ <del>4-4</del> Ι	optimization	Range: 0000~1111	0000

Ones place: Pulse error counter reset option

0: Reset when stop

1: Kept when stop

Tens place: Reserved
 Hundreds place: Reserved
 Thousands place: Reserved

## **Group H Communication Parameters**

## **Group H0 MODBUS Communication Parameters**

Support universal Modbus protocol. Please refer to appendix for detailed description of communication protocol.

		H0-00	SCI port selection	Range: 0~1	Factory default: 0
--	--	-------	--------------------	------------	--------------------

0: Local 485 port

1: Optional 232 port

H0-01	SCI port communication	Range: 0000~1155	Factory default:
	configuration	y	0001

- Ones place: baud rate
- 0: 4800bps
- 1: 9600bps
- 2: 19200bps
- 3: 38400bps
- 4: 57600bps
- 5: 115200bps
- ◆ Tens place: data format
- 0: 1-8-2-N format, RTU
- 1: 1-8-1-E format, RTU
- 2: 1-8-1-O format, RTU
- 3: 1-7-2-N format, ASCII
- 4: 1-7-1-E format, ASCII
- 5: 1-7-1-O format, ASCII
- ◆ Hundreds place: connection type
- 0: Direct cable connection (232/485)
- 1: MODEM (232) (reserved)
- ◆ Thousands place: communication data handling at power loss

## 0: Not saved at power loss

## 1: Saved at power loss

H0-02	Local address of SCI port	Range: 0~247	Factory default: 5
110-02	communication	Nange. 0 247	r actory default. 5

Sets this drive address. 0 is broadcast address, while available addresses are 1~247.

H0-03	Time out detection of SCI port	Range: 0.0s~1000.0s	Factory default:
ПО-03	communication	Range: 0.05~1000.05	0.0s

This parameter sets communication error detection time. When it's set to 0, no communication error will be reported.

H0-04	Time delay of SCI port	Range: 0ms~1000ms	Factory default:
П0-04	communication	Range. unis~ rouums	0ms

Sets response time delay of this drive to the master.

H0-05 Master/Slave option	Range: 0~2	Factory default: 0
---------------------------	------------	--------------------

#### 0: PC controls the drive

PC as master controls the drive. This supports all communication protocols.

#### 1: As master

According to the selection of H0-06, the drive sends current b0-02 (digital setting of master frequency reference) or F0-01 (PID digital setting) through communication. As master, this drive can only send the data and cannot receive the data.

#### 2: As slave

Put the received data into b0-02 (digital setting of master frequency reference) or F0-01 (PID digital setting) through communication. b0-02/F0-01 is selected by parameter H0-06. Other communication data addresses are not supported. As slave, this drive can only receive the data.

l	H0-06	Parameter store address when	Range: 0~1	Factory default: 0
l	110-00	this drive working as master	range. 0 · 1	l actory default. 0

0: b0-02

1: F0-01

This parameter takes effect when H0-05 is set to 1. This parameter sets the slave drive frequency setting address when this drive is working as the master drive.

|--|

This parameter takes effect when H0-05 is set to 2. Data sent by master is multiplied by H0-07 and then put the result into b0-02 or F0-01 (set by H0-06 of master).

This parameter setting is very useful when a master drive controls a number of slave drives and needs to allocate the frequency.

## Group H1 Profibus-DP communication parameters

Refer to EPC-CM2 Instruction Manual for details

## Group L Keys and Display of Control panel

## Group L0 Keys of Control panel

L0-00 MF key setting Range: 0~6 Factory default: 0
----------------------------------------------------

- 0: No function
- 1: Forward jog
- 2: Reverse jog
- 3: Forward/reverse switchover
- 4: Emergency stop 1 (set Decel time on b2-09)
- 5: Emergency stop 2 (coast to stop)
- 6: Run command sources shifted (control panel/terminal/communication)

L0-01	Keys locked option	Range: 0~4	Factory default: 0
-------	--------------------	------------	--------------------

- 0: Not locked
- 1: Full locked
- 2: Keys locked except RUN, STOP/RESET
- 3: Keys locked except STOP/RESET
- 4: Keys locked except >>

Please refer to Chapter 4 for locking operation of keys.

L0-02	Function of STOP key	Range: 0~1	Factory default: 0

- 0: STOP key active only at control panel control
- 1: STOP key deactivated under any run command source

L0-03	Frequency adjustment through	Range: 0000~1111	Factory default:
LU-03	keys ∧/∨	Range. 0000~1111	0100

- Ones place: option at stop
- 0: Clear at stop

Keys ^/vfrequency adjustment step size is cleared at the stop of drive.

1: Holding at stop

Keys ^/vfrequency adjustment step size is held at the stop of drive.

- ◆ Tens place: option at power loss
- 0: Clear at power loss

Keys A/V frequency adjustment step size is cleared at power loss.

1: Holding at power loss

Keys ^/vfrequency adjustment step size is saved at power loss.

♦ Hundreds place: integrating option

0: Integrating disabled

Adjustment step size is kept constant when frequency is adjusted by keys ^/v, and the adjustment will be performed always with the step size set by L0-04.

1: Integrating enabled

When frequency is adjusted by keys  $\wedge/\vee$ , the initial step size is the set value of L0-04. With the press increase of  $\wedge/\vee$ , adjustment step size shows cumulative integrating effect and will increase gradually.

- Thousands place: run direction
- 0: Direction changing prohibited

When the frequency is decreased to 0Hz by terminal UP/DOWN, the drive will run at 0Hz and cannot be able to change the rotary direction

1: Direction changing permitted

When the frequency is decreased to 0Hz by terminal UP/DOWN, the drive continues to decrease its out frequency and change the motor rotary direction.

	L0-04	Step size of frequency	Range:	Factory default:
ı	LU-04	adjustment through keys ^/v	0.00Hz/s~10.00Hz/s	0.03 Hz/s

When frequency setting is "digital setting + control panel  $\land / \lor$  adjustment", progressive increase and decrease of frequency setting is realized through  $\land$  or  $\lor$  on control panel. This parameter is used to set the step size of frequency adjustment through  $\land / \lor$ . The step size is defined as frequency variation per second, and the smallest step size is 0.01 Hz/s.

## Group L1 Control Panel Display Setting

L1-00	LED displayed parameters	Danga, 0000, 2555	Factory default:
L 1-00	setting 1 on run status	Range: 0000~3FFF	080F

Sets LED displayed parameters on run status. When a number of parameters are selected to be displayed, skim-through could be performed using key >> on control panel.

0: No display

1: Display

Ones place

BIT0: Run frequency (Hz) BIT1: Set frequency (Hz) BIT2: Bus voltage (V) BIT3: Output current (A)

◆ Tens place

BIT0: Output torque (%)

BIT1: Output power (kW)

BIT2: Output voltage (V)

BIT3: Motor speed (r/min)

♦ Hundreds place

BIT0: AI1 (V)

BIT1: AI2 (V)

BIT2: AI3 (V)

BIT3: Output sync frequency (Hz)

◆ Thousands place

BIT0: DI

BIT1: External count value

BIT2: Reserved BIT3: Reserved

#### ATTENTION:

When this parameter value is set to 0000, run frequency (Hz) would be displayed as default.

## Example:

To display run frequency, output current, motor speed and Al1 sampled value, L1-00 should be: 0000 0001 1000 1001, i.e. set L1-00 to 0189.

L1-01	Display parameter setting	Range: 0000~01FF	Factory default:
L 1-0 1	2 on run status	Range: 0000~01FF	0000

0: No display

1: Display

Ones place

BIT0: Run linear speed (m/s)

BIT1: Set linear speed (m/s)

BIT2: Input terminal status

BIT3: Output terminal status

◆ Tens place

BIT0: PID reference (%)

BIT1: PID feedback (%)

BIT2: Set length (m)

BIT3: Actual length (m)

Hundreds place:

BIT0: Torque reference (%)

BIT1: Reserved

BIT2: Reserved

BIT3: Reserved

♦ Thousands place:

BIT0: Reserved

BIT1: Reserved

BIT2: Reserved

BIT3: Reserved

L1-02	Display parameter setting	Range: 0000~FF7F	Factory default:
L 1-02	on stop status	Range. 0000-11-71	0003

Sets LED displayed parameters on stop status. When a number of parameters are selected, skimthrough could be realized via key >> on control panel.

0: No display

1: Display

◆ Ones place

BIT0: Set frequency (Hz)

BIT1: Bus voltage (V)

BIT2: Input terminal status

BIT3: Output terminal status

◆ Tens place

BIT0: AI1 (V)

BIT1: AI2 (V)

BIT2: AI3 (V)

BIT3: Reserved

♦ Hundreds place

BIT0: PID reference (%)

BIT1: PID feedback (%)

BIT2: Set length (m)

BIT3: Actual length (m)

◆ Thousands place

BIT0: Run linear speed (m/s)

BIT1: Set linear speed (m/s)

BIT2: External count value

BIT3: DI

Note: when this parameter is set to 0000, the set frequency would be displayed as default (Hz).

## Example:

To display frequency reference, bus voltage, Al1 sampled value, set length and external count value, L1-02 should be: 0100 0100 0001 0011, i.e. set L1-02 to 4413.

L1-03	Linear speed coeff	Range: 0.1%~999.9%	Factory default: 100.0%
-------	--------------------	--------------------	-------------------------

This coefficient is used for calculation of linear speed.

Run linear speed = motor run speed x L1-03

Set linear speed = motor speed setting x L1-03

Both run linear speed and set linear speed can be viewed during the run and stop.

## **Group U** Monitoring

## Group U0 Status Monitoring

All parameters of Group U0 are for display purpose only and can't be set.

U0-00	Run frequency	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U0-01	Set frequency	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U0-02	Bus voltage	Range: 0V~65535V	Factory default: 0V
U0-03	Output voltage	Range: 0V~65535V	Factory default: 0V
U0-04	Output current	Range: 0.0A~6553.5A	Factory default: 0.0A
U0-05	Output torque	Range: -300.0%~300.0%	Factory default: 0.0%
U0-06	Output power	Range: 0.0%~300.0%	Factory default: 0.0%
U0-07	Master FREQ reference source	Range: 0~11	Factory default: 0
U0-08	Auxiliary FREQ reference source	Range: 0~10	Factory default: 0
U0-09	Master FREQ reference	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U0-10	Auxiliary FREQ reference	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz

U0-11 Drive status	Range: 000~222	Factory default: 000
--------------------	----------------	----------------------

♦ Ones place: Run status

0: Accelerating

1: Decelerating

2: Constant speed runningTens place: drive status

0: Stop

1: Running

2: Autotune

♦ Hundreds place: drive status

0: Speed control

1: Torque control

2: Position control

U0-12	Al1 input voltage	Range: 0.00V~10.00V	Factory default: 0.00V
U0-13	Al2 input voltage	Range: 0.00V~10.00V	Factory default: 0.00V
U0-14	Al3 input voltage	Range: -10.00V~10.00V	Factory default: 0.00V
U0-15	AO1 output	Range: 0.0%~100.0%	Factory default: 0.0%
U0-16	AO2 output	Range: 0.0%~100.0%	Factory default: 0.0%
U0-17	X7/DI HF pulse frequency	Range: 0.0kHz~100.0kHz	Factory default: 0.0kHz

U0-18	Status of digital input	Pango: 00-7E	Factory default:
00-16	terminal	Range: 00~7F	00

Digital input terminals that correspond to the bits of U0-18 are as shown in Table 6-21:

**Table 6-21** 

Tens place			Ones	place		
bit6	bit5	bit4	bit3	bit2	bit1	bit0
X7	X6	X5	X4	Х3	X2	X1

0 means terminal input status is OFF, while 1 means terminal input status is ON.

## For example:

If 23 (i.e. 0010 0011) is displayed at U0-18, it means the input status of terminals X1, X2 and X6 is ON and that of the other terminals is OFF.

If 05 (i.e. 0000 0101) is displayed at U0-18, it means the input status of terminals X1 and X3 is ON while that of the other terminals is OFF.

U0-19	Digital output terminal status	Range: 0~7	Factory default: 0
-------	--------------------------------	------------	--------------------

Corresponding relationship between digital output terminals and the bits of U0-19 is shown in Table 6-22:

**Table 6-22** 

bit3	bit2	bit1	bit0
Relay 2	Relay 1	Y2	Y1

0 means terminal output status is OFF, while 1 means terminal output status is ON.

## For example:

If 6 (i.e. 0110) is displayed at U0-19, it means the output status of terminals Y2 and relay 1 is ON while that of the other terminals is OFF.

U0-20	PID set	Range: 0.0%~100.0%	Factory default: 0.0%
U0-21	PID feedback	Range: 0.0%~100.0%	Factory default: 0.0%
U0-22	PID input offset	Range: -100.0%~100.0%	Factory default: 0.0%
U0-23	PLC step	Range: 0~15	Factory default: 0
U0-24	V/f separated target voltage	Range: 0.0%~100.0%	Factory default: 0.0%
U0-25	V/f separated actual output voltage	Range: 0.0%~100.0%	Factory default: 0.0%
U0-26	Encoder feedback pulse frequency	-300.00kHz~300.00kHz	Factory default:0.00Hz
U0-27	Position reference pulse frequency	-300.00kHz~300.00kHz	Factory default:0.00Hz
U0-28	Encoder 2 (optional) resolution	0~65535	Factory default: 0
U0-29	Torque reference value	0.0%~300.0%	Factory default: 0.0%

U0-30	Cumulative power-up time	Range: 0h~65535h	Factory default: 0h
U0-31	Cumulative run time	Range: 0h~65535h	Factory default: 0h
U0-32	Heat sink temperature 1	I Range: -40 0°C~100 0°C	Factory default: 0.0°C
U0-33	Heat sink temperature 2	Range: -40.0°C~100.0°C	Factory default: 0.0°C
U0-34	FAL fault source	Range: 0~6	Factory default: 0

When the drive reports fault "FAL", the fault source can be known by U0-34.

- 0: No fault
- 1: IGBT overcurrent
- 2: Reserved
- 3: Output grounding fault
- 4: Output overcurrent
- 5: DC bus overvoltage
- 6: Other sources

U0-35	Terminal count value	Range: 0~65535	Factory default: 0
U0-36	Run command log at LoU	Range: 0~1	Factory default: 0
U0-37	Fault code log at LoU	Range: 0~100	Factory default: 0
U0-38	Main circulation execution time	Range: 0.0~6553.5	Factory default: 0.0
U0-39	CtC fault source	Range: 0~3	Factory default: 0

- 0: No fault
- 1: U-phase current detection circuit fault
- 2: V-phase current detection circuit fault
- 3: W-phase current detection circuit fault

U0-40	Higher-bit numbers of actual length	Range: 0~65	Factory default: 0
U0-41	Lower-bit numbers of actual length	Range: 0~65535	Factory default: 0
U0-42	Higher-bit numbers of control panel ^/v stored value	Range: -1~1	Factory default: 0
U0-43	Lower-bit numbers of control panel ^/v stored value	Range: 0.00Hz~655.35Hz	Factory default: 0.00Hz
U0-44	Higher-bit numbers of terminal UP/DOWN stored value	Range: -1~1	Factory default: 0

U0-45	Lower-bit numbers of terminal UP/DOWN stored value	Range: 0.00Hz~655.35Hz	Factory default: 0.00Hz
U0-46	Position control pulse error	Range: -9999~+9999	Factory default: 0
U0-52	Center frequency of wobble frequency	Range: 0Hz~600.00 Hz	Factory default: 0.00 Hz
U0-53	Sync motor rotor angle	Range: 0~65535	Factory default: 0
U0-54	Encoder feedback frequency	Range: 0.00Hz~600.00Hz	Factory default: 0.00 Hz
U0-55	Position reference feed-forward frequency	Range: 0.00Hz~600.00Hz	Factory default: 0.00 Hz
U0-56	Sin gain	Range: 0~65535	Factory default: 0
U0-57	Sin offset	Range: 0~65535	Factory default: 0
U0-58	Cos gain	Range: 0~65535	Factory default: 0
U0-59	Cos offset	Range: 0~65535	Factory default: 0
U0-60	Rotator angle	Range: 0~65535	Factory default: 0

# **Group U1** History Fault

U1-00	History fault 1 (latest)	Range: 0~46	Factory default: 0
U1-01	Run frequency at fault 1	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U1-02	Output current at fault 1	Range: 0.0A~6553.5A	Factory default: 0.0A
U1-03	Bus voltage at fault 1	Range: 0V~1000V	Factory default: 0V
U1-04	Temperature 1 of heat sink at fault 1	Range: -40.0°C~100.0°C	Factory default: 0.0°C
U1-05	Temperature 2 of heat sink at fault 1	Range: -40.0°C~100.0°C	Factory default: 0.0°C
U1-06	Input terminal status at fault 1	Range: 0000~FFFF	Factory default: 0000
U1-07	Output terminal status at fault 1	Range: 0000~FFFF	Factory default: 0000
U1-08	Cumulative run time at fault 1	Range: 0h~65535h	Factory default: 0h

Check the information of the latest fault 1. See Chapter 7 for details of fault codes.

U1-09	Code of fault 2	Range: 0~46	Factory default: 0
U1-10	Run frequency at fault 2	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U1-11	Output current at fault 2	Range: 0.0A~6553.5A	Factory default: 0.0A
U1-12	Bus voltage w at fault 2	Range: 0V~1000V	Factory default: 0V
U1-13	Temperature 1 of heat sink at fault 2	Range: -40.0°C~100.0°C	Factory default: 0.0°C
U1-14	Temperature 2 of heat sink at fault 2	Range: -40.0°C~100.0°C	Factory default: 0.0°C
U1-15	Input terminal status at fault 2	Range: 0000~FFFF	Factory default: 0000
U1-16	Output terminal status at fault 2	Range: 0000~FFFF	Factory default: 0000
U1-17	Cumulative run time at fault 2	Range: 0h~65535h	Factory default: 0h

Check the information of fault 2. See Chapter 7 for details of fault codes.

U1-18	Code of fault 3	Range: 0~46	Factory default: 0
U1-19	Run frequency at fault 3	Range: 0.00Hz~600.00Hz	Factory default: 0.00Hz
U1-20	Output current at fault 3	Range: 0.0A~6553.5A	Factory default: 0.0A
U1-21	Bus voltage w at fault 3	Range: 0V~1000V	Factory default: 0V
U1-22	Temperature 1 of heat sink at fault 3	Range: -40.0°C ~100.0°C	Factory default: 0.0°C
U1-23	Temperature 2 of heat sink at fault 3	Range: -40.0°C ~100.0°C	Factory default: 0.0°C
U1-24	Input terminal status at fault 3	Range: 0000~FFFF	Factory default: 0000
U1-25	Output terminal status at fault 3	Range: 0000~FFFF	Factory default: 0000
U1-26	Cumulative run time at fault 3	Range: 0h~65535h	Factory default: 0h

The recorded fault sequence: fault 3, fault 2, fault 1 (the latest). See Chapter 7 for details of fault codes.

# **Chapter 7 Troubleshooting**

## 7.1 Fault Causes and Troubleshooting

Once drive fault occurs, please identify the causes of fault carefully and make a detailed record of fault symptom. To seek services, please contact the dealer. Parameters U1-00, U1-09 and U1-18 are used to view the records of fault 1, fault 2 and fault 3. Faults are recorded with numeric codes (1~46), while the fault information that corresponds to each numeric fault code is specified in the table below.

## **Table of Fault Codes**

Fault code	Fault display	Fault description	Causes	Solutions
			Torque boost is too big under V/f control	Reduce torque boost value
			Start frequency is too high	Drop start frequency
			Accel time is too short	Prolong the Accel time
		Aggel	Motor parameters are improperly set	Set the parameters correctly according to motor nameplate
1	oC1	oC1 Accel overcurrent	Overload is too heavy	Reduce the load
			Inappropriate V/f curve under V/f control	Set V/f curve correctly
			Restart the rotating motor	Reduce current limited value or flying start
			Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance
			Overload is too heavy	Reduce the load
2		oC2 Const-speed overcurrent	Power rating of the drive is relatively small	Select appropriate drive power rating
	oC2		Input voltage is too low	Check power grid voltage
			Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance

Fault code	Fault display	Fault description	Causes	Solutions
			Load inertia is too big	Use dynamic brake
			Decel time is too short	Prolong the Decel time
_		Decel	Input voltage is too low	Check power grid voltage
3	oC3	overcurrent	Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance
			Load inertia is too big	Use dynamic brake
			Abnormal input volt	Check power grid voltage
4	ov1	Accel overvoltage	Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance
	5 ov2	ov2 Const-speed overvoltage	Improper parameter setting of regulator under SVC control	Properly set regulator parameters
			Abnormal input voltage	Check power grid voltage
5			Load variation is too big	Check the load
			Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance
			Load inertia is too big	Use dynamic braking
			Decel time is too short	Prolong the Decel time
			Abnormal input voltage	Check power grid voltage
6	ov3	ov3 Decel overvoltage	Improper parameter setting of regulator under SVC control	Properly set regulator parameters
			Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance

Fault code	Fault display	Fault description	Causes	Solutions
			Overvoltage or overcurrent	Refer to the solutions of overvoltage or overcurrent
			Output short circuit (phase-to-phase short circuit or output ground short circuit)	Check motor connection and output ground impedance
7	FAL	Module protection	Loose connection of control board	Pull out and reinsert the cables of control board
			Direct connection of inverter module	Seek services
			Control board abnormal	Seek services
			Switching mode power supply (SMPS) failed	Seek services
			Bad motor connection	Check motor connection
8	ti IN	UN Autotune failed	Autotune during rotation of the motor	Autotune in stationary status of the motor
	torv		Big error between real motor parameters and the setting	Set the parameters correctly according to motor nameplate
			Torque boost is too big under V/f control	Reduce torque boost value
			Start FREQ is too high	Drop start frequency
			Accel/Decel time is too short	Prolong the Accel/Decel time
			Motor parameters are improperly set	Set the parameters correctly according to motor nameplate
9	oL1	Drive overloaded	Load is too heavy	Reduce the load
		oveneaded	Inappropriate V/f curve under V/f control	Set V/f curve correctly
			Restart the rotary motor	Reduce current limited value or flying start
			Output short circuit (phase-to-phase short circuit and output ground short circuit)	Check motor connection and output ground impedance

Fault code	Fault display	Fault description	Causes	Solutions
			Torque boost is too big under V/f control	Reduce torque boost value
			Inappropriate V/f curve under V/f control	Set V/f curve correctly
			Motor parameters are improperly set	Set the parameters correctly according to motor nameplate
10	oL2	Motor overloaded	Improper setting of motor overloaded protection time	Properly set the motor overloaded protection time
			Motor stalled or sharp variation of load	Identify the causes of motor stalling or check the load condition
			Long-time running of ordinary motor at low speed with heavy load	Select variable frequency motor
		Current C detection circuit failed	Abnormal connection between control board and drive board	Check and re-connection
11	CtC		Abnormal current detection circuit of control board	Seek services
	0.0		Abnormal current detection circuit of drive board	Seek services
			Current sensor failed	Seek services
			SMPS failed	Seek services
	GdP		Output connection ground short circuit	Check motor connection and output ground impedance
12		Output ground short-circuit	Motor insulation abnormal	Check the motor
		protection	Inverter module abnormal	Seek services
			Output ground leakage current is too big	Seek services

Fault code	Fault display	Fault description	Causes	Solutions
			Severe voltage imbalance among power supply phases	Check power grid voltage
13	ISF	Input power supply fault	Abnormal input wiring of power supply	Check power supply input wiring
			Abnormal bus capacitance	Seek services
			Motor cable connection abnormal	Check motor connection
14	oPL	Output phase loss	Imbalance among motor three phases	Check or replace the motor
		ioss	Incorrect setting of vector control parameters	Correctly set vector control parameters
		oL3 Inverter module overload protection	Overcurrent	Handle it with the methods for overcurrent
15	15 oL3		Input power supply abnormal	Check input power grid voltage
15			Motor output abnormal	Check the motor or motor connection
			Inverter module abnormal	Seek services
			Ambient temperature is too high	Drop ambient temperature
		Module	Fan failed	Replace the fan
16	oH1	(IGBT)	Air duct blocked	Clear air duct
10	OTT	thermal protection	Temperature sensor abnormal	Seek services
			Inverter module mounting abnormal	Seek services
			Ambient temperature is too high	Drop ambient temperature
17	17 oH2	oH2 Motor (PTC) thermal protection	Improper setting of motor thermal protection point	Correctly set motor thermal protection point
			Thermal detection circuit failed	Seek services

Fault code	Fault display	Fault description	Causes	Solutions
			Temperature sensor not well connected with socket	Pull out and re-insert
18	оН3	PIM temperature	Ambient temperature is too low	Raise ambient temperature
		measurement circuit fault	Module detection circuit failed	Seek services
			Thermistor failed	Seek services
19	CLL	Encoder disconnected	No signal or lack of signal	Check if encoder is damaged, and/or there is some abnormity with the encoder power supply
			Lines disconnected	Reconnect encoder lines
			Wrong disconnection	Reconnect encoder lines
	20 EC1	Option board 1 connection abnormal	Loose or poor option board 1 connection	Pull out and reinsert
20			Option board 1 abnormal	Seek services
			Control board abnormal	Seek services
		Option board	Loose or poor option board 2 connection	Pull out and reinsert
21	EC2	2 connection abnormal	Option board 2 abnormal	Seek services
			Control board abnormal	Seek services
		Abnormal flat cable	Loose or poor flat cable connection	Pull out and re-insert after complete power off
22	dLC	connection of	Drive board abnormal	Seek services
		control board	Control board abnormal	Seek services
23	TEr	Function conflict between analog terminals	Analog input terminals are set to the same function	Do not set analog inputs to the same function

Fault code	Fault display	Fault description	Causes	Solutions
24	PEr	External	External fault terminal is enabled	Check the status of external fault terminal
24	PEI	equipment error	Stall condition lasts too long	Check if the load is abnormal
26	to2	Consecutive run time attained	"Consecutive run time attained" enabled	See specification of Group E0
27	to3	Cumulative run time attained	"Cumulative run time attained" enabled	See specification of Group E0
28	SUE	Abnormal power supply at run	DC bus voltage fluctuation is too big or the power is lost	Check input power grid voltage and load
29	EPr	EEPROM read/write fault	Parameter read/write abnormal at control board  Seek services	
		Current CL detection	Power supply voltage abnormal	Check grid power supply voltage
30	CCL		Abnormal contactor feedback circuit at drive board	Seek services
		circuit failed	Contactor failed	Seek services
			Buffer resistance failed	Seek services
			Abnormal SMPS	Seek services
			Improper setting of baud rate	Set properly
31	TrC	Abnormal port	Communication port disconnected	Reconnected
31	31 110	n	Upper computer/device does not work	Make upper computer/device work
			Drive communication parameter error	Set properly
		Control panel	Control panel disconnected	Reconnected
32	PdC	communicatio n abnormal	Severe EMI	Check peripheral equipment or seek services

Fault code	Fault display	Fault description	Causes	Solutions
22	CD:	Parameter	Parameter uploading or downloading abnormal	Seek services
33	СРу	copy failure	No parameters stored at control panel	Seek services
35	SFt	Software version compatibility failure	Version of control panel is not consistent with that of control board	Seek services
36	CPU	Abnormal power loss	Abnormal power loss in last operation	RESET the fault
		power loss	Faulty control board	Seek services
		Overcurrent	SMPS failed	Seek services
37	oCr	benchmark error	Control board failed	Seek services
38	SP1	5V supply out-	SMPS failed	Seek services
30	5	of-limit	Control board failed	Seek services
39	SP2	10V supply	SMPS failed	Seek services
39	3F2	out-of-limit	Control board failed	Seek services
		Al input	Control board failed	Seek services
40	AIP	out-of-limit	Al input is too high or low	Set AI input within correct range
41	LoU	Undervoltage protection	DC bus voltage is too low	Check input voltage if it is too low or the drive is the process of power loss
			Set value of over-speed is too small	Set over-speed value correctly
42	oSP	Over-speed	Big fluctuation of load	Stabilize the load
72	oSP Over-speed		Unreasonable vector control parameter setting	Set correctly
			Speed bias setting value is too small	Set speed bias reasonably
43	QDI	Speed bias is	Big fluctuation of load	Stabilize the load
43	SPL Speed bias is large		Unreasonable vector control parameter setting	Set correctly

Fault code	Fault display	Fault description	Causes	Solutions
45	Plo	PID feedback	Abnormal PID feedback channel abnormal	Check the feedback channel
45	PIO	lost	Inappropriate setting of PID parameters	Set properly
		Abnormal	Communication wiring problem	Rewiring
46	PFS	Profibus communicatio n	Severe ambient EMI	Check peripheral equipment or seek services

## **ATTENTION:**

When a fault occurs, please identify the causes and seek solutions according the guidance in the table. If the fault fails to be solved, do not apply power to the drive again. Contact the supplier for service in time

# **Chapter 8 Maintenance**

Ambient temperature, humidity, salt mist, dust, vibration, aging and wear of internal components may result in drive faults. Routine maintenance shall be performed during the use and storage.

## **ATTENTION:**

Please make sure the power supply of the drive has been cut off, and DC bus voltage has discharged to 0V before the maintenance.

## 8.1 Routine Inspection

Please use the drive in the environment recommended by this manual, and perform routine inspection in accordance with the table below.

Inspection items	Inspection aspects	Inspection methods	Criteria
	Temperature	Thermometer	-10°C~40°C
	Humidity	Hygrometer	5%~95%, condensation not allowed
Operating environment	Dust, oil stains, moisture and water- drop	Visual inspection	No filthy mud, oil stains and water drop
	Vibration	Observation	Smooth running. No abnormal vibration
	Gas	Smell, visual inspection	No peculiar smell and abnormal smoke
	Noise	Listen	No abnormal noise
	Gas	Smell, visual inspection	No peculiar smell and abnormal smoke
Drive	Appearance	Visual inspection	No defect and deformation
	Heat dissipation and temperature rise	Visual inspection	No dust and/or fiber particles in air duct, normal working of fans, normal air speed and volume, no abnormal temperature rise

Inspection items	Inspection aspects	Inspection methods	Criteria
	Thermal status	Smell	No abnormal heating and scorching smell
Motor	Noise	Listen	No abnormal noise
	Vibration	Observe, listen	No abnormal vibration and sound
	Power supply input current	Ammeter	In the range of requirement
	Power supply input voltage	Voltmeter	In the range of requirement
Run status	Drive output current	Ammeter	In the range of requirement
parameters	Drive output voltage	Voltmeter	In the range of requirement
	Temperature	Thermometer	The difference between U0-33 displayed temperature and ambient temperature does not exceed 40°C

## 8.2 Regular Maintenance

Users should perform regular inspection of the drive every 3~6 months, so as to eliminate the potential faults.

## **ATTENTION:**

Please make sure power supply of the drive has been cut off, and DC bus voltage has been discharged to 0V prior to maintenance. Never leave screws, gaskets, conductors, tools and other metal articles inside the drive. Failure to comply may result in equipment damage. Never modify the interior components of the drive in any condition. Failure to comply may result in equipment damage.

Inspection items	Measures
Check if control terminal screws are loose	Tighten
Check if main circuit terminal screws are loose	Tighten
Check if ground terminal screws are loose	Tighten
Check if copper bar screws are loose	Tighten
Check if drive mounting screws are loose	Tighten

Inspection items	Measures
Check if there are defect on power cables and control cables	Replace the cables
Check if there is dust on circuit board	Clear it up
Check if air duct is blocked	Clear it up
Check if drive insulation is failed	Test the ground terminal with 500V megameter after all input and output terminals are short-circuited via conductors. Ground test on individual terminals is strictly prohibited since this may cause damage to inverter.
Check if motor insulation is failed	Remove input terminals U/V/W of motor from drive and test the motor alone with 500V megameter. Failure to comply may result in drive failure.
Check if the storage period of the drive is over two years	Carry out power-on test, during which, the voltage should be boosted to rated value gradually using a voltage regulator; be sure to run at no load for more than 5 hours.

# 8.3 Replacement of Vulnerable Parts

Vulnerable parts of drive include cooling fan, electrolytic capacitor, relay or contactor etc. The service lives of these parts are subject to environment and working conditions. To maintain a favorable operating environment is conducive to improving the service life of parts and components; routine inspection and maintenance also contributes to effective improvement of parts' service life. To prolong the service life of entire drive, the cooling fan, electrolytic capacitor, relay or contactor and other vulnerable parts should be subjected to routine inspection according to the table below. Please replace the abnormal parts (if any) in time.

Vulnerable parts	Service life	Cause of damage	Criteria
Fan	30,000~40,000h	Wear of bearing and aging of blade	Check if fan blades have cracks Check if there is abnormal vibration and noise on working
Electrolytic capacitor	40,000~50,000h	Excessively high ambient temperature and excessively low air pressure result in electrolyte volatilization; aging of electrolyte capacitor	Check if there is liquid leakage Check if safety valve projects Check if capacitance value is out of allowable range Check if insulation resistance is abnormal
Relay/cont actor	50,000~100,000 times	Corrosion and dust impairs the contacting effect of contact; excessively frequent contact action	Open/close failure False alarm of CCL fault

## 8.4 Storage

Storage environment should meet the requirements as set forth in the table below.

Items	Requirements	Recommended storage method and environment
Storage temperature	-40~+70°C	In case of long-term storage, areas with an ambient temperature of less than 30°C are recommended Avoid the storage in areas where temperature shock may result in condensation and freezing
Storage humidity	5~95%	Product could be sealed with plastic film and desiccant
Storage environment	A space with low vibration and low content of salt where there is no direct exposure to sunlight, dust, no corrosive or flammable gas, oil stain, vapor and water drop	Product could be sealed with plastic film and desiccant


#### ATTENTION:

Since long-term storage may lead to the deterioration of electrolytic capacitor, the drive must be powered up once in case storage period exceeds 2 years. After applying the power, input voltage must be boosted to rated value gradually using a voltage regulator, and be sure to have the inverter operated at no load for more than 5 hours.


# **Appendix Communication Protocol**

#### 1. Networking Mode

The drives have two networking modes, single master/multiple slaves networking and single master/single slave networking.



Single master/multiple slaves networking diagram



Single master/single slave networking diagram

#### 2. Interface Mode

RS485 or RS232 interface: asynchronous, half-duplex. Default data format: 8-N-2 (8 data bits, no check, two stop bits), 9600 bps. See parameters of Group H0 for parameter setting.

#### 3. Communication Mode


 Drive is used as a slave for master-slave station-to-station communication. When master sends commands using broadcast address, the slave does not respond;

- Native address, baud rate and data format of inverter are set through slave operating panel or serial communication:
- 3) Slave reports the current fault information in the latest response frame for master polling;
- 4) Drive employs RS-485 interface or extended RS-232 interface.

#### 4. Protocol Format

Modbus protocol supports both RTU and ASCII mode.

RTU data frame format is shown as the figure below:



#### RTU:

In RTU mode, idle time between frames can be set through function code or comply with Modbus internal convention, for which the minimum inter-frame idle is as follows:

- Frame header and end define the frame by making bus idle time equal to or longer than 3.5-byte time;
- 2) After the start of frame, the clearance between characters must be less than 1.5character communication time, or the newly received characters will be treated as the header of the new frame;
- 3) Data check employs CRC-16 and the whole information participates in the check; the high and low bytes of check sum shall be sent after exchange. Please refer to examples at the end of protocol for details of CRC check;
- 4) The bus idle time of at least 3.5 characters (or set minimum bus idle time) shall be maintained between frames and needs not to accumulate the starting and ending idle time.

The data frame of which the request frame is "reading parameter value of b0-02 from slave 0x01" is as below:

Address	Function code	Register address	Read words	Check sum
01	03	02 02	00 01	24 72

Response frame of slave 0x01 is as below:


#### **Appendix Table 2**

Address	Function code	Register address	Read words	Check sum
01	03	02	13 88	B5 12

#### ASCII:

- Frame header is "0x3A" while the default frame end is "0x0D0A"; also, frame end can be configured and defined by user;
- In ASCII mode, all data bytes other than frame header and end are sent in the form of ASCII code; high-4-bit byte and low-4-bit byte are sent successively;
- 3) In ASCII mode, the data is 7-bit long. For 'A'~'F', their uppercase ASCII codes are used:
- Data is subjected to LRC check which covers the information portion from slave address to data;
- Check sum is equal to the complement of sum of characters that participate in data check (abort the feed bit).

In ASCII mode, data frame format is as follows:



Examples of Modbus data frame in ASCII mode are as follows.

The writing of 4000 (0xFA0) into internal register 02 02 of slave 0x01 is shown in the table below. LRC check = complement of (01+06+02+02+0x0F+0xA0) = 0x46

#### **Appendix Table 3**

	Header	Add	ress	Param	eter	F	Register	addres	s	١	Write-in	content	t	LRC	check	Er	nd
Character	:	0	1	0	6	0	2	0	2	0	F	Α	0	4	6	CR	LF
ASCII	ЗА	30	31	30	36	30	32	30	32	30	46	41	30	34	36	0D	0A

Different response delays can be set for drive through parameters so as to adapt to specific application requirements of various master stations; in RTU mode, the actual response delay is not less than 3.5 characters, while in ASCII mode, the actual response delay shall not be less than 1ms

#### 5. Protocol Function

The uppermost function of Modbus is to read and write parameters, and different parameters determine different operation requests. Parameters operations supported by inverter Modbus protocol are as shown in the table below:

<b>Appendix</b>	Table 4	<b>Parameters</b>
Appelluix	IGDIC T	i ai aiiietei 3

Parameter	Meaning of parameter
0x03	Read drive functional parameters and run status parameters
0x06	Over-write individual drive functional parameters or control parameters, which are not saved on power loss
0x08	Line diagnosis
0x10	Over-write multiple drive functional parameters or control parameters, which are not saved on power loss
0x41	Write individual drive functional parameters or control parameters, and save them to non-volatile storage unit
0x42	Parameter management

Functional parameters, control parameters and status parameters of the drive are all mapped to read-write register of Modbus. Read-write characteristics and range of parameters comply with the instructions of user manual of the drive. Group numbers of drive parameters are mapped as high byte of register address, while in-group indexes are mapped as low byte of register address. Drive control parameters and status parameters are all virtualized as drive parameter groups. The corresponding relations between parameter group numbers and their high bytes of register address are as shown in table below:

Appendix Table 5 High-byte register addresses mapped from parameter group numbers

Parameter group	Mapping register address, high byte	Parameter group	Mapping register address, high byte
A0	0x00	E1	0x12
A1	0x01	F0	0x13
b0	0x02	F1	0x14
b1	0x03	F2	0x15
b2	0x04	F3	0x16
C0	0x05	F4	0x17
C1	0x06	F5	0x18
C2	0x07	F6	0x19

Parameter group	Mapping register address, high byte	Parameter group	Mapping register address, high byte
C3	0x08	H0	0x1A
C4	0x09	H1	0x1B
d0	0x0A	H2	0x1C
d1	0x0B	L0	0x1D
d2	0x0C	L1	0x1E
d3	0x0D	U0	0x1F
d4	0x0E	U1	0x20
d5	0x0F	U2	0x21
d6	0x10	Drive control parameter group	0x62
E0	0x11	Drive status parameter group	0x63

For example, the register address of drive parameter b0-02 is 0x0202 while that of E0-07 is 0x1107.

In the following paragraphs, we present the formats and meanings of Modbus protocol parameters and data portion hereafter, i.e. to introduce the "parameter" and "data" related contents in above-noted data frame format. These two parts constitute the application layer protocol data unit of Modbus. The application layer protocol data unit mentioned below refers to these two parts. We take RTU mode for example to describe frame format below. The length of application layer protocol data unit should be doubled in ACSII mode.

Application layer protocol data units of various parameters are as follows:

Parameter 0x03: read register content

Request format is shown in appendix table 6.

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x03
Register address	2	0x0000~0xFFFF
Number of registers	12	0x0001~0x000C
Check	LRC or CRC	

Response format is shown in appendix table 7.

## **Appendix Table 7**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x03
Number of read bytes	1	2* number of registers
Register content	2* number of registers	
Check	LRC or CRC	

Parameter 0x06(0x41): write register content (0x41 saved at power loss) Request format is shown in appendix table 8.

# **Appendix Table 8**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x06
Register address	2	0x0000~0xFFFF
Register content	2	0x0000~0xFFFF
Check	LRC or CRC	

Response format is shown in appendix table 9.

#### **Appendix Table 9**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x06
Register address	2	0x0000~0xFFFF
Register content	2	0x0000~0xFFFF
Check	LRC or CRC	

Some parameters of the drive are reserved and cannot be modified by communication setting.

The list of these parameters is shown in appendix table 10.

## Appendix Table 10

	Parameters	Remarks
(Autotune)	d0-22 d3-22	Communication not operable
(Parameter passing)	A0-05	Communication not operable
(User password)	A0-00	User password can not be set by communication, but the user password set by control panel can be unlocked by writing the same password from upper computer/device communication. Upper computer/device can view and modify parameters.

Parameter 0x08: communication line diagnosis.

Request format is shown in appendix table 11.

## **Appendix Table 11**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x08
Sub-parameter	2	0x0000~0x0030
Data	2	0x0000~0xFFFF
Check	LRC or CRC	

Response format is shown in appendix table 12.

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x08
Sub-parameter	2	0x0000~0x0030
Data	2	0x0000~0xFFFF
Check	LRC or CRC	

Sub-parameters supported by line diagnosis are as set forth in the table below.

# Appendix Table 13 Line diagnosis sub-parameter

Sub-PARA	Data (request)	Data (response)	Meaning of subfunction
0x0001	0x0000	0x0000	Reinitialize communication: make no- response mode disable.
0x0001	0xFF00	0xFF00	Reinitialize communication: make no- response mode disable.
0x0003	"New frame end" 00	"New frame end" 00	Set the frame end of ASCII mode and this "new frame end" will replace the original line feed symbol.(Note: new frame end shall not be greater than 0x7F and shall not be equal to 0x3A)
0x0004	0x0000	No response	Set no-response mode. Only response to reinitialization communication request. This is mainly used for isolating faulty equipment.
0x0030	0x0000	0x0000	Make slave no-response to invalid command and error command
UXUU3U	0x0001	0x0001	Make slave response to invalid command and error command

Parameter 0x10: write parameters continuously Request format is shown in appendix table 14.

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x10
Register address	2	0x0000~0xFFFF
Number of registers	2	0x0001~0x0004
Number of bytes of register content	1	2* number of operation registers
Register content	2* number of operation registers	
Check	LRC or CRC	

Response format is shown in appendix table 15.

# **Appendix Table 15**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x10
Register address	2	0x0000~0xFFFF
Number of registers	2	0x0001~0x0004
Check	LRC or CRC	

Parameter 0x42: parameter management

Request format is shown in appendix table 16.

# **Appendix Table 16**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x42
Sub-parameter	2	0x0000~0x0007
Data	2 (high byte is parameter group number, while low byte is parameter in-group index)	
Check	LRC or CRC	

Response format is shown in appendix table 17.

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x42
Sub-parameter	2	0x0000~0x0007
Data	2	0x0000~0xFFFF
Check	LRC or CRC	

Sub-parameters supported by parameter management are set forth in the table 18.

# Appendix Table 18 Parameter management sub-parameters

Sub-PARA	Data (request)	Data (response)	Meaning of sub- function
0x0000	Parameter group number and in-group index respectively possess high and low bytes	Upper limit of parameter	Read the upper limit of parameter
0x0001	Parameter group number and in-group index respectively possess high and low bytes	Lower limit of parameter	Read the lower limit of parameter
0x0002	Parameter group number and in-group index respectively possess high and low bytes	See specification below for details of parameter characteristics	Read the characteristics of parameter
0x0003	Parameter group number possesses high byte, while the lower byte is 0.	Maximum value of in-group index	Read the maximum value of in-group index
0x0004	Parameter group number possesses high byte, while the lower byte is 0.	The next parameter group number possesses high byte, while the lower byte is 0.	Read the next parameter group number
0x0005	Parameter group number possesses high byte, while the lower byte is 0.	The previous parameter group number possesses high byte, while the lower byte is 0.	Read the previous parameter group number

Status parameter group should not be modified and does not support the reading of upper and lower limits. Parameter characteristic is 2-byte long, and the bit definition is shown in the table below:

# **Appendix Table 19 Parameter characteristics**

Characteristic parameter (BIT)	Value	Meaning
	00B	Changeable in run
BIT1~BIT0	01B	Not changeable in run, but changeable in stop
	10B	Read only
	11B	Factory parameters
	000B	Accuracy: 1
	001B	Accuracy: 0.1
BIT4~BIT2	010B	Accuracy: 0.01
DI14~DI12	011B	Accuracy: 0.001
	100B	Accuracy: 0.0001
	Others	Reserved
	000B	The unit is A
	001B	The unit is Hz
	010B	The unit is $\Omega$
BIT7~BIT5	011B	The unit is r/min
DIT7~DIT3	100B	The unit is S
	101B	The unit is V
	110B	The unit is %
	111B	No unit
BIT8	0: decimal; 1: hexadecimal	Display format
BIT9	0: non-quick menu; 1: quick menu	Quick menu or not
BIT10	0: not uploaded; 1: uploaded	Uploaded to control panel or not
	001B	Data width: 1
	010B	Data width: 2
	011B	Data width: 3
BIT13~BIT11	100B	Data width: 4
	101B	Data width: 5
	110B	Data width: 6
	111B	Data width: 7
BIT14	Number of symbols available/not available	0: unsigned number; 1: directed number
BIT15	Reserved	Reserved

The response format is shown as table 20 when an error occurs.

## **Appendix Table 20**

Application layer protocol data unit	Data length (number of bytes)	Range
Parameter	1	0x80 + parameter
Error code	1	
Check	LRC or CRC	

Error codes supported by Modbus protocol are listed in the table below:

## **Appendix Table 21 Error codes**

Error codes	Meanings of error codes
0x01	Illegal parameter
0x02	Illegal register address
0x03	Data error, i.e. data are out of upper limit or lower limit
0x04	Slave operation failed, including errors caused by invalid data
	although there are in the range
0x05	Command is valid and being processed, mainly used for storing data
	to non-volatile storage
0x06	Slave is busy, please try again later; mainly used for storing data into
	non-volatile storage
0x18	Message frame error: including message length error and check error
0x20	Parameter is not changeable
0x21	Parameter is not changeable during the running
0x22	Parameter is under password protection

Drive control parameters are used for start, stop and run frequency setting. By detecting drive status parameters, run status and run mode can be obtained. Drive control parameters and status parameters are shown in appendix table 22.

### **Appendix Table 22 Control parameters**

Register address	Parameter name	Save at power loss
		1033
0x6200	Control command word	No
0x6201	Master frequency setting	Yes
0x6202	Auxiliary frequency setting	Yes
0x6203	Master frequency reference	No

Register address	Parameter name	Save at power loss
0x6204	Auxiliary frequency reference	No
0x6205	Multi-step frequency reference	No
0x6206	Simple PLC frequency reference	No
0x6207	PID digital setting percentage (0~100.0%)	No
0x6208	PID feedback percentage (0~100.0%)	No
0x6209	Driven torque limit (0~200.0%)	No
0x620A	Brake torque limit (0~200.0%)	No
0x620B	Reserved	No
0x620C	Reserved	No
0x620D	Reserved	No
0x620E	Analog AO1 source setting	No
0x620F	Analog EAO source setting	No
0x6210	Digital DO output source setting	No
0x6211 Setting of slave frequency setting proportion (0~100.0%)		No
0x6212	Virtual terminal communication reference	No
0x6213	Accel time 1	Yes
0x6214	Decel time 1	Yes

# **Appendix Table 23 Status parameters**

Register address	Parameter name	
0x6300	Run status word 1	
0x6301	Current run frequency	
0x6302	Output current	
0x6303	Output voltage	
0x6304	Output power	
0x6305	Rotary speed	
0x6306	Bus voltage	
0x6307	Output torque	
0x6308	External counter	

Register address	Parameter name
0x6309	High-bit words of actual length
0x630A	Low-bit words of actual length
0x630B	Status of digital input terminal
0x630C	Status of digital output terminal
0x630D	Setting of run frequency
0x630E	PID setting
0x630F	PID feedback
0x6310	Set length
0x6311	Set Accel time 1
0x6312	Set Decel time 1
0x6313	Al1 (unit: V)
0x6314	Al2 (unit: V)
0x6315	Al2 (unit: V) (Negative value indicates the corresponding digital
0.0010	complement)
0x6316	DI (unit: kHz)
0x6317	Fault 1 (the latest)
0x6318	Fault 2
0x6319	Fault 3
0x631A	Run display parameter
0x631B	Stop display parameter
0x631C	Setting of drive control mode
0x631D	Frequency reference mode
0x631E	Master frequency reference
0x631F	Digital setting of master frequency reference
0x6320	Auxiliary frequency reference
0x6321	Digital setting of auxiliary frequency reference
0x6322	Drive status word 2
0x6323	Current drive fault

Drive control bits are defined as below table 24.

# **Appendix Table 24 Control bits**

Control bit	Value	Meaning	Function description
BIT0	0	Run command disabled	Stop the drive
БПО	1	Run command enabled	Start the drive

Control bit	Value	Meaning	Function description
	1	Reverse	Set the run direction
BIT1	0	Forward	when run command enabled
BIT2	1	Jog	
DITZ	0	Jog disabled	
BIT3	1	Reset command enabled	
БПЗ	0	Reset command disabled	
BIT4	1	Coast to stop enabled	
D114	0	Coast to stop disabled	
BIT15~BIT5	000000B	Reserved	

#### **ATTENTION:**

When BIT0 and BIT2 coexist, jog takes precedence.

Drive status bits are shown in appendix table 25.

# Appendix Table 25 Status word 1 bits

Status bit	Value	Meaning	Remarks
BIT0	1	Run	
БПО	0	Stop	
BIT1	1	Reverse	
БП	0	Forward	
	00B	Constant speed	
BIT3~BIT2	01B	Accel	
	10B	Decel	
BIT4	0	Main setting not attained	
	1	Main setting attained	
BIT7~BIT5	Reserved		
BIT15~BIT8	0x00~0xFF	Fault code	0: drive normal.  Non-0: drive at fault; Refer to relative specification of the fault codes in Chapter 7 in this user manual

# Appendix Table 26 Status word 2 bits

Status bit	Value	Meaning	Remarks
BIT0	1	Jog	
DITU	0	Non-jog	
DITA	1	PID run	
BIT1	0	Non-PID run	
DITO	1	PLC run	
BIT2	0	Non-PLC run	
	1	Run at multi-step	
BIT3		frequency	
Billo	0	Run at non-multi step	
	Ŭ	frequency	
BIT4	1	Ordinary run	
DITT	0	Non-ordinary run	
DITE	1	Wobble frequency	
BIT5	0	Non-wobble frequency	
DITO	1	Undervoltage	
BIT6	0	Normal voltage	
	1	Sensor-less vector	
BIT7	'	control	
Dill	0	Non-sensor-less vector	
		control	
	1	Closed-loop vector	
BIT8		control	
	0	Non-closed-loop vector	
		control	
BIT9	1	Position control	
	0	Non-position control	
BIT10	1	Autotune	
	0	Non-autotune	
Others	0	Reserved	

#### 6. Operation Instructions

0x03 reads multiple (including one) registers (default address is 0x01). Master enquiry:

## **Appendix Table 27**

Address	Parameter	Register address	Number of registers	Check code
01	03	XX XX	000X	XX XX

Slave response:

### **Appendix Table 28**

Address	Parameter	Total number of bytes	Data	Check code
01	03	2* number of registers	Bn~B0	XX XX

Register address: 0x00 00~0x63 22;

Number of registers: 0x00 01~0x00 0C;

Data: n is equal to (2 x the number of registers -1).

Application example:

Note: before using communication controlling drive, please check if hardware is properly connected; in addition, be sure to properly set the communication data format, baud rate and address.

Parameter 0x03 is used here to read values of 0x01 slave's control parameters b0-00, b0-01, b0-02 and b0-03. At this moment, b0-00 = 0, b0-01 = 0, b0-02 = 50.00, b0-03 = 0.

## **Appendix Table 29**

	Address	PARAM	Register address	Number of registers	Number of data bytes	Data	Check sum
Request	01	03	02 00	00 04	None	None	44 B1
Response	01	03	None	None	08	0000,0000, 1388, 000B	11 79

Management of parameter 42H

Master enquiry:

#### **Appendix Table 30**

Address	Parameter	Sub-parameter	Data	Check code
01	42	XX XX	XX XX	XX XX

Slave response:

### **Appendix Table 31**

Address	Parameter	Sub-parameter	Data	Check code
01	42	XX XX	B1~B0	XX XX

Register address: 0x00 00~0x21 06 and 0x62 00~0x63 22.

Sub-parameter: refer to the table of parameter managing sub-parameter.

Data: refer to the values of data as set forth in the table of parameter managing sub-parameter.

Example:

Parameter 0x42 is used here to read the upper limit value of 0x01 slave's control parameter b0-02 which is 600.00:

## **Appendix Table 32**

	Address	Parameter	Sub-PARA	Data	Check sum
Request	01	42	00 00	02 02	F9 64
Response	01	42	00 00	EA 60	36 8D

0x06 (0x41 data storage) writes that individual parameter data is not saved. Master enquiry:

## **Appendix Table 33**

Address	Parameter	Register address	Data	Check code
01	06	62 00	B1 B0	XX XX

Slave response:

## **Appendix Table 34**

Address	Parameter	Register address	Data	Check code
01	06	62 00	B1 B0	XX XX

#### Example:

Parameter 0x06 is used here to write 0x01 slave's control command (forward), i.e. to write 1 to register address 0x6200:

	Address	Parameter	Register address	Number of registers	Number of data bytes	Data	Check sum
Request	01	06	62 00	None	None	00 01	57 B2
Response	01	06	62 00	None	None	00 01	57 B2

10H writes that the data of multiple registers are not saved.

Master enquiry:

### **Appendix Table 36**

Address	Parameter	Register address	Number of registers	Number of data bytes	Data	Check code
01	10	XX XX	0001~0004	Number of 2* registers	I XX XX	XX XX

Slave response:

#### **Appendix Table 37**

Address	Parameter	Register address	Number of registers	Check code
01	10	xx xx	Number of 2* registers	xx xx

Register address: 0x00 00~0x1E 04, 0x62 00~0x62 14

Number of registers: 0x00 01~0x00 04 Number of data bytes: 0x02~0x08

Data: n is equal to (2 x the number of registers -1).

#### Example:

Parameter 0x10 is used here to write the corresponding write data 1, 6 and 0 in control registers 0x6200, 0x6201 and 0x6202 of slave 0x01:

# **Appendix Table 38**

	Address	Parameter	Register address	Number of registers	Number of data bytes	Data	Check sum
Request	01	10	62 00	00 03	06	0001,0006,0000	CE F8
Response	01	10	62 00	00 03	None	None	9F B0

0x08: communication line diagnosis

Master enquiry:

## **Appendix Table 39**

Address	Parameter	Sub-parameter	Data	Check code
01	08	XX XX	XX XX	XX XX

Slave response:

# **Appendix Table 40**

Address	Function code	Subfunction code	Data	Check code
01	08	XX XX	Bn~B0	XX XX

Sub-parameter: table of line diagnosis sub-parameter.

#### Example:

Parameter 0x08 is used here to set the communication no-response mode of 0x01 slave:

## **Appendix Table 41**

	Address	Parameter	Sub-PARA	Data	Check sum
Request	01	08	00 04	00 00	A1 CA
Response	01	08	00 04	00 00	A1 CA

#### Read error or warning

In case illegal parameter, illegal register address, data errors and other anomalies are detected during communication, slave response communication anomaly will occur. In such a case, the slave response will be in the following formats:

Slave response:

#### **Appendix Table 42**

Address	Parameter	Data	Check code
01	0x80+parameter	Error code	XX XX

#### Example:

Parameter 0x10 is used here to write the corresponding write data 1, 11, 4 and 100.00 in control registers 0x6200, 0x6201, 0x6202 and 0x6203 of 0x01 slave:

	Address	Parameter	Register address	Number of registers	Number of data bytes	Data	Check
			auuless	registers	uala byles		Suili
Request	01	10	62 00	00 04	08	0001,000B 0004 2710	DE 64
Response	01	90	None	None	None	20	0C 01

#### 7. LRC/CRC Generation

In consideration of the demand for speed improvement, CRC-16 is usually realized in form mode. C-language source codes for realization of CRC-16 are given below. Please note that the high and low bytes have been exchanged in final result, that is to say, the result is the CRC check sum to be sent:

```
/* The function of CRC16*/
Uint16 CRC16(const Uint16 *data, Uint16 len)
    Uint16 crcValue = 0xffff;
    Uint16 i;
    while (len--)
         crcValue ^= *data++:
         for (i = 0; i \le 7; i++)
             if (crcValue & 0x0001)
             {
                  crcValue = (crcValue >> 1) ^ 0xa001;
             }
             else
                  crcValue = crcValue >> 1;
         }
    }
    return (crcValue);
}
```